

Parameter manual

Language **English**
Translation
Document No. 5.04054.07
Part No. 392424
Status 26.05.2014

be in motion **be in motion**



b maXX[®] BM4100

Active mains inverter

Parameter manual

Software Version 03.09

E	5.04054.07
----------	------------

Read the Operating Manual before starting any work!

Copyright	<p>The owner may produce an unrestricted number of copies of this Parameter manual solely for internal use. This Parameter manual may not be copied or reproduced, even in extract form, for any other purpose.</p> <p>Use and disclosure of the contents of this Parameter manual are not permitted. Names or company symbols in this Parameter manual can be trademarks, the use of which by third parties for their own purposes may infringe the rights of the owners.</p>
Preliminary information	<p>Caution: The following applies if this document is identified as preliminary information: This version contains preliminary technical information which the users of the devices and functions described are intended to receive in advance, in order to be able to make arrangements for any changes or functional enhancements that may be required. This information should be considered to be provisional, as it has not yet been subjected to the final Baumüller internal review process. In particular this information is still subject to change, so that no legal obligation can be deduced on the basis of this preliminary information. Baumüller accepts no liability for damages that may arise from this possibly erroneous or incomplete version.</p> <p>Should you detect or suspect errors of content and/or serious technical errors in this preliminary information, we ask you to contact the Baumüller support person responsible for you and inform us of your findings and comments so that they might be considered and possibly incorporated when the preliminary information becomes finalized (reviewed by Baumüller).</p> <p>The conditions noted in the following section under "Liability" do not apply in the case of preliminary information.</p>
Obligation	<p>This Parameter manual is a part of the device/machine. This Parameter manual must be accessible to the operator at all times and be in a legible condition. When the device/machine is sold/relocated, this Parameter manual must be passed on together with the device/machine by the owner.</p> <p>After the device/machine is sold, this original and all copies must be handed over to the purchaser. After disposal or other end of service life, this original and all copies must be destroyed.</p> <p>When this Parameter manual is handed over, the corresponding Operating Manuals with earlier issue dates become invalid.</p> <p>Please note that specifications/data/information are the current values on the date of printing. These specifications are not legally binding for measuring, computation and costing.</p> <p>Baumüller Nürnberg GmbH reserves the right to change the technical data and operation of Baumüller products within the framework of its own further development of the products.</p> <p>However no guarantee can be provided regarding the freedom from errors of this Parameter manual, unless otherwise described in the General Conditions for Sales and Supply.</p>

© **Baumüller Nürnberg GmbH**

Ostendstr. 80 - 90
90482 Nürnberg
Deutschland

Tel. +49 9 11 54 32 - 0
Fax: +49 9 11 54 32 - 1 30

E-Mail: mail@baumueller.de
Internet: www.baumueller.de



Table of contents

1	Introduction	5
1.1	Copyright and trade mark	5
2	Fundamental Safety Instructions	7
2.1	Safety notes and instructions	7
2.2	Information signs	7
3	Control Structures	9
4	Data Set Management	13
4.1	General information	13
4.2	Command interface	15
4.3	Parameter organization within the data sets	16
4.4	State of delivery	17
4.5	Start-up action	17
4.6	How to change, load, copy and store parameters	18
4.7	How to mark data sets	18
4.8	Functions of the data set manager	19
4.8.1	Data set commands and possible error messages	21
4.8.2	Switching to data set 1 to 8	26
4.8.3	Overview of data set management commands	27
5	Commissioning	29
5.1	Safety instructions	29
5.2	Requirements to the executing personnel	29
5.3	Preconditions	30
5.4	Preparations	30
5.5	Survey	35
5.6	Executing commissioning	36
6	Description of the software modules	43
6.1	Allocation of the software modules in time slices	44
6.2	Configuration	45
6.2.1	Power unit	45
6.2.1.1	Example for a power unit overload monitoring	45
6.2.1.2	Setting the power rate $\cos \varphi$	48
6.2.2	Digital inputs	49
6.2.3	Digital outputs	52
6.2.4	Analog inputs	54
6.2.5	Analog outputs	57
6.2.5.1	Calculation basis	58
6.2.5.2	Sample 1 - Parameters with standard scaling	59
6.2.6	Direct access to digital in-/outputs via the PLC	59
6.2.6.1	Overview	59
6.2.6.2	Configuration	60
6.2.6.3	Addresses of I/O mapping	61
6.2.6.4	Usable I/O modules	61
6.2.6.5	Structure of I/O mappings for DIO-01 and FIO-01 (4-bit digital in, 4-bit digital out)	61



Table of contents

6.2.7	BACI	63
6.2.7.1	Introduction	63
6.2.7.2	System overview	63
6.2.7.3	BACI services	64
6.2.7.4	Configuration of the BACI via controller parameter	64
6.2.7.5	Definition of time of cyclic transfer	66
6.2.7.6	Definition of time cyclic trigger signal generation	67
6.2.7.7	Sequence cyclic communication:	67
6.2.7.8	Error monitoring	68
6.2.8	Application	69
6.3	Management	70
6.3.1	Drive management	70
6.3.2	Data set management	78
6.3.3	PSI-management	78
6.4	Setpoint generators	79
6.4.1	Ramp function generator	79
6.4.2	Setpoint generator	79
6.4.2.1	Fix setpoint	79
6.4.2.2	Time controlled setpoint	80
6.4.2.3	Setpoint depending on mains voltage	81
6.5	Diagnosis	82
6.5.1	Oscilloscope function	82
7	Parameters	85
7.1	Structure of controller parameter range	85
7.1.1	Range of numbers	85
7.1.2	Field bus addressability	86
7.1.3	Data type	87
7.1.4	Attributes	88
7.1.5	Reserved bits	88
7.2	Structure of the parameter description	89
7.3	Parameter description	91
	Appendix A - List of Parameters	197
	Table of figures	207
	Index	209
	Revision survey	211

1

INTRODUCTION

In this manual information is to be found referring to the parameters for the devices b maXX[®] 4100, for

WinBASS II from version 1.09
ProDrive
Controller- firmware from version 03.03 to 03.09

With the parameters you will affect the behavior of the controller.

The controller affects the behavior of the power unit and of the motor which is connected to it.

A survey of the control structures is to be found in [▶Control Structures◀](#) from page 9.

After an adaptation of the parameter values has been done to your application, you must store these. References to this are to be found in [▶Data Set Management◀](#) from page 13.

A procedure for the commissioning is to be found in [▶Commissioning◀](#) from page 29.

Operating principle of the single software modules and its parameters are described in chapter [▶Description of the software modules◀](#) from page 43.

A comprehensive description of the parameters sorted by parameter numbers you will find in chapter [▶Parameters◀](#) from page 85.

A brief survey of all the parameters is shown in [▶List of Parameters◀](#) from page 197.

1.1 Copyright and trade mark

Hiperface[®] is a registered trade mark of SICK/Stegmann

b maXX[®] is a registered trade mark of Baumüller Nürnberg GmbH

FUNDAMENTAL SAFETY INSTRUCTIONS

In this chapter we describe the possible dangers which may occur when you parameterize a Baumüller **b maXX[®] BM4100** controller part and we explain the meaning of the information sign.

2.1 Safety notes and instructions



WARNING!

Risk of injury from mechanical and electrical cause!

The modification of parameters affects the action of the Baumüller unit and consequently the action of the installation and its components. If you change the adjustments of the parameters, you may cause dangerous actions to the construction and/or of its components.

Therefore:

- After each modification of the parameter settings, execute a commissioning with consideration to all safety instructions and safety regulations.

2.2 Information signs




NOTE!

....highlights useful tips and recommendations, as well as information for efficient and problem-free use.

3

CONTROL STRUCTURES

In this chapter we describe the structure of the **b maXX[®] BM4100** controller. The model of the control system we describe by using graphics.



4100_0001_rev01_int.cdr

Figure 1: Overview




Figure 2: Current controller




Figure 3: U_{DC} link controller

4

DATA SET MANAGEMENT

In this chapter we describe the controller's data set management. You will be informed about how to create and change data sets without using WinBASS II. Furthermore the operating principle of the **PSI** (**p**arameter **s**torage interface) is described.

All parameters related to the software module data set management, you will find under [▶Data set management◀](#) on page 78.

4.1 General information

Parameters, which can be stored in the EEPROM of the controller, are stored either in 'central data' or in max. 4 switchable data sets.

Central data (CD) are those parameters, which are valid for the entire system and must not be switched over application-specific in the online mode (e. g. encoder-, motor-, system settings), while data set parameters can be switched over in the online mode (operation enabled) (e. g. recipe change a. s. o.).

On the front side of the controller is a connector (X2) for an external data storage, the **PSI** (Parameter Storage Interface).



NOTE!

The PSI must only be plugged or unplugged if the controller is in a no-voltage condition!

Due to the activation of the function 'PSI load automatically' \triangleright P0326 \triangleleft , after switching on the data sets are loaded from the PSI instead of the internal EEPROM of the controller. By a further setting 'store PSI automatically' \triangleright P0326 \triangleleft the data which was loaded from the PSI are automatically stored into the EEPROM of the controller. The settings in parameter \triangleright P0326 \triangleleft must be stored on the PSI, as they are read out from the PSI after switch-on. With the help of the PSI several machines are able to be parameterized without WinBASS II/ProDrive via this mechanism.




Figure 4: Data set management controller - PSI

4.2 Command interface

The data set management can be accessed via WinBASS II/ProDrive or via the field bus.

The following actions are permitted:

- Creating and deleting of data sets
- Initialization of data sets
- Switching between (valid) data sets
- Selection of the boot data record
- Copying of data sets
- Saving data sets to controller-internal EEPROM or PSI
- Loading data sets from controller-internal EEPROM or PSI

A command is activated either by WinBASS II/ProDrive or by writing a command code into parameter [▶P0310◀](#) data set management command. Additional auxiliary parameters complete the command interface.

When operating the system by use of WinBASS II/ProDrive, no data set command codes or data set auxiliary parameters must be observed, as the user interface does this automatically.

The parameter [▶P0311◀](#) Data set management status shows the immediate operational state of the command interface and also under certain circumstances an error message of the last command.

The write counter [▶P0317◀](#) EEPROM Write Count shows the number of EEPROM write cycles. Each command, which comprises an EEPROM memory access, forces the controller to increment this counter.

The write counter [▶P0318◀](#) PSI Write Count shows the number of EEPROM write cycles on the PSI. Each command, which comprises an EEPROM memory access, forces the controller to increment this counter.

4.3 Parameter organization within the data sets

Within the controller there are eight separate memory partitions for parameters marked by the 'data set' attribute (DS1 to DS8).

The numbers of these parameters start from P1000. The parameter with the number P1000 also exists in data set 1, in data set 2, in data set 3... and in data set 8.

Additionally there is a 'window', which represents the currently active data set (DS 0). One of these eight data sets are always switched active. By writing to the parameter [▶P0312◀](#) Active data set number, data set 1, 2, 3, 4, 5, 6, 7 or 8 can be connected active; that means that you are able to switch between the data sets. Doing so, the window is shifted from DS 0 to the memory area of the activated data set.

Example:

Data set 3 is activated.

The "window" of the active data set addresses data set 3.




Figure 5: Active data set

Basically, by use of external option modules or field buses you can only access the data of the **active data set** (DS 0).

4.4 State of delivery

In the appliance's state of delivery only data set No. 1 is valid. The other data sets DS2 to DS8 are deleted. Boot data set and active data set (DS 0) are data set 1. All parameters have their standard values. Switching over to another data set is not possible.

After parameterization of the controller and homing or notch position search the parameters should be stored in the controller-internal EEPROM. If an error occurs, when storing into the EEPROM (e. g. by switching off the controller during a programming procedure), the controller writes the standard values (factory setting) into the parameters after restarting.

4.5 Start-up action

- Without PSI
after b maXX[®] restart all parameters of the central data as well as all parameters of the created data sets are loaded from the controller-internal EEPROM into the user memory. The controller activates the data set, which is stored in parameter [▶P0327◀](#) Boot data set within the EEPROM. Invalid data sets are ignored.
- PSI are plugged and programmed
If in the PSI the function 'load PSI automatically' [▶P0326◀](#) bit 0 = 1 is set, the data sets are loaded from the PSI instead from the controller-internal EEPROM into the RAM after switching on.
Due to further setting 'store PSI automatically' [▶P0326◀](#) bit 1 = 1, the data which was loaded from the PSI are automatically stored into the controller-internal EEPROM and the previous parameterization is reset.
For the control of the switch-on behavior the mode bits of parameter [▶P0326◀](#) as they are stored in the PSI and not the bits of this parameter, which were set in the controller, because the parameter [▶P0326◀](#) is read out of the PSI immediately after switching on.



NOTE!

The settings for the load behavior after switch-on of „load PSI automatically“ and „store PSI automatically“ (mode bits of parameter [▶P0326◀](#)) are stored in the PSI module. If these settings are changed, thereupon the PSI must be reprogrammed, in order to store these settings in the PSI module.

4.6 How to change, load, copy and store parameters

Changes of parameter values (e.g. by WinBASS II or via a field bus) only affect the user memory of the controller. If changes shall be kept also after the next restarting of the controller, the parameter must be explicitly stored in the EEPROM or the PSI. It is not possible to store a single parameter, but only a complete data set. If a single data set or all data sets are stored, the central data is also stored automatically.

By use of data set commands also parameter values of valid data sets can be loaded as single data sets or complete data sets from the EEPROM or PSI into the operating memory. If you load the complete set, an automatic data set switch-over can be performed, if the parameter value of [▶P0312◀](#) Active data set in the EEPROM or PSI differs from the current value in the RAM.

The copy function of data sets allows you to copy parameter values of a valid record set source into another record set target. If the record set target is not already created, the controller creates it automatically. If the record set target is valid, the source parameter values are overwritten.

By using the WinBASS II function 'Up-/Download' of the 'Data set management' menu you can store parameters also on PC data cartridges. You can also re-write data back to the controller.

4.7 How to mark data sets

b maXX[®] has two parameters for marking data sets:

parameters	Data type	Meaning
▶P1010◀ Data set ID	UINT	Here you can mark each data set (DS 1 to DS 8) with an unique number from 0 to 65535
▶P1010◀ Data set name	STRING	Free choice of name for data set

4.8 Functions of the data set manager

- Data set management Commands** The data set management has the following functions (adjustable in [▶P0310◀](#) Data set manager command):
- Reset data set command
 - Write all data into EEPROM
 - Read EEPROM completely
 - Reset EEPROM completely
 - Make settings of standard values (from ROM) for active data set
 - Make settings of standard values (from ROM) for entire data sets which have been created
 - Generate data set <n>
 - Reset data set <n>
 - Copy data set <x> to data set <y> (from RAM into RAM)
 - Load data set <x> from EEPROM into RAM data set <x>
 - Store data set <x> from EEPROM into RAM data set <x>
You can only store data sets which have been defined before using the 'create data set <n>' command.
 - Write all parameters of the valid data sets into the PSI
 - Read PSI completely
 - Reset PSI completely
- Boot data set** The boot data set is defined over [▶P0327◀](#).
- Status of data set management** In order to display the result, the status parameter [▶P0311◀](#) Data record management status:
- Writing error (false value, parameter write-protected, invalid parameter number)
 - Reading error
 - Command processing active
 - Error code
- Some commands used for data set management require additional parameters, which we have listed below:



NOTE!

In the parameter [▶P1101◀](#) communication source the BACI command interface must always be enabled. This way service data can be parameterized by use of option modules (such as CANopen, sercos, a. s. o.).

- [▶P0314◀](#) **Source data set**
According to [▶P0310◀](#) data set command refers to source data set to the EEPROM or PSI (e. g. at reading of data set) or to the RAM (e. g. at data set write into EEPROM/ PSI).
- [▶P0315◀](#) – **Data Set Target**
According to [▶P0310◀](#) the data set command the data set target refers to a data set in the EEPROM/PSI or in the RAM.
- [▶P0312◀](#) – **Active Data set**
The number of the active data set is displayed here. Writing on this parameters in on-line-mode (operation enabled) causes an immediate data set switching.
- [▶P0316◀](#) – **Error Parameter**
Displays number of the parameter, which has caused an error during memory access (read/write). If an error occurs during command processing, the command will not interrupt transferring, but will continue transferring with the next parameter. When multiple errors occur, only the last error will be displayed.
- [▶P0317◀](#) – **EEPROM Write Count**
Number of EEPROM write cycles. Each command, which comprises EEPROM memory access, forces the controller to increment this counter.
- [▶P0318◀](#) – **PSI Write Count**
Number of EEPROM write cycles to the PSI. Each command, which comprises PSI memory access, forces this counter to be incremented.
- [▶P1010◀](#) – **Record data set ID**
Unique ID-number of data set stored in EEPROM.
- [▶P1011◀](#) – **Record name**
Name of active data set (string) can be freely chosen by the user.

4.8.1 Data set commands and possible error messages

- **Reset data set command**

This command leads to a complete reset of all error bits or to the error status word of the data set manager.

- Possible error messages:
None

- **Create data set**

In the state of delivery each controller comes with only one active data set (data set 1). The user therefore cannot switch to other data sets. Only after the user has created another data set (2 to 8) using this command, the controller enables to switch to that data set. This message contributes to ensure, that the user cannot switch by mistake to a still unchanged data set. The user that way is forced to willingly enable a data set for switching.

This data set command creates a data set, which is selected by [▶P0315◀](#) record set target. The parameter values of this data set are set to default values and are stored in the EEPROM.

This command causes incrementation of the write count [▶P0317◀](#) EEPROM Write Count.

Possible error messages:

- Data set already exists
- Wrong data set number (other than 1 to 8)

- **Reset data set <n>**

This data set command deactivates a data set. The data set stated in [▶P0315◀](#) record set target may not be the current active data set. When a data set becomes deactivated, the controller can no longer switch to that data set. Absolutely no values - neither in the EEPROM, nor in the RAM of the controller are modified. Only the flag, which data sets are created, will be actualized in the EEPROM.

This command causes incrementation of the write count [▶P0317◀](#) EEPROM Write Count.

Possible error messages:

- Data set not yet activated
- Wrong data set number (other than 1 to 8)

- **Copy data set <x> to data set <y> (from RAM into RAM)**

This data set command copies parameters from data set x ([▶P0314◀](#) record set source) to parameters of data set y ([▶P0318◀](#) record set target). The copy procedure takes a few milliseconds - therefore this command is valid in offline-mode (drive stopped) only.

Only state record set sources which are already created. If you prompt a record set target, it will be created automatically. That command will cause the copied data (record set target) to be copied into the EEPROM.

This command causes incrementation of the write count [▶P0317◀](#) EEPROM Write Count.

Central data is also stored to EEPROM.

Possible error messages:

- Data set not yet activated
- False data set source number
- Wrong data set target number
- Drive not stopped

- **Load data set <x> from EEPROM**

This data set command loads all parameters of data set x ([▶P0314◀](#) record set source) from the EEPROM into the controller's operating memory. The target data corresponds to the source data set. The data set must be valid. In online-mode (operation enabled) the data set must not be the actual active data set. During copying procedures switching of data sets is invalid.

Possible error messages:

- Data set not yet activated
- False data set source number
- Drive not stopped
- Value less than the minimum value
- Value greater than the maximum value
- Read-only parameter
- Parameter cannot be modified because of operating status
- Incorrect parameter value
- Checksum error during test

- **Store data set <x> into EEPROM**

This data set command stores all parameters of data set x (>P0314< record set source) from RAM into EEPROM. The data set must be valid. In online-mode (operation enabled) the data set can also be the actual active data set. During copying procedures into EEPROM data set switching is valid.

This command causes incrementation of the write count >P0317< EEPROM Write Count.

Central data is also stored to EEPROM.

If the EEPROM is reset, the controller stores the data sets, which were created into the EEPROM.

Possible error messages:

- Data set not yet activated
- False data set source number
- No or invalid EEPROM header
- Invalid section in EEPROM
- Invalid data in EEPROM
- EEPROM write error
- EEPROM too small
- unidentified error

- **Read EEPROM completely**

This data set command reads all parameters from EEPROM into controller RAM. Only valid controller data sets are read. The numerically assignment of the data sets in EEPROM and RAM are kept.

During copying procedures switching of data sets is invalid.

Possible error messages:

- Drive not stopped
- Value less than the minimum value
- Value greater than the maximum value
- Read-only parameter
- Parameter cannot be modified because of operating status
- Incorrect parameter value
- Checksum error during test

- **Write all parameters of the valid data sets into EEPROM**

This data set command stores all parameters of the valid data sets from RAM into EEPROM. In online-mode (operation enabled) one of the data sets can also be the actual active data set. During copying procedure into EEPROM data set switching is valid.

This command causes incrementation of the write count [▶P0317◀](#) EEPROM Write Count.

Possible error messages:

- No or invalid EEPROM header
- Invalid section in EEPROM
- Invalid data in EEPROM
- EEPROM write error
- EEPROM too small
- Unidentified error

- **Reset EEPROM completely**

This data set command resets the header entry in EEPROM only. Thus all data within EEPROM expire their validity.

This command causes incrementation of the write count [▶P0317◀](#) EEPROM Write Count.

Possible error messages:

- EEPROM write error
- Unidentified error

- **Set standard values for active data/generated record data**

This data set command writes the default values (factory-set) from the ROM into the parameters of the active data set/generated record data. Possible in offline-mode (with drive stopped) only.

Possible error messages:

- Drive not stopped

- **Write all parameters of the valid data sets into the PSI**

This data set command stores all parameters of the valid data sets from RAM into PSI. In online-mode (operation enabled) one of the data sets can also be the actual active data set. During copying procedure into PSI a data set switching is valid.

This command causes incrementation of the write count [▶P0318◀](#) PSI Write Count.

Possible error messages:

- PSI not plugged
- Unidentified error

- **Read PSI completely**

This data set command reads all parameters from PSSI into the controller RAM. The numerical assignment of the data sets in PSSI and RAM remain.

During copying procedures switching of data sets is invalid.

After reading the PSSI the controller takes over the data set configuring from the PSSI into the working storage (RAM). Due to this, the controller resets the data sets, which were created in the controller, but were not stored in the PSSI. Accordingly the controller creates new data sets in the RAM, which were read from the PSSI and which were not created in the controller yet. In order to receive this new configuration after the next switch-off, the data set command „Write all parameters of the valid data sets into EEPROM“ must be executed.

Possible error messages:

- PSI not plugged
- PSSI reset
- Drive not stopped
- Value less than the minimum value
- Value greater than the maximum value
- Read-only parameter
- Parameter cannot be modified because of operating status
- Incorrect parameter value
- Checksum error during test

- **Reset PSSI completely**

This record set command resets PSSI. Thus all data within EEPROM expire their validity.

This command causes incrementation of the write count [▶P0318◀](#) PSSI Write Count.

Possible error messages:

- PSSI not plugged
- Writing error on PSSI

4.8.2 Switching to data set 1 to 8

Data sets can be switched in online-mode (operation enabled), that means during active controlling.

Because of the mechanical inertia of the system to be controlled and the high controller sample rate you can assume a mechanical bumpless transfer.



NOTE!

When switching data sets you cannot regard inconsistent setpoints and monitoring values. At switch-over it is not to be excluded, that, e. g. a monitoring value of the new data set is smaller than the associated current actual value of the data set being active before that. In this case a monitoring function may respond, which, for example initiates an pulse inhibit.

The activation doesn't take place via data set command but only by writing of the according value in [▶P0312◀](#) Active data set number. In this parameter the user can read the number of the actual selected data set.

During input the following conditions are checked before data switching in online-mode (operation enabled):

- 1 Is the value ≤ 8 and ≥ 1 ?
- 2 Is the value valid, that means does the specified data set already exist?

Only if the above mentioned conditions have been fulfilled, the data set switching in the online mode (operation enabled) can be performed.

Possible error messages:

- Data set not yet activated
- False data set number
- At the moment a data transfer from EEPROM or PSI to RAM or vice versa is active. Data set switching invalid.
- Drive is not stopped (this error is only displayed in certain cases e. g. at encoder switching).

4.8.3 Overview of data set management commands

▷P0310◁ Data set management Command	Value	▷P0314◁ Source data set	▷P0315◁ Target data set	▷P0317◁ EEPROM write count	▷P0318◁ Number of write counts on PSI	Central data
Reset data set command	0					
Write all parameters of the valid data sets into EEPROM	1			Counter is incremented		Yes
Read EEPROM completely	2					
Reset EEPROM completely	3			Counter is incremented		Yes
Set standard values for active data set	4					
Set standard values for all generated data sets	5					Yes
Generate data set <n>	6		Data set to be created	Counter is incremented		
Reset data set <n>	7		Data set to be reset	Counter is incremented		
Copy data set <x> to data set <y>	8	Source data set	Target data set	Counter is incremented		Yes
Load data set <x> from EEPROM	9	Data set in EEPROM				
Store data set <x> into EEPROM	10	Data set in RAM = EEPROM		Counter is incremented		Yes
Write all parameters of the valid data sets into the PSI	12				Counter is incremented	Yes
Read PSI completely	13					
Reset PSI completely	14				Counter is incremented	Yes

COMMISSIONING

In this chapter we describe an exemplary commissioning of a b maXX mains inverter. Carry out the commissioning, to make sure that the delivered devices are in an accordingly condition. This commissioning is **not** for the complete installation of the device for your application.

5.1 Safety instructions

Please refer to the relevant information in chapter [►Fundamental Safety Instructions◄](#) from page 7.



DANGER!

Risk of injury from electricity!

The control cabinet is equipped with power cables which carry dangerous voltages.

Therefore:

- Put all relevant cables off-circuit and protect them against accidental reactivation.
- Refer to the relevant safety rules when commissioning power electronics.

5.2 Requirements to the executing personnel

The personnel, who is assigned for commissioning, must have enough knowledge about:

- Safety technology
- PC-operation (windows), especially in the program WinBASS II / ProDrive
- Connection and operating method of the device b maXX[®] 4100.

5.3 Preconditions

The commissioning is an exemplary checking of the functionality of the device. When commissioning, make sure that the device is ready for operation.

5.4 Preparations

Precondition for the commissioning is that mounting and installation are correctly executed.

- 1 Assure, that mounting is correctly executed and especially that all safety instruction were referred to (see mounting in manual of b maXX[®] 4100).



NOTE!

Figures referring to the next working steps are to be found in the manual of the basic unit b maXX 4100.

- 2 Assure, that the installation is correctly executed, and that especially all safety instructions were referred to (see installation in the manual of the basic unit b maXX 4100).
- 3 WinBASS II/ProDrive must be installed onto the PC/laptop.



NOTE!

The controller firmware versions which are supported by WinBASS II/ProDrive are to be found in the WinBASS II/ProDrive online help in the menu „user indications/supported b maXX[®] devices“, or on the WinBASS II/ProDrive CD in the readme file under „user indications/b maXX[®] devices“.

- 4 Assure, that you have all necessary data.
- 5 Make sure, that switching elements for pulse enable and reset error memory are connected to b maXX 4100 (e. g. in a switchboard) and function correctly. Assure, that the switches are in inoperative position (inactive).
- 6 Assure, that all safety devices are connected line-side and are ready-to-operate.
- 7 Assure, that a function module BM4F-UME-01 is plugged into slot A and connect it (see installation in the manual of the basic unit b maXX 4100).
- 8 Assure, that a function module BM4F-SRM-01 or SRM-02 is plugged into slot B and is connected (see installation in the manual of the basic unit b maXX 4100).
- 9 Assure, that a function module BM4-F-SEA-01 or SEA-02 is plugged into slot C and is connected (see installation in the manual of the basic unit b maXX 4100).
- 10 Assure, that a function module BM4F-DIO-01 or BM4F-DIO-01 is plugged into slot D and is connected (see installation in the manual of the basic unit b maXX[®] 4100).
- 11 Assure, that PC/laptop is connected with a serial cable (RS232/9-pin sub-d connector) to the plug connection X1 of the controller - start WinBass II.
- 12 After starting the WinBASS II/ProDrive program window appears.




Figure 6: Start screen PorDrive

Select „Select device...“ on the start page. The window „Select device“ is opened (see >Figure 7< on page 32). Usually you can proceed as follows.

13 Select the serial interface where the PC is connected with the b maXX[®] 4100 device.

5.4 Preparations

14 Then select the type of device.

Select „b maXX[®] 4100 FW03“ for controller firmware version 03.xx. Thereby it doesn't matter, if there is a PLC in the device or not (the firmware version is to be recognized at the device from the type key on the type plate after the third hyphen e. g. BM4XXX-XXX-XXXXX-**XX**).

15 Then press „test connection“. If an online connection with the b maXX[®] device is generated, then an according session is suggested, which only has to be confirmed.

16 With a click on „continue“ the graphically user interface is started.



NOTE!

In case there is a PLC in the b maXX[®] device a communication with WinBASS II/ProDrive to the controller only can be established, if a project is existing in the PLC!



Figure 7: ProDrive - start

Further notes and explanations are to be found in the online help of the program. This online help is initiated with the following starting window with „help“.

17 Wait until the following display mask appears and find the „Navigation“ on the right site.

Startpage | Parameter list | Scaling | Data set management | User defined groups |

ProDrive - Service - b maXX 4100

Database

Version:

Information

Controller type	4100
Controller firmware type	0
Controller firmware ID	1384
Controller Firmware version	3.09
Parameter table version	169
Controller FPGA version	0x0000
Controller bootloader version	0.00

Configuration

Configuration ID:

Drive name:

Password

Password for service mode:

Time informations

System time:

Time since last boot: 0 days 0:00

Power time: 0 days 0:00

Functionmoduls

	Module name	Module type	Hardware version	Wire break supervi:	RS-485	Temp-acquis.
Slot A	not used			-	-	-
Slot B	not used			-	-	-
Slot C	not used			-	-	-
Slot D	not used			-	-	-
Slot E	not used			-	-	-

Figure 8: ProDrive - startpage b maXX 4100

18 Click in the project tree/navigation on „power unit“.




Figure 9: ProDrive: Navigation




NOTE!

If the window „power unit“, down right, shows „wrong version“ you have a software version, which is not compatible with the controller. You have to close WinBASS II/ProDrive and start it anew. In the starting window you must then select „test connection“ or you must select the suitable WinBASS II/ProDrive session. In case there is no session for the present controller firmware version you need an update for the WinBASS II/ProDrive program.

5.5 Survey

The following survey shows commissioning schematically. The individual steps of the commissioning you will find described in detail in [►Executing commissioning◄](#) from page 36.



4100_0007_rev01_int.cdr

Figure 10: Starting sequence

5.6 Executing commissioning

Start with the commissioning, after you have completed the preparations.

- 1 Effectuate the power supply to the bmaXX® (supply voltage + control voltage).
Hereupon the device starts up and shows its operational readiness by flashing of the orange-colored LED H-2 (Power ON).
 - LED H-2 must light up orange, this means Power ON, the device is ready-to-operate.
 - LED H-2 may **not** light up green: The green lit LED H-2 means „operation enabled“! DC-link voltage is controlled! Immediately cancel this with the switch element pulse enable or quickstop enable!
 - LED H-3; the red luminous LED means current limit reached. Reduce the load. Continue the parameterization.
 - LED H-4; red lit LED means a state of error. Remove the error and with the help of the operating program WinBASS II or with the error reset switch connect the X3-4. Continue the parameterization.
- 2 **Now** plug on the (RS232-)cable connector from the PC/laptop to the controller at the bmaXX®.
The communication runs through the connection cable between the processor and the bmaXX®.
- 3 Start WinBASS II/ProDrive (as far as it isn't running yet).



NOTE!

In case you receive an error message referring to a plug-in module, then please first check if the plug-in module is accurately cabled and if necessary, is supplied with voltage.

Warnings/reset errors

- 4 Then click on „device management“




Figure 11: ProDrive: Navigation

- 5 If „by WinBASS II/ProDrive“ is selected „reset“ existing warnings/errors in the window „Drive manager“ (possibly the key „Quit errors“ has to be activated multiple times).





Figure 12: ProDrive: Device manager

5.6 Executing commissioning

6 Click on „power unit“.




Figure 13: ProDrive: Navigation

7 Enter into „maximum current of the drive“ the current, which is necessary for your application, at a maximum the limit current of the device (according to data sheet): 82.5 A, by which the power unit shall be operated.

The screenshot shows the 'Power unit' configuration page with the following data:

Type and data	
Serial number	0
Type code	BM4135 55 A DC 35 kW
Firmware version	0.00
Data configuration	0

Voltages	
Main voltage actual value	0,0 V
DC link voltage actual value	0,00 V
Main frequency actual value	50,0 Hz
Main power actual value	0,0 kW
Dead time	4,5 μs

Monitoring	
Warning limit mains power	230,0 V
PSU main overvoltage warning	520,0 V
PSU main undervoltage warning	30,0 kW
thermal time constant 1	0,00 s
thermal time constant 2	60,00 s

Current data	
Peak current	82,5 A
Nominal current	55,0 A

Limit values	
Max. device current	20,0 A
Ixt actual value	0,0 %

Heatsink temperature	
Shutdown temperature	87 °C
Warning temperature	75 °C
Actual temperature	0 °C

Internal device temperature	
Shutdown temperature	70 °C
Warning temperature	75 °C
Actual temperature	0 °C

Additional information: Status: Not operational; Fan control: Fan: off (switched on with mains on signal).

Figure 14: ProDrive: Power unit

8 Go back to the project tree/navigation.

9 Click on „Startpage“.

Slot	Module name	Module type	Hardware version	Wire break supervis	RS-485	Temp-acquis.
Slot A	Mains voltage monitoring	BM4-F-UME-01	Version A	-	-	-
Slot B	Monitoring signal of main contator	BM4-F-SRM-01	Version A	-	-	-
Slot C	Coil of main contactor	BM4-F-SEA-01	Version A	-	-	-
Slot D	Digital I/O 4 inputs, 4 outputs	BM4-F-DIO-01/11	Version B	-	-	-
Slot E	not used			-	-	-

Figure 15: ProDrive: Start page with the used modules

In the start page it can be determined, at which slot the necessary modules for the mains inverter are plugged into.

10 Check, if the modules, which were plugged in, have been recognized correctly.

**CAUTION!****Danger arising from errors in the hardware identification!**

The device in which the b maXX[®]4100 is installed, can be damaged or can work defective, if a module or more modules were not recognized or were recognized wrongly.

Therefore:

- Cancel commissioning, if at least one plug-in module was not or was recognized wrongly. Contact Baumüller Nürnberg GmbH.

- 11 Go back to the project tree/navigation.
- 12 Click in the data set management on the button „Save all“.




Figure 16: ProDrive 1.14: Data set management window

- 13 Wait until next to „data set status“ is shown: „o.k.“
Thus the data record is saved in the EEPROM.
 - 14 Disconnect the device from the mains- and the control voltage.
 - 15 Effectuate the power supply to the b maXX[®]
(supply voltage + control voltage).
- By switching on and off you can check, if your settings lead to warnings or errors.
- 16 Go back to the project tree/navigation.
 - 17 Double-click on: „Set value generators“.
 - 18 Click on: „Set value generator 1“ .




Figure 17: ProDrive: Ramp function generator

19 Enter the values into the following entry fields:

- (U_{zk} set value) input
- Enter the value dependent on the mains voltage (e.g. 640 V when U_{mains} = 400 V). Confirm with *enter*.

20 In case you have shut the window „drive manager dialogue“: click on the icon „Device management“.




Figure 18: ProDrive: Ramp function generator - icon bar

Additionally the window „Drive manager dialogue“ appears.




Figure 19: ProDrive: Drive manager

21 Select in the drive manager dialogue in the scrolling list the operation mode „U_{DC} control“.

22 Turn on the charging contactor.

23 Click on the drive manager dialogue on button „On“ to switch on the main contactor as soon as the pre-charge has been completed successfully.

24 Switch on pulse enable active, as soon as the pre-charge has been completed successfully.

25 Click on the drive manager dialogue menu on the button „Start“
Now U_{DC} should be regulated to U_{DC} set.




Figure 20: ProDrive: Drive manager

26 Switch on pulse enable inactive.

5.6 Executing commissioning

Data set storage

This data record we now want to save.

27 Click in the icon bar on the icon „Data set management“.




Figure 21: ProDrive!: Ramp function generator - icon bar

28 Click in the data set management on the button „Save all“.




Figure 22: WinBASS II: Data set management

29 Wait until next to „data set status“ is shown: „o.k.“

Thus the data record is saved in the EEPROM.

30 Separate over the accordant switching elements the device from the mains- and control voltage.

Thus the commissioning is successfully completed.

DESCRIPTION OF THE SOFTWARE MODULES

In the following we describe the working principles of software modules and its parameters. A comprehensive description of the parameters sorted by parameter numbers you will find in chapter [Parameters](#) from page 85.

A structure has been selected, which is similar to the WinBASS II Project tree/ProDrive Navigation.




Figure 23: WinBASS II: Project tree

6.1 Allocation of the software modules in time slices

Allocation of time slices	Software modules
every 125 μ s	Current controller U _{DC} controller
every 250 μ s	Mains inverter control
every 500 μ s	Ramp function generator Current controller control Uploading of digital inputs
every 1 ms	Digital outputs Mains inverter manager Evaluation of digital inputs (dispatched, e. g. according to system working load possibly allocated to several time slices)
every 2 ms	Warning manager
every 4 ms	Drive manager Status word 2 U _{DC} controller control
every 8 ms	Overload management
every 16 ms	Operation mode switch-over Setpoint generator LED control


6.2 Configuration

6.2.1 Power unit

Here you find parameters displayed regarding the power unit (power section). It is also possible to change the parameter values.

6.2.1.1 Example for a power unit overload monitoring

This monitoring protects the power unit against thermal overload. By use of a I^2t model the temperature is simulated and monitored.



4100_0072_rev01_int.cdr

Figure 24: Example for a motor overload monitoring

Current controller I_q actual value		▶P0333◀
Current controller I_d actual value		▶P0336◀
Apparent current actual value	$(I_{actual}) [A_{eff}]$	$\sqrt{P0333^2 + P0336^2}$
Power unit nominal current 8 kHz	$(I_{nominal}) [A_{eff}]$	▶P0012◀
Power unit maximum current 8 kHz	$(I_{max}) [A_{eff}]$	▶P0013◀
Power unit maximum current of the drive	$(I_{limit}) [A_{eff}]$	▶P1241◀
Power unit overload time	$(t_u) [s]$	▶P0015◀
Power unit heatsink temperature actual value	$(\vartheta_{actual}) [^{\circ}C]$	▶P0482◀
Power unit Ixt value	$(Ixt) [\%]$	▶P0485◀
Power unit overload factor max.	$(u_{max}) [\%]$	
Power unit overload factor presently	$(u) [\%]$	
Power unit thermal time constant	$(\tau_{LT}) [s]$	
Power unit release time	$(t_{off}) [s]$	Time up to limit on I_{nom}
Power unit Ixt offset	$(Ixt \text{ offset}) [\%]$	

$$u_{\max} = \frac{I_{\max}}{I_{\text{nom}}} \cdot 100 \quad [\%]$$

$$u = \frac{I_{\text{act}}}{I_{\text{nom}}} \cdot 100 \quad [\%]$$

$$\tau_{\text{power unit}} = -\frac{t_u}{\ln\left(\frac{u_{\max} - 100}{u_{\max}}\right)} \quad [\text{s}]$$

- for power unit temperature > 45 °C

$$\text{IxtOffset} = \frac{\vartheta_{\text{act}} - 45^{\circ}\text{C}}{85^{\circ}\text{C} - 45^{\circ}\text{C}} \cdot 100 \quad [\%]$$

- otherwise
Ixt offset = 0 %

- Release time

$$t_{\text{off}} = \tau_{\text{power unit}} \cdot \ln\left(\frac{u}{u - 100 + \text{IxtOffset}}\right)$$

Example:

$$I_{\text{nominal}} = 10 \text{ A}_{\text{eff}}$$

$$I_{\max} = 15 \text{ A}_{\text{eff}}$$

$$t_U = 1 \text{ [S]}$$

$$I_{\text{limit}} = 12 \text{ A}_{\text{eff}}$$


$$\vartheta_{\text{act}} = 35^{\circ}\text{C}$$

$$u_{\max} = \frac{15}{10} \cdot 100 = 150 \quad [\%]$$

$$u = \frac{12}{10} \cdot 100 = 120 \quad [\%]$$


$$\tau_{\text{power unit}} = -\frac{1}{\ln\left(\frac{150 - 100}{150}\right)} = 0,91 \quad [\text{s}]$$

$$t_{\text{off}} = 0,91 \cdot \ln\left(\frac{120}{120 - 100}\right) = 1,63 \quad [\text{s}]$$



4000_0389_rev01_int.cdr

4000_0390_rev01_int.cdr



The characteristic curve is assumed from a cold power unit ($I_{xt\ offset} = 0$;
 $\vartheta_{actual} < 45\text{ }^{\circ}\text{C}$)

6.2.1.2 Setting the power rate $\cos \varphi$

Parameter Power Supply Unit offset rho \triangleright P1350 \triangleleft sets the power factor within a range from -0.866 to +0.866.




Figure 25: Characteristic curve power factor

Example:

$\cos \varphi$ should be +0,95.

\triangleright P1350 \triangleleft = $\arccos(0,95) = 18,19^\circ$



NOTE!

The angle change of φ (\triangleright P1350 \triangleleft) should be not higher than 5° per second.

The function of the device can be disturbed if the angle φ (\triangleright P1350 \triangleleft) is changed to fast.

6.2.2 Digital inputs

Digital inputs can be used for external control of single or even of several bits in parameters. That way, for example, single bits in the parameter „Drive manager control word“ can be influenced enabling you to control the drive manager.



NOTE!

One of the function modules BM4-F-DIO-01 or BM4-F-DIO-02 must be built-in the device if the b maXX[®] 4100 is controlled via hardware signals (drive manager menu „only via pulse enable“ is selected). The digital input 1 is predefined in this case. The other digital inputs 2 to 4 are freely programmable.

For the digital inputs 4 parameter blocks are provided. That way a maximum of four inputs can be evaluated simultaneously. These enable you to write to all writable 16-bit-parameters.

Each parameter block consists of five parameters:

- Select digital input x
Channel selection
- Target number digital input x
Input of target parameter number
- Bit selection digital input x
Choice of the bits of the target parameter, which have got to be changed.
- Bit pattern at LOW digital input x
Bit pattern, written to target parameter when digital input LOW.
- Bit pattern at HIGH digital input x
Bit pattern, written to target parameter when digital input HIGH.

At the inputs only edges are evaluated.

Thus it is possible to influence a single parameter by use of several inputs.

Example: Two inputs influence the same parameter bit




Figure 26: Edge evaluation of digital inputs

Any of the four inputs are scanned every millisecond at intervals of approx. 20 μ s.

If 2 signals change their condition simultaneously, the signal with higher significance is accepted (digital input 1 has the lowest significance, digital input 4 has the highest).

Furthermore, for every of the 5 module slots there is a parameter, which reflects the status of the inputs of the module slots ([▶P0410◀](#) to [▶P0414◀](#)).

Thereby channel 1 corresponds to bit No. 0, channel 2 to bit No. 1 and so on. These 5 parameters are read-only.



NOTE!

A digital input is activated by writing to all parameters, which are associated to this input. The following sequence must be followed:

- 1 Select digital input x
- 2 Target number digital input x
- 3 Bit selection digital input x
- 4 Bit pattern at LOW digital input x
- 5 Bit pattern at HIGH digital input x

Deactivation of a digital input is done by writing the value "0" to parameter Target number digital input x.

Procedure when programming:

- 1 Select module slot with the digital inputs and select respective **input**.
- 2 Fill in **target number** of desired input.
⇒ still no effect on target parameter.
- 3 Enter bit selection of requested output
Only the bits, which have been set in the parameter **Bit selection**, also can be modified in the target parameter according to pattern in the parameters **Bit pattern at High** or **bit pattern at Low**. Accordingly such bits are kept the same in the target parameter, which equal 0 in **bit selection**.
- 4 **Bit pattern at Low** and **bit pattern at High** is determined
With a positive edge of the digital input the target parameter is changed as follows:
Target parameter = (target parameter AND NOT (**bit_selection**))
OR (**bit pattern at High** AND **bit_selection**)

At a negative edge of the digital input the target parameter is changed as follows:
Target parameter = (target parameter AND NOT(**bit_selection**))
OR (**bit pattern at Low** AND **bit_selection**)

- Example 1:

In slot D (module slot 4) you have plugged in a module for digital inputs.

By operating module input 3, the parameter ▶P0440◀ Set value generator mode shall be set to 0 (when switch is LOW) and set to 1 (when switch is HIGH).

i. e. according to signal status bit 0 to 15 are „ANDed“ bitwise with the LOW or HIGH pattern.

Parameter block 1 shall be used.

The following parameters then must be written:

Selection digital input 1	▶P1090◀	P0403 _{hex}
Target number digital input 1	▶P1091◀	440
Bit selection digital input 1	▶P1092◀	FFFF _{hex}
Bit pattern at LOW digital input 1	▶P1093◀	0000 _{hex}
Bit pattern at HIGH digital input 1	▶P1094◀	0001 _{hex}

- Example 2

In slot D (module slot 4) you have plugged in a module for digital inputs.

By programming an additional input (module slot 4) now value 2 and 3 in parameter **▷P0440◁** set value generator mode shall be adjusted.

Parameter block 1 and 2 shall be used.

So the following programming is necessary:

Selection digital input 1	▷P1090◁	0403 _{hex}
Target number digital input 1	▷P1091◁	440
Bit selection digital input 1	▷P1092◁	FFFD _{hex}
Bit pattern at LOW digital input 1	▷P1093◁	0000 _{hex}
Bit pattern at HIGH digital input 1	▷P1094◁	0001 _{hex}
Selection digital input 2	▷P1095◁	0404 _{hex}
Target number digital input 2	▷P1096◁	440
Bit selection digital input 2	▷P1097◁	FFFE _{hex}
Bit pattern at LOW digital input 2	▷P1098◁	0000 _{hex}
Bit pattern at HIGH digital input 2	▷P1099◁	0002 _{hex}

→ The digital input 1 influences now bit 0 and bits 2 to 15 ;
the digital input 2 influences the bits 1 to 15.

Bit No.	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Example for initial value ▷P0440◁	1	1	1	1	0	0	0	0	1	1	1	1	0	1	0	1
Input 1 → HIGH	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
Input 2 → HIGH	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1
Input 1 → LOW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
Input 2 → LOW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

- Example 3

In slot D (module slot 4) you have plugged in a module for digital inputs.

One input (module input 5) shall influence bit 4 and bit 11 of the parameter **▷P0300◁** control word.

Thereby parameter block 3 should be used.

So the following programming is necessary:

Selection digital input 3	▷P1100◁	0405 _{hex}
Target number digital input 3	▷P1101◁	300
Bit selection digital input 3	▷P1102◁	0810 _{hex}
Bit pattern at LOW digital input 3	▷P1103◁	0800 _{hex}
Bit pattern at HIGH digital input 3	▷P1104◁	0010 _{hex}

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Initial value ▷P0300◁	0	0	0	0	0	0	0	0	0	0	0	0	1	1	1	1
Input 2 → HIGH	0	0	0	0	0	0	0	0	0	0	0	1	1	1	1	1
Input 2 → LOW	0	0	0	0	1	0	0	0	0	0	0	0	1	1	1	1

6.2.3 Digital outputs

Digital outputs can be used to forward certain states to the higher-level control or for display purposes. That way, e. g. certain bits or also bit combinations of the parameter „status word of the drive manager“ can be signaled towards the outside.

For the digital outputs 4 parameter blocks are provided.

That way a maximum of 4 outputs can be evaluated simultaneously. Not assigned outputs are set „LOW“.



NOTE!

One of the function modules BM4-F-DIO-01 or BM4-F-DIO-02 must be built-in in module slot D, if the device is controlled only via hardware signals (device management „only via pulse enable“ is selected). In this case all 4 digital outputs are pre-defined.

All digital outputs of the function modules BM4-F-DIO-01 or BM4-F-DIO-02 are freely programmable, if the device is controlled via operation program / BACI (device management „via WinBASS II/ProDrive“ and/or „via BACI“).

Each parameter block consists of four parameters:

- Select digital output x
Channel selection
- Source number digital output x
Number of parameter, which is to be displayed (only 2 byte parameter permitted).
- Bit selection digital output x
Selection of the bits of the source parameters, which have to be identical.
- Bit pattern digital output x
If this pattern and the selected bit pattern of the source parameter are identical, the selected output will be switched to HIGH.

The 4 outputs are scanned every millisecond.

Furthermore, for every of the module slots there is a parameter, which reflects the status of the outputs of the module slots (>P0418< to >P0419<). Thereby channel 1 corresponds to bit 0, channel 2 to bit 1 and so on. These parameters are read-only.



NOTE!

You can activate a digital output by writing to all parameters, which are associated with this output. The following sequence must be followed:

- 1 Select digital output x
- 2 Source number digital output x
- 3 Bit selection digital output x
- 4 Bit pattern digital output x

Deactivation of a digital output is done by writing the value "0" to parameter source number digital output x or by writing the value "0" to parameter bit selection digital output x.

Procedure when programming:

- 1 Select module slot with the digital outputs and select respective **output**.
- 2 Fill in **source number** of desired output.
⇒ still no effect on source parameter.
- 3 Enter **bit selection** of requested output:
⇒ All selected bits of the source parameter are set to 1.
- 4 Enter **bit pattern** of the same output.
The selected bits of the source parameter are compared with the **bit pattern**. If they are identical, the output is set to HIGH.
⇒ Affects target parameter.

- Example:

In slot D (module slot 4) you have plugged in a module for digital outputs.

The digital output 2 of the module shall turn HIGH, if in parameter `>P0200<` error system 1 bit 0 = 0 and bit 2 = 1.

In order to do so, parameter block 3 shall be used:

The following parameters then must be written:

Selection digital output 3	<code>>P1118<</code>	P0402 _{hex}
Source number digital output 3	<code>>P1119<</code>	200
Bit selection digital output 3 bit 0, bit 2	<code>>P1120<</code>	0005 _{hex}
Bit pattern digital output 3 bit 0 = 0 and bit 2 = 1	<code>>P1121<</code>	0004 _{hex}

6.2.4 Analog inputs

If you intend to use analog inputs, you need at least one of the function modules BM4-F-AIO-01, BM4-F-AIO-02 or BM4-F-AIO-03.

Analog inputs can be used read-in external voltages. That way, e. g. via the parameter „Ramp function generator input value“, the set speed can be specified with the help of an analog input voltage.

For the analog inputs 2 parameter blocks are provided. That way a maximum of four inputs can be evaluated simultaneously.

They enable writing to all 16-bit- and 32-bit-parameters that are not read-only. With the 32-bit-parameters only the high-word of parameter is written to. The low-word remains unchanged. Furthermore for 32-bit-parameters the high-word of the maximum value is valid.

Each parameter block consists of seven parameters:

- **Select analog input x:**
Channel selection
- **Smoothing time analog input x:**
Input of time constants of smoothing capacitor in ms.
- **Scaling factor analog input x:**
Input of the scaling factor.
- **Target number analog input x:**
Number of the parameter which has got to be changed.
- **Offset analog input x:**
Offset input.
- **Threshold value analog input x:**
Sensitivity of the input.
- **Value analog input x:**
Current input value

The sampling of the specified analog input operates every 125 µs.

The input value is selected by use of **select analog input**. This value is smoothed by use of **smoothing time** and is converted with the **scaling factor**. Then the **offset** is added. Is this result less than the **threshold value**, it is set to 0.

The result is multiplied with the maximum value of the target parameter and written to the target parameter.

**NOTE!**

A connection follows, as soon as the **target number** has been set.

In order to deactivate an input, the **target number** must be set to 0. The latest output value is kept within the target parameter.

Procedure when programming:

- 1 Select module slot with the analog inputs and select respective **input**.
- 2 Set the required smoothing time.
- 3 Select **scaling factor**.
- 4 Set **offset** according to existing offset.
- 5 Eventually set **threshold** according to existing threshold.
- 6 Set **target number**.

With reprogramming to another target number the target number first must be set to zero and then has to be programmed as recommended above in order to avoid unwanted effects.

Calculation basis:

Bigger absolute value of the level limits of the target parameter: Maximum value

Analog input voltage:

$$U_{in} \{ -10 \dots +10 \text{ V} \};$$

$$U_{inmax} = +10 \text{ V};$$

Calculation formula:

- for unipolar parameter:

$$\text{VALUE ANALOG INPUT [\%]} = \frac{U_{in}[\text{V}] + 10 \text{ V}}{2 \cdot U_{inmax}[\text{V}]} * \text{scaling} * 100 \% + \text{offset}$$

Is VALUE ANALOG INPUT > 100 %,
then VALUE ANALOG INPUT = 100 % is set.

If |VALUE ANALOG INPUT [%]| is < threshold value [%],
then VALUE ANALOG INPUT = 0 % is set.

- for bipolar parameter:

$$\text{VALUE ANALOG INPUT [\%]} = \frac{U_{\text{in}}[\text{V}]}{U_{\text{inmax}}[\text{V}]} * \text{scaling} * 100 \% + \text{offset}$$

If VALUE ANALOG INPUT > 100 %,
then VALUE ANALOG INPUT = 100 % is set.

If VALUE ANALOG INPUT is < -100 %,
then VALUE ANALOG INPUT = -100 % is set.

If |VALUE ANALOG INPUT [%]| is < threshold value [%],
then VALUE ANALOG INPUT = 0 % is set.

To the target parameter the following value is written:

$$\text{Target parameter} = \frac{\text{VALUE ANALOG INPUT [\%]}}{100 \%} \cdot \text{maximum value}$$

If you have 32-bit-parameters, the maximum value of the high-word equals the true maximum value. To the target parameter only the high-word is written. The low-word remains unchanged.

- Examples:

Input voltage ↔

VALUE ANALOG INPUT [%] * maximum value of target parameter

→ target parameter value

Scaling = 1; offset = 0%; threshold value = 0%;

Unipolar target parameter:

10 V ↔ 100 % * maximum value
5 V ↔ 75 % * maximum value
0 V ↔ 100 % * maximum value
-5 V ↔ 25 % * maximum value
-10 V ↔ 0 % * maximum value

Bipolar target parameter:

10 V ↔ 100 % * maximum value
5 V ↔ 50 % * maximum value
0 V ↔ 100 % * maximum value
-5 V ↔ -50 % * maximum value
-10 V ↔ -100 % * maximum value

Scaling = 1; offset = 0%; threshold value = 10.1%;

Unipolar target parameter:

10 V ↔ 100 % * maximum value
5 V ↔ 75 % * maximum value
0 V ↔ 50 % * maximum value
-5 ↔ 0 % * maximum value
-9 V ↔ 0 % * maximum value (threshold!)
-10 V ↔ 0 % * maximum value

Bipolar target parameter:

10 V ↔ 100 % * maximum value
5 V ↔ 50 % * maximum value
1 V ↔ 0 % * maximum value (threshold!)
-1 V ↔ 0 % * maximum value (threshold!)
-5 V ↔ -50 % * maximum value
-10 V ↔ -100 % * maximum value

Scaling = 2; offset = -100%; threshold value = 0%

Unipolar target parameter:


10 V ↔ 100 % * maximum value
 5 V ↔ 50 % * maximum value
 0 V ↔ 0 % * maximum value
 -5 V ↔ 0 % * maximum value (limit!)
 -10 V ↔ 0 % * maximum value (limit!)

Bipolar target parameter:

10 V ↔ 100 % * maximum value
 5 V ↔ 0 % * maximum value
 0 V ↔ -100 % * maximum value
 -5 V ↔ -100 % * maximum value (limit!)
 -10 V ↔ -100 % * maximum value (limit!)

Example characteristic curves:

Unipolar target parameter
 Offset = 0 %; Scaling = 1



Bipolar target parameter
 Offset = 0 %; Scaling = 1




Figure 27: Example characteristics analog input

4000_0209_rev01_int.cdr

6.2.5 Analog outputs

If you intend to use analog inputs, you must have one of the AIO-01, AIO-02 or AIO-03 function modules.

With the analog outputs any device parameters, as e. g. current actual value or following error, but also the status parameters are issued. 16-bit as well as 32-bit parameters can be issued.

For the analog outputs two parameter blocks are provided. That way a maximum of 2 outputs can be evaluated simultaneously. The outputs are scanned every 125 μ s.

Four parameters belong to every parameter block:

- Select fast analog output [▷P1150◀](#) and [▷P1154◀](#)
Select of the output channel and of the function module slots.
- Source parameter number analog output [▷P1151◀](#) and [▷P1155◀](#)
Parameter number for the source parameter, which shall be generated at the output. The calculation of the output value acts automatically in accordance with the kind of the parameter: 16 or 32 bit, signed or unsigned.
- Scaling factor analog output [▷P1153◀](#) and [▷P1157◀](#)
Scaling factor for the calculation of the output value.
- Offset analog output [▷P1152◀](#) and [▷P1156◀](#)
With the offset the output value is able to be shifted by a possible offset error of the analog output.

6.2.5.1 Calculation basis

For the calculation of the analog outputs it is assumed that there is a standard scaling in the drive. The most actual value parameters as e. g. speed, speed torque and current, are internally scaled to a value 4000_{hex} (at 16 bit parameters) or 40000000_{hex} (at 32 bit parameters). That means that a parameter value of 4000_{hex} (40000000_{hex} is according to 100 %).

If the parameter, which is to be output, is shown in the standard scaling, the simplified conversion formulae can be used.

Signed parameters:

$$U_{\text{off}} = \text{parameter value [\%]} \cdot \text{scaling [WinBASS]} \cdot 10 \text{ V} + \text{offset [V]}$$

Unsigned parameters:

$$U_{\text{off}} = \text{parameter value [\%]} \cdot \text{scaling [WinBASS]} \cdot 20 \text{ V} - 10 \text{ V} + \text{offset [V]}$$

For the scaling of parameters, which do not correspond to the standard scaling, the general calculation formulae are value. Thereby the internal representation must be used in order to calculate the parameter value. The internal representation is to be taken from the according parameter description.

16 bit signed parameter

$$U_{\text{off}} = \frac{\text{parameter value [internal]}}{4000_{\text{hex}}} \cdot \text{scaling [WinBASS]} \cdot 10 \text{ V} + \text{offset [V]}$$

32 bit signed parameter

$$U_{\text{off}} = \frac{\text{parameter value [internal]}}{40000000_{\text{hex}}} \cdot \text{scaling [WinBASS]} \cdot 10 \text{ V} + \text{offset [V]}$$

16 bit unsigned parameter

$$U_{\text{off}} = \frac{\text{parameter value [internal]}}{4000_{\text{hex}}} \cdot \text{scaling [WinBASS]} \cdot 20 \text{ V} - 10 \text{ V} + \text{offset [V]}$$

32 bit unsigned parameter

$$U_{\text{off}} = \frac{\text{parameter value [internal]}}{40000000_{\text{hex}}} \cdot \text{scaling [WinBASS]} \cdot 20 \text{ V} - 10 \text{ V} + \text{offset [V]}$$

6.2.5.2 Sample 1 - Parameters with standard scaling

In slot E (module slot 5) you have plugged in a module for analog outputs.

The value of the parameter [P0170](#) mains voltage shall be issued on output 1. Therefore parameter block 1 must be used.

Following settings are necessary:

Select fast analog output 1 ▶P1150◀	0501 _{hex}
Source number fast analog output 1 ▶P1151◀	170
Offset fast analog output 1 ▶P1152◀	-100 (no offset)
Scaling factor fast analog output 1 ▶P1153◀	1

(at output:

$U_{\text{mains}} = 0 \text{ V,}$	output = -10 V;
$U_{\text{mains}} = 400 \text{ V,}$	output = 0 V;
$U_{\text{mains}} = 800 \text{ V,}$	output = +10 V)

6.2.6 Direct access to digital in-/outputs via the PLC

6.2.6.1 Overview

The b maXX[®] controller from firmware version 3.01 onwards offers in connection with an existent drive PLC the option to read out or to control the digital in-/outputs of one or several function modules of the type DIO-01 and FIO-01 on the slots D to E.

Herewith the controller of the PLC supplies special addresses for I/O mappings on which the user program of the PLC can read or write. The contents of the mappings are exchanged in every control cycle that means **every 125 µs** between PLC and function module.

The bit assignment in the I/O mapping is defined by the hardware version status of a function module.

The status of hardware version is coded in the bits 8 ... 10 of the module identification (parameter module type slot D ... module type slot E [▶P0553◀](#) ... [▶P0554◀](#)):

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
					0	0	0								
					0	0	1								
					0	1	0								
					0	1	1								
					1	0	0								
					1	0	1								
					1	1	0								
					1	1	1								
X	X	X	X	X	Module function ID (0 0 1 0 1 _{binary} for DIO-01 and FIO-01)										

Example:

At a DIO-01 with hardware version status the ID = 2B00_{hex}.

At usage of different version statuses a decoding of the hardware version status which is dependent on the function module type is necessary in the PLC user program in order to guarantee a correct bit assignment.

6.2.6.2 Configuration

An I/O mapping address of the data type WORD (16 bit) is individually assigned to a function module. Each module possesses an own address in order to read the digital inputs from the function module and another address to write on these digital outputs.

A sharing of inputs of a function module is possible by the PLC and controller, during the usage of outputs which are configured bitwise as either only the controller or only the PLC uses the outputs of a module.

The configuration of the assignment of the outputs at the controller or at the PLC operates by the controller parameter [▶P0579◀](#) function module selection for PLC I/o accesses. Each of the lower five bits is a function module slot D ... E. If the according bit is not set, only the controller has the access to the outputs of the module. Then output information from the PLC mapping does not reach the module. If the according bit is set, the PLC can write to the outputs of the assigned module. In this case, output mappings of the controller do not effect the module, but only the controller output mapping (status of the digital outputs in module slot D ... E. Status of the digital outputs in module slot E [▶P0418◀](#) ... [▶P0419◀](#)). The controller output mapping is shown in WinBASS.

A reconfiguring of the output assignment controller or PLC also is possible in the operating status. It has to be considered that after reconfiguring the according activated output mapping immediately is set.

6.2.6.3 Addresses of I/O mapping

w_InputSlotD AT %MW3,1262094 : WORD; (* input mapping slot D *)
 w_InputSlotE AT %MW3,1262098 : WORD; (* input mapping slot E *)

 w_OutputSlotD AT %MW3,1262092 : WORD; (* output mapping slot D *)
 w_OutputSlotE AT %MW3,1262096 : WORD; (* output mapping slot E *)

6.2.6.4 Usable I/O modules

The following b maXX[®] functional modules are provided for the PLC direct accesses:

- BM-F-DIO-01
- BM-F-FIO-01

6.2.6.5 Structure of I/O mappings for DIO-01 and FIO-01 (4-bit digital in, 4-bit digital out)

The functional modules DIO-01/FIO-01 are provided with:

4 x inputs I1...I4
 4 x outputs Q1...Q4

The assignment of the bits in the I/O mapping is dependent on HW version status (bits 8 ... 10 in the module ID).

- **Hardware revision (module identification: 29xx_{hex})**

I/O input mapping

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
								0	0	0	0	0	0	0	0
															No short-circuit and 24 V supply of the E/As is existent
								1	1	1	1	1	1	1	1
															Short-circuit or 24 V supply of I/Os is missing
				X	X	X	X	Reserved							
-14	-13	-12	-11												

I/O output mapping

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
												-Q1	-Q2	-Q3	-Q4
X	X	X	X	X	X	X	X	X	X	X	X	Reserved			

- **Hardware revision B (module identification: 2Axx_{hex})**

I/O input mapping

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
									0	0	0	0	0	0	0
															No short-circuit and 24 V supply of the E/As is existent
									1	1	1	1	1	1	1
															Short-circuit or 24 V supply of I/Os is missing
					X	X	X	Reserved							
	-14	-13	-12	-11											
X	Reserved														

I/O output mapping

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
															X
															Reserved
											-Q1	-Q2	-Q3	-Q4	
X	X	X	X	X	X	X	X	X	X	X	Reserved				

Q values in order to control Q1...Q4: 1D_{hex}, 1B_{hex}, 17_{hex}, 0F_{hex}

- **Hardware revision 1C1 and 1D (module identification: 2Bxx_{hex} and 2Cxx_{hex})**

I/O input mapping

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
									0	0	0	0	0	0	0
															No short-circuit and 24 V supply of the E/As is existent
									1	1	1	1	1	1	1
															Short-circuit or 24 V supply of I/Os is missing
				X	X	X	X	Reserved							
-14	-13	-12	-11												

I/O output mapping

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
												-Q1	-Q2	-Q3	-Q4
X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	Reserved

Q values in order to control Q1...Q4: 0E_{hex}, 0D_{hex}, 0B_{hex}, 07_{hex}

6.2.7 BACI

6.2.7.1 Introduction

BACI (BAumüller-Component-Interface) define the hardware- and the software interface of Baumüller between controller and option cards in the b maXX[®] system.

Via this interface both the controller and the control system is able to communicate with other option cards, like field bus slave, field bus master card, IEI option module and so on. Likewise controller and PLC can, among each other exchange data.

6.2.7.2 System overview

A communication connection by BACI always exists between a BACI master and up to five option cards as BACI slaves. The controller module always takes in the role of the master. The PLC takes in, towards the controller, the role of a slave ON, towards all the other option modules it takes in the role of the BACI master. The control of the communication connection is automatically executed by the b maXX[®] system. A data access over BACI is always active executed by a BACI master. A data transfer from slave to slave is not possible.

BACI backplanes




Figure 28: b maXX[®] option card bus

6.2.7.3 BACI services

The BACI differs between the following communication services:

- 1 **System configuration** (after power on) and reconfiguration (during the running operation)
- 2 **Cyclic data** - quick synchronous exchange (e. g. set- and actual values) - no character strings
- 3 **Service data** for the time-uncritical data transfer of adjusted- or configured parameters.
- 4 **Command interface** - b maXX[®] internal in order to configure and diagnose automatically.
- 5 **Synchronization, interrupt.** The controller processing cycle can be synchronized via the control lines with a synchronous signal, which is, e. g. generated via a field bus option module.

Furthermore, you can generate cyclic interrupts on field bus modules by the controller. For further information please refer to the description of the according field bus module.



NOTE!

The controller only operates option modules on the slots G and H.

The controller can at the time with max. one option module exchange cyclic data (a control module belongs to this, too). Service data and commands can be operated simultaneously with two option modules at maximum.

The PLC can, with several option modules, communicate cyclic on all slots.

The controller provides parameters for the BACI system configuration and for the adjusting of cyclic communication between controller and the option module with whom cyclic data shall be exchanged.

6.2.7.4 Configuration of the BACI via controller parameter

Slot selection

[▶P0827◀](#)

The controller checks the assignment of both slots G and H consecutively in the specified sequence. It automatically configures the first option module, which it finds for the cyclic communication and herewith uses the parameters [▶P0800◀](#) to [▶P0819◀](#). If the controller recognizes a second option module it configures the second module with the parameters [▶P0860◀](#) to [▶P0879◀](#).

The assignment between the modules and the BACI configuration parameter can be exchanged with the setting in the parameter option module selection ([▶P0827◀](#)). Further information see description of this parameter.

The controller only evaluates this parameter after the switching off/switching on of the system.

Hardware-/software configuration of the option module	<p>The parameters option module G configuration 1 ▶P0830◀ ... option module G configuration 8 ▶P0837◀ as well as option module H configuration 1 ▶P0840◀ ... option module H configuration 8 ▶P0847◀ provide the option modules on slot G and H module with module-specific configuration parameters. During initialization the option modules can read these parameters and make according initialization or settings. The meaning of the entries into these parameters is module-specific and can be read in the according option module manual.</p>
Configuration of the set- and actual value parameters	<p>We designate those parameters setpoints, which are cyclic written from the option card to the controller; actual values we designate the parameters, which are cyclic written from the controller. If there is a cyclic communication, a specified scope of set- and actual values is exchanged one to another in a defined period at a determined point of time. After switching on this configuration is read from the particular controller parameters and is notified to the option card. The option card on its part can assign a deviant configuration to the controller. This happens automatically on system initialization. After completion of this initialization, the configuration parameters in the controller show the configuration which is currently valid.</p> <p>Moreover, after running up the system, that means in the running operation, an option card with the controller can declare and effectuate a change of configuration. In this case the controller configuration parameters reflect the changed configuration.</p> <p>For the cyclic set- and actual value transmissions the kind and scope of the parameters are limited:</p> <ul style="list-style-type: none">• The number of the possible set- and actual value transmissions between controller and option card are, at the moment, limited by the b maXX[®] controller of controller type 2 to eight setpoints and 8 actual values.• Only those parameters may be cyclic written, which possess the attribute „cyclic writable“ (in this manual marked with CW).• Only those parameters may be cyclic read, which have a 16- or 32-bit data type. Character strings of cyclic transfer are excluded. These can be read or can be written as service data.
Setpoints:	<p>The parameters option module 1 master 1 para-number setpoint ▶P0801◀ to ▶P0808◀ specify the parameter numbers of max. 8 theoretical possible cyclic setpoints.</p>
Actual values:	<p>The parameters option modules 1 master 1 para-number actual value ▶P0809◀ to ▶P0816◀ specify the parameter numbers of the max. 8 theoretical possible cyclic actual values.</p>
Cyclic transfer rate:	<p>Parameter option module 1 master cycle time ▶P0800◀ and option module 2 master cycle time ▶P0860◀ specify at which intervals the controller (per 125 μs) places the cyclic transfer for the assigned slave (see parameter option module select ▶P0827◀:</p>

The value refers to a multiple of 125 µs.

Value	Meaning
0	no cyclic data exchange
1	not permissible
2	250 µs
3	375 µs
and so on	

6.2.7.5 Definition of time of cyclic transfer

Option module 1 master 1 cycle offset setpoints [▶P0818◀](#) or
option module 2 master 1 cycle offset setpoints [▶P0878◀](#)
as well as

option module 1 master 1 cycle offset actual values [▶P0819◀](#) or
option module 2 master 1 cycle offset actual values [▶P0879◀](#).

Specify the cycle offset for the data exchange of the set- or actual values for the according slaves. This offset defines in which controller cycle within a transfer period the data exchange for the set- or actual values shall occur.

When using two BACI slaves it is to be considered at cycle time parameterization, cycle offset setpoints and cycle offset actual values, that not both slaves exchange data in a controller cycle, because otherwise a time-slice time-error could occur during the running operation (error No. 19).

Example:

At the same cycle time ([▶P0800◀](#)) and ([▶P0860◀](#)) the offset values however should be

Option module 1 master 1 cycle offset setpoint [▶P0818◀](#) and
option module 1 master 1 cycle offset actual values [▶P0819◀](#) are not identical.

The accordant is valid for

Option module 2 master 1 cycle offset setpoints [▶P0878◀](#) and
option module 2 master 1 cycle offset actual values [▶P0879◀](#).



NOTE!

At an unfavorable choice of the cycle offsets, during the cyclic communication access conflicts between controller and option card can arise.

Therefore, if you change an offset without exact knowledge of the time coherences, the recommendations specified in the option module manuals should be followed!

6.2.7.6 Definition of time cyclic trigger signal generation

In the chosen data exchange interval the controller can read out a cyclic trigger signal to the option module. The offset (unit μs) option module 1 master 1 trigger offset \triangleright P0817 \triangleleft determines the temporal reference between the beginning of the communication interval and the output of the trigger signal.

6.2.7.7 Sequence cyclic communication:

The following diagram outlines the temporal process of a cyclic BACI communication between controller and **an** option card. In order to configure the option card the parameters \triangleright P0800 \triangleleft to \triangleright P0819 \triangleleft are used (option module select \triangleright P0827 \triangleleft have the value 0).

The following settings are effective:

The value refers to a multiple of 125 μs .

Parameters	Value	Description
Option module 1 master 1 cycle time \triangleright P0800 \triangleleft	4	Data exchange every 500 μs . This accords to the sync-interval, on which the controller synchronizes.
Option module 1 master 1 cycle offset setpoints \triangleright P0818 \triangleleft	0	Setpoints are transmitted in the controller cycle, which follows the sync pulse, that therefore means in the interval zero.
Option module 1 master 1 cycle offset actual values \triangleright P0819 \triangleleft	3	Actual values are transferred in the third controller interval, that means in the last interval before the next sync pulse.




Figure 29: BACI timing cyclic communication

The individual processes during the communication are characterized in the diagram by parenthesized numerals, e. g. (3).

- (1) Transmission of the actual values from the controller to the option card in the third controller interval. If necessary, the actual values are scaled within the option card and are made available to the field bus.
- (2) Preparation of the setpoints by the option card and transmission of the setpoints to the controller
- (3) Within the controller processing the setpoints are written into the target parameters and afterwards the control algorithms are calculated. At the end of the controller task new actual values are available.

The detail drawing of the controller processing shows, how the controller first reads in the setpoints over the BACI interface of the option card, then writes the actual values to the option card and then calculates the control algorithms.

6.2.7.8 Error monitoring

By the usage of BACI different error sources are possible.

- Configuration errors
- Delay errors

All errors are detected by the system and are signaled via the error mechanisms of the controller and are, for example, shown in WinBASS.

Parameter error in function- or option modules [▷P0204◀](#) shows, that there is an error in coherence with an option module. The error code in the parameters error option module G ... error option module H [▷P0245◀](#) ... [▷P0246◀](#) shows the exact cause of error. If there are two errors at one module simultaneously, the controller shows the most recent error code.

Configuration errors

The most configuration errors are:

Errors	Meaning
Invalid parameter number for setpoint 1..8	The parameter number doesn't exist or isn't cyclic writable
Invalid parameter number for actual value 1..8	The parameter number doesn't exist or isn't cyclic readable (false data type)
False value für cycle time	The data of the communication interval is 0 or 1
False value für cycle offset	The value for cycle offset, that means the information, in which the controller interval set- or actual values are exchanged is invalid. Cycle offset never may never be greater than or equal to the value of the cycle time, because the counting method of cycle offset begins at 0.
PCI-error or general reading error/writing error	Reading error/writing error on the configuration register of the option module - cause: module invalid.
Timeout within the configuration phase after system start	The option module doesn't initialize its BACI driver or it initializes it too late. Error reaction is. Possible causes: · At the PLC: Program is not started. · At field bus cards: system initialization is not completed.

Delay errors

Delay errors of the BACI can appear at all communication services during the cyclic communication and at the service data communication.

Errors	Meaning
Invalid value at setpoint parameter 1... 8	The cyclic to be written value violates the min-/max limit of the named parameter
BACI-timeout with cyclic data	The controller monitors the cyclic communication over a timeout mechanism. A timeout-counter starts at the first successful cyclic setpoint transmission. Every further successful cyclic setpoint transmission re-triggers this time counter.
Access conflicts with slave at cyclic communication	At an unfavorable choice of the cycle offsets, during the cyclic communication access conflicts between controller and option card can arise. Hence these offsets shouldn't be changed from the in the option module manuals given recommendations, without having exact knowledge of the temporal connections! Corrective measures by access conflicts: Modification of the offset values.
Error cyclic communication: Alive-counter conflict	The so-called alive-counter-mechanism of BACI cyclically monitors the reciprocative existence and correct operating of the communication partner. The controller signals an alive-counter conflict, if the option card doesn't react to the cyclic communication demands anymore. Remedy: Restarting of the system, checking of the user program in the PLC, if the associated option module is a control.

Diagnosis

For a diagnosis of the BACI-communication services the controller offers the following development parameters:

Parameters	Meaning
▷P3344◀	Internal BM_u_BaciStatus.
▷P3345◀ ▷P3385◀	Counter for access conflicts with option module.
▷P3346◀ ▷P3386◀	Counter for Alive-Counter-Errors (see above)
▷P3347◀ ▷P3387◀	Counter for reconfiguration operations during the current operation
▷P3348◀ ▷P3388◀	Counter for the cyclic data exchange of setpoints.
▷P3349◀ ▷P3389◀	Counter for den cyclic data exchange of actual values.
▷P3350◀ ▷P3390◀	Counter for BACI commands
▷P3351◀ ▷P3391◀	Counter for service data communication

6.2.8 Application

Application parameter is placed at ones disposal, e. g.:

- Linking of in- and outputs
- Access via field busses or PLC

All application parameters are stored at the storing of data sets (retained).

6.3 Management

6.3.1 Drive management

The drive manager controls the essential system resources of the device. These are for example: the complete device control in the different operation modes, the change-over operation mode, troubleshooting, the managing of all communication interfaces and so on.

The device control occurs via a status machine, which is operated via the control word [▶P0300◀](#) and via hardware control inputs. Thereby, a control is possible via the hardware inputs, i. e. without operating the control word [▶P1001◀](#). The bits for the U_{DC} -control must be reset in parameter communication source.

The device control status machine is shown in [▶Figure 31◀](#) on page 74. The control word [▶P0300◀](#) and the accordant commands are precisely described in the parameter description.

The following control inputs are existent:

- Input reset errors: FX 3-4
 - A rising edge at this input enables an error reset.
- Pulse enable (IF):
 - Terminal: FX 3-5
 - Enables the pulses of the PWM. This input directly effectuates the power unit driver. If there is a zero level here, no pulses can be enabled by the power unit.

- **Device control statuses**
- NOT READY-TO-START
 - The electronics are voltage-supplied
 - Initialization is running
 - The device function is inhibited
 - “Ready-to-operate“ relay is OFF (device is not ready-to-operate)
 - Main contactor is not switched on
- INHIBIT START
 - Software/hardware initialization is completed
 - Application can be reparameterized
 - Device function is inhibited
 - Switch-on is inhibited
 - “Ready-to-operate“ relay is OFF (device is not ready-to-operate)
 - Main contactor is not switched on
- Main contactor - READY-TO-START
 - Application can be reparameterized
 - Device function is inhibited
 - Switch-on is inhibited
 - Main contactor is switched on
 - “Ready-to-operate“ relay is OFF (device is not ready-to-operate)
- READY-TO-START
 - Application can be reparameterized
 - Device function is inhibited
 - Main contactor is switched on
 - Operation is enabled
 - “Ready-to-operate“ relay is ON (device is ready-to-operate)
- SWITCHED ON
 - Application can be reparameterized
 - Device function is inhibited
 - Power unit is ready for use, there is supply voltage
 - Main contactor is ON
 - “Ready-to-operate“ relay is ON (device is ready-to-operate)

- OPERATION ENABLED
 - Application can be reparameterized
 - Device function is enabled
 - “Ready-to-operate” relay is ON (device is ready-to-operate)
 - Main contactor is ON
 - Ready-to-operate for drive (operation mode) is ON

- ERROR
 - Application can be reparameterized
 - Device function is inhibited
 - “Ready-to-operate” relay is OFF (device is not ready-to-operate)
 - Main contactor is OFF
 - Ready-to-operate for drive (operation mode) is OFF

- UNREGULATED DC LINK VOLTAGE
 - Application can be reparameterized
 - Device function is LIMITED (power reduction is necessary)
 - “Ready-to-operate” relay is ON (device is ready-to-operate)
 - Main contactor is ON
 - Ready-to-operate for drive (operation mode) is ON

Introduction of the device control display





Figure 30: Introduction of the device control

Within the statuses (see above) the bits 7 ...0 of the status word **>P0301<** are shown in binary type as XXXX XXXX.

At the state transitions (arrows, see above) the bits 7 ...0 of the control word **>P0300<** are shown in binary form as xxxx xxxx.

All digits, which are marked with X (that means the bits of the status word) or x (that means the bits of the control word) are without a meaning for the control of the status machine and the representation of the current status.

• Device control status machine



BHS : Ready for main contactor ON
 BA: Ready-to-operate drive
 BIF: Ready for pulse enable

IF = 1: Pulse enable on 1-level (1 = high)
 IF = 0: Pulse enable on 0-level (0 = low)
 BA = 1: Ready-to-operate on 1-level (1 = high)
 BA = 0: Ready-to-operate on 0-level (0 = low)
 BIF = 1: Ready for pulse enable on 1-level (1 = high)
 BIF = 0: Ready for pulse enable on 0-level (0 = low)
 BHS = 1: Ready for main contactor ON on 1-level (1 = high)
 BHS = 0: Ready for main contactor ON on 0-level (0 = low)

Figure 31: Device control status machine

- **State transitions of device control**

0 Input of the status machine → NOT READY-TO-START

- Event:
 - Switch on electronic power supply
 - Hardware reset or
 - Software reset
- Action:
 - “Ready-to-operate“ relay is switched off
 - Initialization and self-test are started

1 NOT READY TO START → Inhibit start

- Event:
 - Initialization and self-test are completed error-free
- Action:
 - Monitoring precharge is activated

2 Inhibit start → MAIN CONTACTOR READY-TO-START

- Event:
 - Precharge successful
 - Ready for main contactor ON
- Action:
 - Main contactor ON = 1

3 MAIN CONTACTOR READY-TO-START → READY-TO-START

- Condition:
 - Main contactor monitoring ok
- Action:
 - Signal ready for pulse enable = 1

4 READY-TO-START → SWITCHED ON

- Event:
 - Command “switch on“
- Condition:
 - Pulse enable FX3-5 = 1
 - Power unit signal ready-to-operate
- Action:
 - Monitoring DC-link voltage is activated
 - Monitoring ready-to-operate of the power unit is activated
 - Pulses are enabled, U_{DC} is controlled

5 SWITCHED ON → ENABLED

- Event:
 - $U_{DC} > U_{DC} - \text{setpoint}$
- Action:
 - Ready-to-operate relay is switched on
 - BA of DIO = 1 and FX3-1 = 1

6 ENABLED → READY-TO-START

- Event:
 - Pulse enable FX3-5 = 0
 - or
 - command “shut down”
- Action:
 - Device function is inhibited, pulse is inhibited
 - “Ready-to-operate” relay is switched off
 - BA of DIO = 0 and FX3-1 = 1
 - Monitoring ready-to-operate of the power unit is switched off

7 SWITCHED ON → READY-TO-START

- Event:
 - Pulse enable FX3-5 = 0
 - or
 - command “shut down”
- Action:
 - Device function is inhibited, pulse is inhibited
 - Monitoring ready-to-operate of the power unit is switched off

8 READY-TO-START → INHIBIT START

- Event:
 - $U_{DC} < \text{threshold}$
 - Command “inhibit voltage”
- Action:
 - Main contactor is switched off
 - Device is inhibited
 - BIF = 0

9 MAIN CONTACTOR READY-TO-START → INHIBIT START

- Event:
 - $U_{DC} < \text{threshold}$
 - Command “inhibit voltage”
- Action:
 - Main contactor is switched off
 - Device is inhibited

10 all statuses → ERROR

- Event:
 - Device error is recognized
- Action:
 - Main contactor is switched off
 - Device function is inhibited, pulse is inhibited
 - “Ready-to-operate” relay is switched off
 - BA of DIO = 0
 - Monitoring ready-to-operate of the power unit is switched off
 - BIF = 0

11 ERROR → INHIBIT START

- Event:
 - Command “reset error“ or
 - RESET ERROR MEMORY input = 0 → 1 (rising edge)
- Condition:
 - Error doesn't exist anymore
- Action:
 - Reset error is carried out
 - Monitoring precharge is activated

12 ENABLED → UNREGULATED DC LINK VOLTAGE

- Event:
 - Mains fault, but no power failure
- Condition:
 - [▶P1007◀](#) error reaction = 1
- Action:
 - Pulses are inhibited
 - Power limit reached from DIO = 1

13 UNREGULATED DC LINK VOLTAGE → ENABLED

- Event:
 - Mains fault no longer detected
- Action:
 - Pulses are enabled, $U_{DC \text{ link}}$ is controlled
 - Power limit reached from DIO = 0

The status change only operates, if the actions have completely been carried out. The sequence of the actions is the same as their execution during condition change. After complete controller processing of the actions the next status is reached and new commands are accepted.

- Control of the ready-to-operate relay

The switching condition of the ready-to-operate relay is only changed at the following transition conditions.

Transition	Switching action at the ready-to-operate relay	Comment
0	Switch off	Beginning of initialization of the device
5	Switch on	U_{DC} is controlled
13	Switch off	An error has occurred in the device.
6	Switch off	Pulse enable = 0 or error

The outcome for each status of the drive manager is a definite operating status for the ready-to-operate relay.

Status	Operating status of the ready-to-operate relay
NOT READY-TO-START	OFF
INHIBIT START	OFF
MAIN CONTACTOR-READY-TO-START	OFF
READY-TO-START	OFF
SWITCHED ON	OFF
OPERATION ENABLED	ON
ERROR REACTION ACTIVE	OFF
ERROR	OFF
UNREGULATED DC LINK VOLTAGE	ON

6.3.2 Data set management

A description of the data set management function principle you will find in chapter [▶Data Set Management◀](#) from page 13.

6.3.3 PSI-management

The description of the mode of functioning of the **PSI (Parameter Storage Interface)** is to be found in chapter [▶Data Set Management◀](#) from page 13.

6.4 Setpoint generators

6.4.1 Ramp function generator

The ramp function generator is for the generation of acceleration- or deceleration ramps of the setpoint of the DC-link voltage in the DC-link voltage control.

The ramp function generator has an input with a separately ramp-up- and ramp-down time.

The input value of the acceleration encoder is an absolute variable in V.

The ramp grade for the rising and the decrease of the DC-link voltage is determined by the acceleration- or deceleration time. The times thereby refer to 0 V setpoint change.

For the further acceleration- or deceleration a smoothing element (smoothing) with an adjustable time constant is connected to the ramp function generator.

The ramp function generator offers the following control possibilities directly via the control word also see [▶P0300◀](#) on page 114:

- Stop ramp function generator (freeze output value)

Furthermore the negative setpoint at the ramp function generator is inhibited.

6.4.2 Setpoint generator

6.4.2.1 Fix setpoint

The setpoint generator 1 generates a constant setpoint of the DC link voltage.

The setpoint generator is able to effectuate the following target parameter (adjustable via [▶P0440◀](#) setpoint generator mode):

- Fix setpoint

Normally $U_{DC\ link}$ should calculated as follows:

$$U_{DClink} = 1,35 \cdot U_{mains}(\text{phase} - \text{phase}) + 100\text{ V}$$

line to line

6.4.2.2 Time controlled setpoint

The setpoint generator 2 generates for each of the four time zones a constant setpoint. Thereby the setpoint and the time is adjustable for every zone.

The setpoint generator 2 is able to effectuate the following target parameters (adjustable via \blacktriangleright P0440 \blacktriangleleft setpoint generator mode):

- Time control

In this mode the output time for the according setpoint is set with the time.

Furthermore it can be set, if after expiration of the last time zone the setpoint generator starts with the first time zone again (endless operation), or if only one cycle is passed through and the last setpoint remains.

Therewith, e. g. the following U_{DC} -setpoint variation can be generated:




Figure 32: Setpoint generator U_{DC} -setpoint variation

The setpoint generator 2 has a cycle time of 16 ms and is only active if the device is enabled. After enable of the device it is always started with the first setpoint from the profile, which was set.

6.4.2.3 Setpoint depending on mains voltage

from firmware-version FW 03.07

The setpoint generator 3 generates the setpoint of DC link voltage, which depends on the mains voltage.

The setpoint generator 3 is able to effectuate the following target parameters (adjustable via **P0440** setpoint generator mode):

- depends on mains voltage

A hysteresis has been set:




Figure 33: DC link voltage depending on the mains voltage

6.5 Diagnosis

6.5.1 Oscilloscope function

For the quick and user-friendly commissioning the b maXX[®] controller offers an integrated oscilloscope function.

Function range of oscilloscope function:

Number of channels:	8
Sampling time:	$2^n * 125 \mu\text{s}$ (n = 0...65535)
Recording:	triggered or not triggered
Triggering:	<ul style="list-style-type: none">• by internal status change,• change of value or• external digital or analog inputs
Number of triggers	2
Trigger linking:	Logic operation of both trigger events: AND, OR, XOR
Trigger time referring to memory depth:	programmable 0 ... 100 % (i. e. recording with or without history referring to the trigger event)
Trigger sources:	<ul style="list-style-type: none">• digital signals (selection of relevant bits via bit masks possible) e. g.:<ul style="list-style-type: none">○ status change○ error- or warning events○ external digital inputs• analog signals<ul style="list-style-type: none">○ set- or actual values○ analog inputs

- 1 Command, in order to initiate recording in bmaXX[®] controller.
- 2 Command to interrupt a running recording. Then no values are shown.
- 3 Command to start a recording with the trigger condition (trigger settings (see [▶Oscilloscope configuration◀](#) from page 83)).
- 4 Export recorded measuring data to an external CSV file (table).
- 5 Invoking dialog „oscilloscope configuration“ (also see [▶Oscilloscope configuration◀](#) from page 83).
- 6 Buttons to position the scales.
- 7 Buttons to switch on or switch off the measuring curves.
- 8 Invoking dialog „oscilloscope limits“ (also see [▶Oscilloscope scaling◀](#) from page 83).
- 9 The larger the storage of oscilloscope is set, the longer the measuring values are recorded, but also the longer the transmission of data will take.

► Oscilloscope configuration

In this window trigger conditions can be configured and the source parameters for the maximum of eight channels can be selected. The deactivating of record channels enlarges automatically the available record buffer for the remaining channels.

► Oscilloscope scaling

There is the possibility to set limits for each scale of the measuring curves. In mode „user limits“ the limits, which where set on this dialog are immediately accepted. At „auto. limits“ automatically calculated limits are set from the recorded minimum and maximum values.

7

PARAMETERS

For the controller b maXX[®] 4100 there are more than 300 parameters, which are described in this chapter.

7.1 Structure of controller parameter range

Every parameter has

- a name,
- an association to a function group,
- an unique number,
- a data type,
- and fixed attributes or characteristics.

7.1.1 Range of numbers

Not all parameter numbers have been assigned yet - according to function association and meaning. The following table shows the parameter range of numbers:

Range	Parameter numbers	
	from	up to
Reserved for invalid number	0	0
Controller identification	1	5
Power unit identification	6	49
Data for the mains inverter	170	189
Actual values and operational data	190	599
Reserved	600	859
BACI configuration	860	879
Reserved	880	899
Array parameters	900	999
Active data set	1000	1999

7.1 Structure of controller parameter range

Range	Parameter numbers	
	from	up to
Oscilloscope function	2000	2029
System	2030	2049
Reserved	2050	2999
Development parameters	3000	3499
Reserved	3500	65535

7.1.2 Field bus addressability

Access on parameters by use of field busses is done using the parameter numbers only. Some field busses do not support 16-bit-numbers or limit the valid range of numbers. Thereby the arrangement of the parameters in number ranges for b maXX was selected in such a way, that all parameters relevant for the operation of the controller are addressable by standardized field busses.



NOTE!

When handling data set parameters, you can access by use of the parameter number only the parameters of the active data set.

Overview of field busses and accessibility of appliance parameters.

Field bus	Directly accessible parameter range in LC/MC appliance	Manufacturer parameter number in protocol	Expansion by two-step access possible
OPC	All	Parameter name	Not necessary
USS	0 - 2047	Para No.	yes
PROFIBUS	0 - 1999 (without 900 - 999)	Para No.	yes
CANopen	0 - 16384	Para No. + 4000 _{hex}	yes
CANsync	0 - 4095	Para No.	yes
Sercos	0 - 4095	Para No. + 8000 _{hex}	yes

7.1.3 Data type

Every parameter has a data type. The data type reflects the number of bytes occupied by the parameter and the interpretation of each single bit. The b maXX recognizes the following data types:

Data type	Bit number	Value range
INT	16	-32768 to 32767
UINT	16	0 to 65,535
DINT	32	-2,147,483,648 to 2,147,483,647
UDINT	32	0 to 4,294,967,295
WORD	16	0 to FFFF _{hex}
DWORD	32	0 to FFFFFFFF _{hex}
STRING	80 * 8	80 ASCII characters

Some parameters become standardized from the ranges of integer values stated in the table above into smaller or bigger ranges of values. WinBASS II/ProDrive carries out this scaling automatically, but at accesses via external field buses it eventually must be taken into account.

Example:

Parameters **P0171 PSU DC link actual mains voltage (filtered)**

Data type = UINT (normal range of values, 0 to 65535)

Scaled range of values: 0 to 2160 V.

One increment equals 0.03296 volts

7.1 Structure of controller parameter range

7.1.4 Attributes

Every parameter can have one or more attributes - see detailed parameter description

Attributes	Meaning
A	Parameter only serves as display (identification, operational status, actual value, etc.)
EE	The parameter is part of the "Central data" and can be stored in EEPROM. This parameter will be automatically loaded from the controller's internal EEPROM when the controller is started.
DS	Data set parameter This parameter can be stored to one of the four existing data sets. When the controller is switched on it will be loaded automatically out of the controller-internal EEPROM.
-	The parameter will not be stored (effective for e.g. actual values)
CW	The parameter may (e. g. via a field bus) be written cyclical. Normally this affects synchronously to be written setpoints or the control word of the controller. Parameters, who don't have this attribute, can be written to only by using the service data communication (or WinBASS II/ProDrive) - thereby consider parameter 'Communication source' ▶P1001◀ .

7.1.5 Reserved bits

In the description of the parameters, especially of the mode parameters and status parameters several bits are marked as reserved. The bits can obtain an importance with future extensions. For these bits the following is valid:

- In setting parameters the bits are to be set to 0.
- In status parameters these bits are not to be evaluated.

7.2 Structure of the parameter description

All parameter descriptions are based on the following scheme:

P1172	Hochlaufgeber Hochlaufzeit	0.00 to 650.00 s	
DS	Ramp function generator ramp-up time	0.00 s	
	BM_u_Ds0_RFG1RampUpTime	100:1	CW

The different branches of the scheme are described below:




Figure 34: Parameter description scheme

The construction of the internal parameter name is shown below:




Figure 35: Construction of internal parameter name

7.2 Structure of the parameter description

In the tables in which we have listed the meaning of the single error bits, you will also find - by certain parameters - the column „reaction“ and „following parameter“. Thereby was meant:

Reaction

IS = Pulse inhibit, the drive reacts to this error with pulse inhibit. This reaction can, on behalf of the security, not be changed.

Settable = You can adjust the reaction of the drive to this error. Use for the selection of the code the following table:

Selection code	Function	Name
0	Pulse inhibit	DRIVE_REACTION_PULSEINHIBIT
1	Deceleration on the ramp function generator	DRIVE_REACTION_RFG_STOP
-1	No reaction	DRIVE_REACTION_NONE

Following parameters - With following parameters we denote the parameter(s), in which further details according an error event are shown.

Example:

In the parameter ▶P0206◀ an error is shown by bit 0 (error No. 80), which was set. In the „following parameter“ ▶P0233◀ then the exact error cause of the communication error by means of the displayed error number can be read off there.

7.3 Parameter description

P0001	Regler Typ	1 to 3	
-	Controller type	1	
A	BM_u_ControllerType	1:1	-

Identification of controller type.

Value	Meaning
1	LC controller
2	LC controller with 28xx-processor(LC2)
3	LC controller with 28xx-processor (LC3)

P0002	Regler Firmware-Typ	0 to 65535	
-	Controller firmware type	0	
A	BM_u_SoftwareType	1:1	-

Differentiation between standard firmware and customized firmware.

Value	Meaning
0	Standard software
1 to 65535	Customized software

P0003	Regler Firmware-Nummer	0 to 65535	
-	Controller firmware ID	0	
A	BM_u_SoftwareID	1:1	-

Baumüller internal software number.

P0004	Regler Firmware-Version	0.00 to 655.35	
-	Controller firmware version	0.00	
A	BM_u_SoftwareVersion	100:1	-

Version of the software, which is used.




Figure 36: Controller software version

7.3 Parameter description

P0005	Parametertabellen-Version	0 to 65535	
-	Parameter table version	0	
A	BM_u_ParamTableVersion	1:1	-
	Version of parameter table used.		
P0006	Leistungsteil-Typenschlüssel	20 ASCII characters	
-	Power unit type code	""	
A	BM_s_AmpType	1:1	-
	Display of power unit type key. 0 means unknown power unit.		
P0007	Leistungsteil Seriennummer	0 to 65535	
-	Power unit serial number	0	
A	BM_ud_AmpSerialNr	1:1	-
	Display of power unit serial number. 0 means unknown serial number.		
P0008	Leistungsteil Datenkonfiguration	0 to 65535	
-	Power unit data configuration	0	
A	BM_u_AmpDataConfig	1:1	-
	Baumüller internal power unit data code.		
P0009	Leistungsteil Firmware-Version	0 _{hex} to FFFF _{hex}	
-	Power unit firmware version	0 _{hex}	
A	BM_u_AmpSW_Version	1:1	-
	Version of power unit software.		




Figure 37: Software version of power unit

Example: 0201_{hex} is according to software version 2.01.

P0012	Leistungsteil Nennstrom 8 kHz	0.0 to 6553.5 A	
EE	Power unit nominal current 8kHz	2.5 A	
A	BM_u_AmpNomCurrent8kHz	10:1 A	-
	Display of power unit nominal current at 8 kHz switching frequency.		
P0013	Leistungsteil Maximalstrom 8 kHz	0.0 to 6553.5 A	
EE	Power unit peak current 8kHz	2.5 A	
A	BM_u_AmpPeakCurrent8kHz	10:1 A	-
	Display of power unit peak current at 8 kHz switching frequency. The peak current is greater or equal to the power unit nominal current at 8 kHz.		
P0014	Leistungsteil Überlastzeit 1	0.00 to 655.35 s	
EE	Power unit overload time 1	1.00 s	
A	BM_u_AmpTimeConst1kHz	100:1 s	-
	Display of defined time constant in the power unit "overload time 1". During the overload time 1 the power unit can be operated with peak current. After that, the current will be limited to the nominal current.		
P0015	Leistungsteil Überlastzeit 2	0.00 to 655.35 s	
EE	Power unit overload time 2	1.00 s	
A	BM_u_AmpTimeConst2	100:1 s	-
	Display of defined time constant in the power unit "overload time 2". During the overload time 2 the power unit can be operated with peak current. After that, the current will be limited to the nominal current.		
P0016	Leistungsteil Innenraum-Warntemperatur	0 to 125 °C	
EE	Power unit internal device warning temperature	75 °C	
ON	BM_u_AmpAmbientWarnTemp	1:1	-
	Warning threshold for interior air temperature within power unit. If the inside air temperature exceeds this threshold, warning 16 is generated. The warning threshold of every power unit has a predefined individual value. Warning threshold can be changed.		

P0017	Leistungsteil Inneraum-Abschalttemperatur	0 to 125 °C	
EE	Power unit internal device shutdown temperature		
A	BM_u_AmpAmbientMaxTemp	1:1 °C	-
	Display of shutdown threshold for interior air temperature. If the interior air temperature exceeds this threshold, the power unit will be shut down and error 85 will be generated.		
P0018	Leistungsteil Kühlkörper-Warntemperatur	0 to 125 °C	
EE	Power unit heatsink warning temperature	75 °C	
ON	BM_u_AmpHeatsinkWarnTemp	1:1 °C	-
	Warning threshold for heatsink temperature within power unit. If the heatsink temperature exceeds this threshold, warning 17 is generated. The warning threshold of every power unit has a predefined individual value. Warning threshold can be changed.		
P0019	Leistungsteil Kühlkörper-Abschalttemperatur	0 to 125 °C	
EE	Power unit heatsink shutdown temperature		
A	BM_u_AmpHeatsinkMaxTemp	1:1 °C	-
	Display of shutdown threshold for heatsink temperature. If the heatsink temperature exceeds this threshold, the power unit is shut down and error 81 is generated.		
P0020	Leistungsteil Uzk-Nennwert	280 to 1000 V	
EE	Power unit nominal voltage	540 V	
	BM_u_AmpNomDcLinkVolt	1:1 V	-
	Nominal value of DC link voltage for internal voltage scaling within control. This value should be always 540 V independent on U_{DC} link setpoint (▶P1353◀).		
P0021	Leistungsteil Totzeit	0.0 to 6553.5 µs	
EE	Power unit dead time	0.0 µs	
A	BM_u_AmpDeadTime	10:1 µs	-
	Dead time required for power transistors. Internal value, not relevant for user.		

P0022	Leistungsteil Bürdenfaktor Iac	-1.65 to 1.65 V	
EE	Power unit burden factor Iac	0 V	
A	BM_i_AmpBurdenFactor_Iac	100:1 V	-

Conversion factor for current measuring. Internal value, not relevant for user.

P0023	Leistungsteil Bürdenfaktor Vdc	0.00 to 10.00 V	
EE	Power unit burden factor Vdc	0 V	
A	BM_u_AmpBurdenFactor_Vdc	100:1 V	-

Conversion factor for DC link voltage measurement. Internal value, not relevant for user.
Displayed value accords to $1000 \text{ V } U_{\text{DC link}}$.

P0024	Leistungsteil Modus	0_{hex} to FFFF_{hex}	
EE	Power unit mode	0_{hex}	
	BM_w_AmpMode	1:1	-

Setting for behavior of power unit.

Bit No.	Meaning
0	0: Fan is controlled via the heatsink temperature of the power unit 1: Fan is switched on with mains-on signal
15 ... 1	reserved

P0030	Leistungsteil Bürdenfaktor Netzspannung	0 to 65535	
A	Power unit burden factor Vmain	0	
	BM_u_AmpBurdenFactor_Main	1:1	-

Power unit-specific burden factor for the measurement of the mains voltage.

P0170	Einspeiseeinheit Netzspannung gefiltert	0 to 763.6 V	
-	PSU actual mains voltage (filtered)	0 V	
A	BM_u_ActMainVoltFiltered	4000_{hex} :100 %	-

Display of filtered mains voltage (smoothing time = 8 ms).
Scaling: $100 \% \leftrightarrow \text{Power unit } U_{\text{DC link}} \text{ nominal value } (\rightarrow \text{P0020}) / \sqrt{2}$

7.3 Parameter description

P0171 Einspeiseeinheit UZK-Istwert gefiltert 0 to 1080 V
 - **PSU DC link actual mains voltage (filtered)** 0 V
 A BM_u_ActDCLinkVoltFiltered 4000_{hex}:100 % -
 Display of the filtered DC-link voltage. The smoothing time is set in [▶P1342◀](#).
 Scaling: 100 % ↔ Power unit U_{DC link} nominal value ([▶P0020◀](#))

P0172 Einspeiseeinheit Netzleistung-Istwert -3276.8 to 3276.7 kW
 - **PSU actual mains power** 0 kW
 A BM_i_ActMainPower 10:1 kW -
 Display of measured mains power.

P0173 Einspeiseeinheit Netzfrequenz-Istwert gefiltert 0 to 312.5 Hz
 - **PSU actual mains frequency** 0 Hz
 A BM_i_ActMainFreqFiltered 65535/312.5 Hz -
 Display of measured mains frequency (smoothing time = 20 ms).

P0174 Einspeiseeinheit Status 1 0_{hex} to FFFF_{hex}
 - **PSU status1** 0
 A BM_w_PSU_Status1 1:1 -
 Status 1 of supply unit

Bit No.	Meaning
0	1: Mains ok
3 ...1	Reserved
4	1: Phase failure
5	1: Power failure
6	1: Undervoltage
7	1: Overvoltage
8	1: Error phase sequence identification
9	1: Frequency change > 5 Hz/s
10	1: Frequency range exceeded
11	1: Errors mains connection
12	1: Errors U _{DC} min
13	1: Error synchronization
15 ... 14	Reserved

P0175

Einspeiseeinheit Status2

0_{hex} to FFFF_{hex}

-

PSU status2

0

A

BM_w_PSU_Status2

1:1

-

Status 2 of supply unit

Bit No.	Meaning
0	Main contactor control 0: Main contactor off 1: Main contactor on
1	Monitoring main contactor 0: None 1: O.K.
2	Monitoring after debouncing operation 0: None 1: O.K.
3	Phase sequence 0: Clockwise 1: Counter-clockwise
4	Phase sequence identification 0: Not completed 1: Completed
5	Offset compensation 0: Not completed 1: Completed
6	Mains frequency 0: 50 Hz 1: 60 Hz
7	Mains frequency measurement 0: Not executed 1: Executed
8	Monitoring mains connection 0: Not executed 1: Executed
9	Precharging 0: Off 1: On
10	Current limit reached 0: No 1: Yes
11	Energy direction 0: Supply 1: Feedback
13 ... 12	Reserved
14	Precharging 0: Not completed 1: Completed
15	Ready-to-operate 0: Not ready 1: ready

7.3 Parameter description

P0176	Einspeiseeinheit Status3	0 _{hex} to FFFF _{hex}	
-	PSU status 3	0	
A	BM_w_PSU_Status3	1:1	-

Status 3 of supply unit

Bit No.	Meaning
0	0: ID Set-ID Actual < Diff_Id_Max 1: ID Set-ID Actual >= Diff_Id_Max
1	0: Iq Set-Iq Actual < Diff_Iq_Max 1: Iq Set-Iq actual >= Diff_Iq_Max
2	0: Vdc Set-Vdc actual < Diff_Vdc_Max 1: Vdc Set-Vdc actual >= Diff_Vdc_Max
14 ... 3	Reserved
15	0: Not ready for precharge 1: Ready for precharge

P0177	Einspeiseeinheit UZK-Regler Status	0 _{hex} to FFFF _{hex}	
-	PSU DC link controller status	0	
A	BM_w_PSU_VdcCtrlStatus	1:1	-

Status 1 of supply unit.

P0178	Einspeiseeinheit Ausgangswert des Hochlaufgebers	0 _{hex} to FFFFFFFF _{hex}	
-	PSU ramp function generator output	0	
A	BM_ud_PSU_RFPOutput	1:1	-

Status 1 of supply unit.

P0179	Einspeiseeinheit UZK-Sollwert	280 V to 800 V	
-	PSU DC link voltage set voltage	640 V	
A	BM_u_PSU_DClinkVoltSetBUC	1:1	CW

This parameter is only for the display.

P0180	Einspeiseeinheit SWG Sollwert1	280 V to 800 V	
EE	PSU SVG setpoint 1	640 V	
	BM_u_PSU_SVGSetvalue1	1:1 V	CW

This parameter can be used with values of -280 V to +800 V. The setpoints are switched onto the setpoint generator output depending on the assigned time.

P0181	Einspeiseeinheit SWG Sollwert2	280 V to 800 V	
EE	PSU SVG setpoint 2	640 V	
	BM_u_PSU_SVGSetvalue2	1:1 V	CW

This parameter can be used with values of -280 V to +800 V. The setpoints are switched onto the setpoint generator output depending on the assigned time.

P0182	Einspeiseeinheit SWG Sollwert3	280 V to 800 V	
EE	PSU SVG setpoint 3	640 V	
	BM_u_PSU_SVGSetvalue3	1:1 V	CW

This parameter can be used with values of 280 V to +800 V. The setpoints are switched onto the setpoint generator output depending on the assigned time.

P0183	Einspeiseeinheit SWG Sollwert4	280 V to 800 V	
EE	PSU SVG setpoint 4	640 V	
	BM_u_PSU_SVGSetvalue4	1:1 V	CW

This parameter can be used with values of -280 V to +800 V. The setpoints are switched onto the setpoint generator output depending on the assigned time.

P0184	Einspeiseeinheit DIO Status	0 _{hex} to FFFF _{hex}	
-	PSU DIO status	0 _{hex}	
A	BM_u_PSU_DIOStatus	1:1	-

This parameter displays the DIO status of the power supply unit.

Bit No.	Meaning
0	Ready for pulse enable
1	Current limit reached
2	Ready-to-operate for drive
3	Ready for main contactor ON
15 ... 4	reserved

7.3 Parameter description

P0200	Fehler System 1	0_{hex} to $\text{FFFFFFF}_{\text{hex}}$
-	Error System 1	0_{hex}
A	BM_dw_SysError1	1:1 -

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®] 4100.

Bit No.	Meaning	Reaction	Following parameter
0	Error in module μ -processor	IS	P0201
1	Error in module operating system	IS	P0202
2	Error in module Proprog communication	adjustable	P0203
3	Error in functional or optional modules	adjustable	P0204
4	Error in module feed unit	adjustable	P0205
5	Error in module power unit	adjustable	P0206
9 ... 6	not assigned = 0		
10	Error in module drive manager	adjustable	P0211
11	Error in module data set manager	adjustable	P0212
13 ... 12	not assigned = 0		
14	Error in module free programmability	adjustable	P0215
15	Reserved	adjustable	P0216
32 ... 16	Reserved		

P0201	Fehler Prozessor	0_{hex} to FFFF_{hex}
-	Error Processor	0_{hex}
A	BM_w_ProcessorSysError	1:1 -

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®] 4100.

Errors in module processor.

Bit No.	Meaning	Error No.	Reaction
0	Reserved	0	
1	Watchdog error	1	IS
2	False or unexpected interrupt has occurred	2	IS
3	NMI-Interrupt has occurred /bus error	3	IS
15 ... 4	not assigned = 0	4 to 15	

P0202	Fehler Betriebssystem	0_{hex} to FFFF_{hex}	
-	Error Operating System	0_{hex}	
A	BM_w_OperatingSysError	1:1	-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®] 4100.

Error in module operating system.

Bit No.	Meaning	Error No.	Reaction
0	Errors while booting	16	IS
1	Software error:	17	IS
2	Time slot configuration	18	IS
3	Time slicing - time violation	19	IS
4	1= not assigned memory	20	IS
5	Invalid error code	21	IS
6	Invalid warning code	22	IS
7	False FPGA version	23	IS
15 ... 8	not assigned = 0	24 to 31	

P0203	Fehler PROPROG Kommunikation	0_{hex} to FFFF_{hex}	
-	Error in module Proprog communication	0_{hex}	
A	BM_w_ProprogSysError	1:1	-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®] 4100.

Error in module Proprog communication driver.

Bit No.	Meaning	Error No.	Reaction
0	Timeout protocol	32	No reaction
1	Protocol structure	33	No reaction
2	Incorrect module type	34	No reaction
3	Too many data in the telegram	35	No reaction
4	Not enough data in telegram	36	No reaction
5	Invalid operand	37	No reaction
6	Invalid memory type	38	No reaction
7	Invalid operand address	39	No reaction
8	Value less than the minimum value	40	No reaction
9	Value greater than the maximum value	41	No reaction
10	Parameter is write-protected	42	No reaction
11	Parameters in this operation status not writeable	43	No reaction
12	Incorrect parameter value	44	No reaction
13	Communication error WinBASS/ProDrive ↔ controller	45	can be set with ▶P1007◀
15 ... 14	not assigned = 0	46 to 47	

P0204

Fehler in Funktions- oder Optionsmodulen

0_{hex} to FFFF_{hex}

-

Error in function- or option modules

0_{hex}

A

BM_w_ExtendedModuleError

1:1

-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®] 4100.

Error in additional modules.

Bit No.	Meaning	Error No.	Reaction	Sequence parameter
0	Error in function module A	48	Level 3 error	P0240
1	Error in function module B	49	Level 3 error	P0241
2	Error in function module C	50	Level 3 error	P0242
3	Error in function module D	51	Level 3 error	P0243
4	Error in function module E	52	Level 3 error	P0244
5	Error in option module G	53	Level 3 error	P0245
6	Error in option module H	54	Level 3 error	P0246
10 ... 7	not assigned = 0	55 to 58	Level 3 error	
11	Timeout when waiting for the RST signal of the slaves	59	IS	
12	CRC error in SPI transmission module ▶ controller	60	No reaction	
13	CRC error in SPI transmission controller ▶ module	61	No reaction	
15 ... 14	not assigned = 0	62 to 63		

P0205

Fehler Netzeinspeisung

0_{hex} to FFFF_{hex}

-

Error PSU0_{hex}

A

BM_w_PSU_SysError

1:1

-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®] 4100.

Error in module feed unit.

Bit No.	Meaning	Error No.	Reaction
0	Power failure	64	adjustable
1	Phase failure	65	IS
2	Mains undervoltage	66	IS
3	Mains overvoltage	67	IS
4	Undervoltage 24 V	68	IS
5	Phase sequence identification error	69	IS
6	Frequency change	70	IS
7	Frequency range error	71	IS
8	Error of main contactor	72	IS
9	No monitoring signal from the main contactor	73	IS
10	Error at precharge	74	IS
11	Mains input undervoltage U _{DC}	75	IS
12	Mains connection error	76	IS
13	Current limit reached	77	IS
14	Synchronization errors	78	IS
15	not assigned = 0	79	

7.3 Parameter description

P0206

Fehler Leistungsteil

0_{hex} to FFFF_{hex}

-

Error Power Unit

0_{hex}

A

BM_w_AmpSysError

1:1

-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®]4100.

Error in module power unit.

Bit No.	Meaning	Error No.	Reaction	Following parameter
0	Communication error after HIPERFACE [®] specification	80	IS	▶P0233◀
1	Heatsink temperature	81	IS	
2	Overvoltage DC link	82	IS	
3	Overcurrent	83	IS	
4	Earth current	84	IS	
5	Device internal overtemperature	85	IS	
6	Cable break temperature sensor	86	IS	
7	Safety relay off (and accordingly defect)*)	87	IS	
8	Bridge short-circuit	88	IS	
9	Power unit not ready-to-operate	89	IS	
15 ... 10	not assigned = 0	90 to 95		

*) : The controller signals an error „Error safety relay“ (Amp Error 87), if pulse enable has been set and one of the cases occurs:

- 1 The safety relay is not controlled or
- 2 the safety relay is faulty

If there is no pulse enable and if the cases 1) or 2) occur, the controller only signals a warning (No. 20).

P0211	Fehler Antriebs-Manager	0_{hex} to FFFF_{hex}	
-	Error drive manager	0_{hex}	
A	BM_w_DriveManagSysError	1:1	-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®]4100.

Error in module drive manager.

Bit No.	Meaning	Error No.	Reaction
0	Timeout communication	160	No reaction
1	Timeout BACI	161	No reaction
2	Timeout cyclic communication	162	No reaction
3	Timeout required data	163	No reaction
4	Field bus error	164	No reaction
5	Controller not synchronous to external signal	165	adjustable ▶P0300◀
15 ... 6	not assigned = 0	166 to 175	

P0212	Fehler Datensatzverwaltung-Manager	0_{hex} to FFFF_{hex}	
-	Error data set manager	0_{hex}	
A	BM_w_DataRecSysError	1:1	-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®]4100.

Error in module data set management.

Bit No.	Meaning	Error No.	Reaction
0	EEPROM copy error	176	No reaction
1	Write timeout EEPROM	177	No reaction
2	checksum error	178	IS
3	No boot data set	179	IS
4	Incompatible software	180	IS
5	Data record is nonexistent	181	No reaction
6	Checksum error im PSI module	182	No reaction
7	PSI is reset	183	No reaction
8	PSI data invalid	184	No reaction
9	Autotuning tables invalid. (carry out autotuning anew)	185	No reaction
10	A/D correction table invalid (exchange controller cartridge)	186	No reaction
15 ... 11	not assigned = 0	187 to 191	

7.3 Parameter description

P0215 Fehler Freie Programmierbarkeit 0_{hex} to FFFF_{hex}

- **Error in module free control section.** 0_{hex}

A BM_w_FreeCtrlSecSysError 1:1 -

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®]4100.

Error in module free control section.

Bit No.	Meaning	Error No.
15 ... 0	not assigned = 0	224 to 239

P0216 Fehler CANsync 0_{hex} to FFFF_{hex}

- **Error CANsync** 0_{hex}

A BM_w_CANSyncError 1:1 -

Reserved

P0233

Fehler Leistungsteil-Serielle Schnittstelle

0_{hex} to FFFF_{hex}

-

Error Power Unit serial interface0_{hex}

A

BM_w_AmpHiperfaceError

1:1

-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®] 4100.

Error in module power unit serial interface.

Number	Meaning
6	Data overflow
7	Bit framing error
8	Invalid command state
9	Partition error
10	Checksum error
11	Invalid command code
12	Data number error
13	Invalid argument
14	Data field not writable
15	Incorrect access code
16	Data field is not changeable in its size
17	Word address outside of data field
18	Data field is nonexistent
36	Wrong data checksum
37	No answer
38 to 65	Reserved
66	Invalid answer

P0240	Fehler Funktionsmodul A	0_{hex} to FFFF_{hex}	
-	Error function module A	0_{hex}	
A	BM_w_SmallModuleErrorA	1:1	-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®]4100.

Error in function module A.

Sub-error No.	Meaning	Reaction
0	Reserved	
1	Module not recognized	No reaction
2	Module not permitted at this position	No reaction
3	24 V missing or output short-circuited	No reaction
4	Invalid target parameter value due to digital input	No reaction
5	Direct PLC-I/O access for this module not permitted.	No reaction
6	The necessary module is missing	IS
7	Module in controller not permitted	IS
8 to 15	not assigned = 0	

P0241	Fehler Funktionsmodul B	0_{hex} to FFFF_{hex}	
-	Error function module B	0_{hex}	
A	BM_w_SmallModuleErrorB	1:1	-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®]4100.

Error in function module B.

Sub-error description see [▶P0240◀](#) on page 108.

P0242	Fehler Funktionsmodul C	0_{hex} to FFFF_{hex}	
-	Error function module C	0_{hex}	
A	BM_w_SmallModuleErrorC	1:1	-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®] 4100.

Error in function module C.

Sub-error description see [▶P0240◀](#) on page 108.

P0243	Fehler Funktionsmodul D	0_{hex} to FFFF_{hex}
-	Error function module D	0_{hex}
A	BM_w_SmallModuleErrorD	1:1 -

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®] 4100.

Error in function module D.

Sub-error description see [▶P0240◀](#) on page 108.

P0244	Fehler Funktionsmodul E	0_{hex} to FFFF_{hex}
-	Error function module E	0_{hex}
A	BM_w_SmallModuleErrorE	1:1 -

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®] 4100.

Error in function module E.

Sub-error description see [▶P0240◀](#) on page 108.

P0245	Fehler Optionsmodul G	0_{hex} to FFFF_{hex}
-	Error option module G	0_{hex}
A	BM_w_BigModuleErrorG	1:1 -

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®] 4100.

Error in option module G.

Sub-Error No.	Meaning	Reaction
4096	Wrong parameter No. at setpoint parameter 1	No reaction
4097	Wrong parameter No. at setpoint parameter 2	No reaction
4098	Wrong parameter No. at setpoint parameter 3	No reaction
4099	Wrong parameter No. at setpoint parameter 4	No reaction
4100	Wrong parameter No. at setpoint parameter 5	No reaction
4101	Wrong parameter No. at setpoint parameter 6	No reaction
4102	Wrong parameter No. at setpoint parameter 7	No reaction
4103	Wrong parameter No. at setpoint parameter 8	No reaction
4104	Wrong parameter No. at setpoint parameter 9	No reaction
4105	Wrong parameter No. at setpoint parameter 10	No reaction
4106	Wrong parameter No. at setpoint parameter 11	No reaction
4107	Wrong parameter No. at setpoint parameter 12	No reaction
4108	Wrong parameter No. at setpoint parameter 13	No reaction
4109	Wrong parameter No. at setpoint parameter 14	No reaction
4110	Wrong parameter No. at setpoint parameter 15	No reaction

7.3 Parameter description

Sub-Error No.	Meaning	Reaction
4111	Wrong parameter No. at setpoint parameter 16	No reaction
4112	Wrong parameter No. at actual value parameter 1	No reaction
4113	Wrong parameter No. at actual value parameter 2	No reaction
4114	Wrong parameter No. at actual value parameter 3	No reaction
4115	Wrong parameter No. at actual value parameter 4	No reaction
4116	Wrong parameter No. at actual value parameter 5	No reaction
4117	Wrong parameter No. at actual value parameter 6	No reaction
4118	Wrong parameter No. at actual value parameter 7	No reaction
4119	Wrong parameter No. at actual value parameter 8	No reaction
4120	Wrong parameter No. at actual value parameter 9	No reaction
4121	Wrong parameter No. at actual value parameter 10	No reaction
4122	Wrong parameter No. at actual value parameter 11	No reaction
4123	Wrong parameter No. at actual value parameter 12	No reaction
4124	Wrong parameter No. at actual value parameter 13	No reaction
4125	Wrong parameter No. at actual value parameter 14	No reaction
4126	Wrong parameter No. at actual value parameter 15	No reaction
4127	Wrong parameter No. at actual value parameter 16	No reaction
4128	Invalid value at setpoint parameter No. 1	No reaction
4129	Invalid value at setpoint parameter No. 2	No reaction
4130	Invalid value at setpoint parameter No. 3	No reaction
4131	Invalid value at setpoint parameter No. 4	No reaction
4132	Invalid value at setpoint parameter No. 5	No reaction
4133	Invalid value at setpoint parameter No. 6	No reaction
4134	Invalid value at setpoint parameter No. 7	No reaction
4135	Invalid value at setpoint parameter No. 8	No reaction
4136	Invalid value at setpoint parameter No. 9	No reaction
4137	Invalid value at setpoint parameter No. 10	No reaction
4138	Invalid value at setpoint parameter No. 11	No reaction
4139	Invalid value at setpoint parameter No. 12	No reaction
4140	Invalid value at setpoint parameter No. 13	No reaction
4141	Invalid value at setpoint parameter No. 14	No reaction
4142	Invalid value at setpoint parameter No. 15	No reaction
4143	Invalid value at setpoint parameter No. 16	No reaction
4144	Invalid value for setpoint period	No reaction
4145	Invalid value for actual value period	No reaction
4146	Wrong value for cycle offset setpoints	No reaction
4147	Wrong value for cycle offset actual values	No reaction
4148	BACI timeout at cyclic data	with P0298
4149	BACI timeout at service data	No reaction
4150	Checksum error during test	IS
4151	Ramp-up timeout when waiting for the Slave-Type or when waiting for the reset of Config-Pending-Flag	No reaction
4152	Invalid data transfer structure type	No reaction
4153	Internal error: Wrong BACI status	No reaction
4154	Access conflicts with slave at cyclic communication	No reaction

Sub-Error No.	Meaning	Reaction
4155	Error cyclic communication: Parameter value wrong	No reaction
4156	Error cyclic communication: Alive-counter conflict	No reaction
4157	Cmd interface: Channel number wrong (0 or > 6)	No reaction
4158	Cmd interface: The channel which was indicated does not exist	No reaction
4159	Cmd interface: Internal error - wrong pointer	No reaction
4160	Cmd interface: Internal error - wrong status	No reaction
4161	Cmd interface: Wrong package number	No reaction
4162	Cmd interface: Wrong command number	No reaction
4163	Cmd interface: Wrong status when handling the package	No reaction
4164	Cmd interface: Timeout at command processing	No reaction
4165	Cmd interface: Wrong package length	No reaction
4166	Cmd interface: Descriptor not available	No reaction
4167	Cmd interface: Wrong package type	No reaction
4168	Cmd interface: Checksum error	No reaction
4169	Module identification: PCI-error when reading	No reaction
4170	Module identification: PCI-error when writing	No reaction
4171	Module identification: general Reading error	No reaction
4172	Module identification: general Error at writing	No reaction
4173	Internal error	No reaction
4174	Configuration cyclic services: Parameters are not cyclic writeable	No reaction
4175	Configuration cyclic services: Invalid parameter number	No reaction
4176	Wrong option module error code	No reaction
4177 to 8191	Reserved	
8192	Error CANopen timeout on CAN bus	set with P1007

P0246

Fehler Optionsmodul H

0_{hex} to FFFF_{hex}

-

Error in option module H0_{hex}

A

BM_w_BigModuleErrorH

1:1

-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®] 4100.

Error in option module H.

Sub-error description see [P0245](#) on page 109.

P0251

Fehler-Parameter ID Proprog-Zugriff

0 to 65535

-

Error communication parameter No.

0

A

BM_u_ProprogCmdErrId

1:1

-

Number of parameter, where an error occurred during the last protocol access (Win-BASS/ProDrive).

7.3 Parameter description

P0260

Warnungen System 1

0_{hex} to FFFF_{hex}

-

Warning System 1

0_{hex}

A

BM_w_SysWarning1

1:1

-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®]4100.

Bit No.	Meaning	Following parameters
0	Warning in module feed unit	▶P0261◀
1	Warning in module power unit	▶P0262◀
15 ... 2	not assigned = 0	

P0261

Warnungen Netzeinspeisung

0_{hex} to FFFF_{hex}

-

Warning PSU

0_{hex}

A

BM_w_PSU_Warning

1:1

-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®]4100.

Bit No.	Meaning	Warning No.
0	Reserved warning	0
1	Undervoltage 24V	1
2	Mains undervoltage	2
3	Mains overvoltage	3
4	Power failure	4
5	Phase failure	5
6	Phase sequence identification	6
7	Frequency change	7
8	Frequency range	8
9	Mains connections	9
10	Precharge is running	10
11	Undervoltage U _{DC}	11
12	Synchronization	12
13	Exceeding the set power limit	13
15 ... 14	not assigned = 0	14 to 15

P0262	Warnungen Leistungsteil	0_{hex} to FFFF_{hex}	
-	Warning Power Unit	0_{hex}	
A	BM_w_AmpWarning	1:1	-

Procedures for troubleshooting and for additional information see chapter „Troubleshooting“ in the manual b maXX[®]4100.

Bit No.	Meaning	Warning No.
0	Inside temperature of device	16
1	Heatsink temperature	17
6 ... 2	not assigned = 0	18 to 22
7	Undervoltage DC-link	23
8	Ixt-threshold 1 is exceeded	24
15 ... 9	not assigned = 0	25 to 31

P0290	Client-Überwachungs-Timeout	0 to 65535 ms	
EE	Client alive timeout	2000 ms	
ON	BM_u_ClientAliveTimeout	1:1 ms	-

This parameter is for the setting of the connection monitoring between WinBASS II/ProDrive and the controller. This allows the controller to guide the drive at interrupted communication into a safe status.

If the value is zero no connection monitoring operates.

The controller checks the maximum time between two telegrams. If there is a telegram failure the controller signals an error. The error reaction is to be set via error reaction [▶P1007◀](#).

This mechanism is implemented not before controller firmware version 3.01 and WinBASS Version 1.08 or ProDrive.

P0291	Empfangstimeout Proprog Protokoll	300 to 65535 ms	
EE	Receive timeout proprog protocol	500 ms	
ON	BM_u_ProprogCharTimeout	1:1 ms	-

This parameter determines the maximum value of the time which may elapse between two sequently signs of a telegram before the controller signals a communication error and synchronizes anew.

Deviations from the standard value are only then technical efficient if the according settings of the value timeout have been made in the connection settings of WinBASS II/ProDrive or PROPROG wt, in order to, for example, allow protocol processing for modem operation.

P0298	Fehlerreaktion für BACI-Kommunikation	-1 to 3	
EE	Error reaction BACI communication	-1	
ON	BM_i_ErrReactionBaci	1:1	-

Reaction of the controller at abort of the cyclic setpoint transmission over the BACI. Reaction code see table:

Reaction code	Meaning
-1	No reaction
0	Pulse disable
1	Stop. ramp down at the ramp function generator ramp (BM_u_Ds0_RFG1RampDownTime - ▶P1173◀)
2	Quickstop ramp down at the quickstop ramp (BM_u_Ds0_RFG1StopTime - ▶P1175◀)
3	Stop. Ramp down at the current limit

The monitoring of the cyclic BACI-setpoint transmission starts after the first error-free transmission. If due to the parameter timeout for cyclic BACI communication [▶P0839◀](#) determined monitoring time the controller does not receive any new setpoints, from this starting point on, then the controller signals the error „BACI timeout at cycl. data“ - error code 4148 in parameter [▶P0245◀](#) on page 109.

P0300	Steuerwort	0_{hex} to FFFF_{hex}	
EE	Control word	0_{hex}	
ON	BM_w_Control word	1:1	CW

See also [▶Drive management◀](#) from page 70.

This parameter is the input word used in the status machine of the device control.

Bit No.	Meaning
0	1: Command "switch on" 0: Command "shut down"
1 ¹⁾	1: Command „inhibit no voltage“ (operating status) 0: Command "inhibit voltage"
2	Reserved
3	1: Command "operation enabled" 0: Command „inhibit operation“
4	Depending on operation mode: Ramp function generator inhibit, start homing, new setpoint
5	Depending on operation mode: RFG-stop, set homing position, immediately change set
6	Depending on operation mode: RFG zero, absolute/relative target input
7	0 -> 1 reset error
15 ... 8	Reserved

¹⁾ These bits are **low active**.

Description of bits

- Bit 0 to 3
Control of drive status machine.
The device control commands are defined with the following bit combinations:

Command	Bit 7 Reset ERROR	Bit 3 Operation enabled	Bit 2 Quickstop ¹⁾	Bit 1 Inhibit volt- age ¹⁾	Bit 0 Switch on	Transitions
Close down	X	X	1	1	0	2,6,7
Switch on	X	X	1	1	1	4
Inhibit voltage	X	X	X	0	X	8, 9
Reset error	0 → 1	X	X	X	X	11

The bits which are marked with X are of no significance for the accordant command.

¹⁾ These bits are **low active**.

- Bit 4 - inhibit RFG
 - U_{DC} control (operating mode -3)
 - 1: Inhibit ramp function generator (output on 0)
 - 0: Enable ramp function generator (enable output)
- Bit 5 - RFG stop
 - U_{DC} control (operating mode -3)
 - 1: Ramp function generator inhibit ramp-up, freeze output
 - 0: Ramp function generator enable ramp-up
- Bit 6 - RFG zero
 - U_{DC} control (operating mode -3)
 - 1: Set ramp function generator input to zero (braking with ramp)
 - 0: Ramp function generator enable input
- Bit 7: device control command „reset errors“.
 - For the command is a change from 0 to 1 in this bit necessary.

Control word total overview of all operating modes

Bit No.	Speed control -3 ²⁾
0	Switch on (status machine device control)
1	Inhibit voltage (status machine device control) ¹⁾
3	Operation enabled (status machine device control)
4	Inhibit RFG
5	RFG stop
6	X
7	Reset error (status machine device control)
8	X
9	X
10	X
11	X
12	X
13	X
14	X
15	X

The bits which are marked with X are reserved and are to be set from the control to 0.

¹⁾ These bits are **low active**.

²⁾ In the operating modes -3 and 4 the bits 4, 5 and 6 are prioritized as follows:
Bit 4 before bit 5 before bit 6

P0301

Statuswort

0_{hex} to FFFF_{hex}

-

Status word0_{hex}

A

BM_w_Status word

1:1

-

See also [▶Drive management◀](#) from page 70.

This parameter is the output word used in the status machine of the device control. Every 4 ms it is updated.

Bit No.	Meaning
0 ²⁾	1: Ready-to-start 0: Not ready-to-start
1 ²⁾	1: Switched on 0: Not ready-to-operate
2 ²⁾	1: Operation enabled 0: Operation inhibited
3 ²⁾	1: Error 0: No error
4 ¹⁾²⁾	1: Main contactor is switched on 0: Main contactor is switched off
5 ¹⁾	1: Regulated DC link voltage 0: Unregulated DC link voltage
6 ²⁾	1: INHIBIT START 0: No inhibit start
7	1: Warning 0: No warning
8	RFG stop
9	Remote
10	1: Setpoint reached 0: Setpoint not reached
11	1: Internal limit active 0: no internal limit active
12	Depending on operation mode
13	Depending on operation mode
15 ... 14	Parameterizable real time bits - see parameters ▶P1290◀ to ▶P1293◀

1) These bits are **low active**.

2) Display operational status of drive manager

Description of bits

- Bit 0 to bit 6
These bits show the status of the drive status machine.

Bit in status word					
Status of unit control	Bit 6 INHIBIT START	Bit 3 ERROR	Bit 2 OPERATION ENABLED	Bit 1 SWITCHED ON	Bit 0 Ready-to- start
NOT READY-TO-START	0	0	0	0	0
INHIBIT START	1	0	0	0	0
READY-TO-START	0	0	0	0	1
SWITCHED ON	0	0	0	1	1
OPERATION ENABLED	0	0	1	1	1
ERROR	0	1	0	0	0

- Bit 3 - error
The controller will set this bit, as soon as an error ([▶P0200◀](#) error system 1) is present, which will cause an error reaction of the drive. The bit remains set during the error reaction and under the status error. The bit is deleted only after the error has been successfully reset.
As soon as this bit is set, the error LED lights up.
- Bit 4: main contactor switched on
- Bit 5: unregulated DC link voltage
The bit is low-active and is deleted, if a mains error (but not mains failure) is detected and all IGBT are disabled. The bit is set again, if the mains error is detected no longer and the mains inverter is enabled again.
- Bit = 7 warning
The bit displays, if there is a warning or an error in the controller, which causes that there is no error reaction. This status is external recognizable due to the flashing of the error LED.
- Bit 8 - status ramp function generator stop
The bit displays that the high ramp generator has been stopped, that means that the output was frozen.
- Bit 9 - remote
The bit is set, if at the communication source [▶P1001◀](#) the control e. g. the access on the control word is controlled via BACI.
- Bit 10 - setpoint reached
The bit is set, if the U_{DC} controller deviation is less than the limit, which was set.
- Bit 11: internal limit active
The bit is set, if an internal limit is active, for example current limit. This bit is updated, independent on the device status.
Via parameter [▶P1008◀](#) mask for internal limits it is able to be determined which internal limits shall be displayed.

P0302	Steuerwort 2	0_{hex} to FFFF_{hex}	
EE	Control word 2	0_{hex}	
ON	BM_w_Control word 2	1:1	CW

See also [►Drive management◄](#) from page 70.

Second control word of drive manager.

Bit No.	Meaning
15 ... 0	Reserved

P0303	Statuswort 2	0_{hex} to FFFF_{hex}	
-	Status word 2	0_{hex}	
A	BM_w_Status word 2	1:1	-

See also [►Drive management◄](#) from page 70.

The status word 2 of the drive manager is assigned as follows:

Bit No.	Meaning	Corresponds to bit in parameter
7 ... 0	Reserved	-
8	Status of free digital input 1 in slot D 0: Input is set 1: Input is not set	►P0413◄ status of digital inputs in module slot D bit 0
15 ... 9	Reserved	-

P0304	Ist-Betriebsart	-7 to 6	
-	Operation mode actual	-3	
A	BM_i_OperationModeAct	1:1	-

This parameter displays the momentary active drive operation mode.

Value	Meaning
-3	U _{DC} -control

7.3 Parameter description

P0305	Antriebs-Status	0_{hex} to FFFF_{hex}
-	Drive status	0_{hex}
A	BM_w_DriveStatus	1:1 -

This parameter shows the current status of the drive.

See also [▶Drive management◀](#) from page 70.

Value (hex)	Meaning
0	Not ready-to-start
1	Inhibit start
2	Ready-to-start
3	Switched on
4	Operation enabled
A	Main contactor ready-to-start
C	Unregulated DC link voltage
F	Error

P0306	Status dig. inputs drive manager	0_{hex} to FFFF_{hex}
-	Status digital inputs drive manager	0_{hex}
A	BM_w_DI_StatusDrvControl	1:1 -

Display of the status of the digital inputs for drive control (quickstop FX 3-4 and pulse enable FX 3-5).

See also [▶Drive management◀](#) from page 70.

Bit No.	Meaning
0	1: Pulse enable input is closed 0: Pulse enable is open
1	1: Error reset input is closed 0: Error reset input is open
15 ... 2	Reserved

P0308	Statuswort 3	0_{hex} to FFFF_{hex}
EE	Status word 3	0_{hex}
ON	BM_w_Statusword 3	1:1 -

The status word 3 of the drive manager is assigned as follows:

Bit No.	Meaning
0	Two-level-controller 1 output 0: output inactive 1: output active
1	Two-level-controller 2 output 0: output inactive 1: output active
2 ... 15	Reserved

P0310	Datensatzverwaltung Kommando	0 to 32
EE	Data set command	0
ON	BM_i_RecordCommand	1:1 -

See [▷Data Set Management◀](#) from page 13.

By use of this parameter the commands for the data set management are defined.

Value	Meaning	▷P0314◀ Source data set	▷P0315◀ Target data set
0	Reset data set command		
1	Write all parameters from the valid data sets into EEPROM		
2	Read EEPROM completely		
3	Reset EEPROM completely		
4	Set standard values for active data set		
5	Set standard values for all generated data sets		
6	Generate data set <n>		Data set to be generated
7	Reset data set <n>		DS to be deleted
8	Copy data set <x> to data set <y>	Source data set	Target data set
9	Load data set <x> from EEPROM	DS in EEPROM	
10	Store data set <x> into EEPROM	DS in RAM = EEPROM	
11	Reserved		
12	Write all parameters of the valid data sets into the PSI		
13	Read PSI completely		
14	Reset PSI completely		
15 ... 32	Reserved		

7.3 Parameter description

P0311	Datensatzverwaltung Status	0 _{hex} to FFFF _{hex}
EE	Data set status	0
A	BM_w_RecordStatus	1:1 -

See [▶Data Set Management◀](#) from page 13.

This parameter displays the status of the last data set management command.

Return code	Meaning
00 _{hex}	No error
01 _{hex}	Write/read cycle in process
02 _{hex}	Invalid parameter number
03 _{hex}	Invalid data type
04 _{hex}	Value less than the minimum value
05 _{hex}	Value greater than the maximum value
06 _{hex}	Parameter is read-only
07 _{hex}	Parameter cannot be modified because of operating status
08 _{hex}	Incorrect parameter value
09 _{hex}	EEPROM header not existent or invalid
0A _{hex}	Invalid section in EEPROM
0B _{hex}	Invalid data in EEPROM
0C _{hex}	Checksum error during test
0D _{hex}	Writing error to EEPROM
0E _{hex}	EEPROM too small
0F _{hex}	Unidentified error
10 _{hex}	Incompatible parameter (-numbers)
11 _{hex}	Data set operation in the active operation status not permissible (RUN)
12 _{hex}	Selected data set has not been generated yet
13 _{hex}	Selected data set already exists - cannot be generated anymore
14 _{hex}	Wrong data set number (not equal 1 to 8)
15 _{hex}	Wrong data set source number
16 _{hex}	Wrong data set target number
17 _{hex}	No enable possible during data set switch-over
18 _{hex}	EEPROM is reset
19 _{hex}	Self-optimization parameters invalid → copying not permitted
1A _{hex}	PSI not plugged
1B _{hex}	PSI reset
1C _{hex}	PSI -data are not compatible (e. g. PSI data generated from BM3XXX).

Value	Meaning
0000 _{hex}	Command „reset data set management“ successfully completed
1001 _{hex}	„Write all parameters of valid data sets into EEPROM“ successfully completed
1002 _{hex}	„Completely read EEPROM“ successfully completed
1003 _{hex}	„Reset EEPROM completely“ successfully completed
1004 _{hex}	„Set standard values for active data set“ successfully completed
1005 _{hex}	„Make settings of standard values for entire data sets“ successfully completed
1006 _{hex}	„Create data set <n>“ successfully completed
1007 _{hex}	„Reset data set <n>“ successfully completed
1008 _{hex}	„Copy data set <x> to data set <y>“ successfully completed
1009 _{hex}	„Load data set <x> from EEPROM“ successfully completed
100A _{hex}	„Store data set <x> into EEPROM“ successfully completed
100B _{hex}	Reserved
100C _{hex}	„Write all parameters of the valid data sets into the PSI“ successfully completed
100D _{hex}	„Read PSI completely“ successfully completed
100E _{hex}	„Reset PSI completely“ successfully completed
1010 _{hex} to 1016 _{hex}	Reserved

P0312

Aktive Datensatznummer 1 to 8

- **Active data set number** 1

ON BM_u_ActiveDataSet 1:1 -

See [▶Data Set Management◀](#) from page 13.

Here, the number of the active data set is displayed. Writing to this parameter, in online mode causes an instant data set switch-over (certain status must be met anyway, see also [▶Switching to data set 1 to 8◀](#) from page 26).

P0313	Angelegte Datensätze	00 _{hex} to FF _{hex}	
-	Valid data sets	01 _{hex}	
A	BM_w_ValidDataSets	1:1	-

See [▶Data Set Management◀](#) from page 13.

Bit mask in order to show which of the eight data sets are existent in the controller, e.g. which data sets can be stored or read. A set bit signals an existent data set. A set bit signals a created data set.

Bit No.	Meaning
0	0: data set 1 is deleted 1: data set 1 existent
1	0: data set 2 is deleted 1: data set 2 existent
2	0: data set 3 is deleted 1: data set 3 existent
3	0: data set 4 is deleted 1: data set 4 existent
4	0: data set 5 is deleted 1: data set 5 existent
5	0: data set 6 is deleted 1: data set 6 existent
6	0: data set 7 is deleted 1: data set 7 existent
7	0: data set 8 is deleted 1: data set 8 existent
8 to 15	Reserved

P0314	Quell-Datensatz	0 to 8	
-	Data set source	0	
ON	BM_u_RecCmdSource	1:1	-

See [▶Data Set Management◀](#) from page 13.

Source data set number for data set operations. According to [▶P0310◀](#) data set command the data set source refers to the EEPROM (e. g. at read data set) or to the RAM (e. g. at write data set in EEPROM).

P0315	Ziel-Datensatz	0 to 8	
-	Data set target	1	
ON	BM_u_RecCmdTarget	1:1	-

See [▶Data Set Management◀](#) from page 13.

Target data set number for data set operations. The target data set refers, according to the [▶P0310◀](#) data set command either to a data set in the EEPROM or in the RAM.

P0316	Fehlerhafter Parameter	1 to max. Para No.
-	Error data set parameter No.	-
A	BM_u_RecCmdError	1:1 -

See [▶Data Set Management◀](#) from page 13.

Here, the number of the parameter is displayed, which has caused an error during memory access (read/write). If an error occurs during command processing, the command will not interrupt transferring, but will continue transferring with the next parameter. When multiple errors occur, only the last error will be displayed.

P0317	Anzahl Schreibvorgänge EEPROM	1 to 65535
-	EEPROM write count	
A	BM_u_EepromWriteCount	1:1 -

See [▶Data Set Management◀](#) from page 13.

Number of write counts in EEPROM. This counter will be incremented at each write access.

P0318	Anzahl Schreibvorgänge auf das PSI	1 to 65535
-	PSI write count	
A	BM_u_PsiWriteCount	1:1 -

Number of write counts to the PSI data memory. This counter is incremented each time a command that initiates memory access on the PSI is processed.

P0319	Parameternummer für PSI-Zugriff	1 to 65535
-	PSI parameter number	
A	BM_u_PsiParameterId	1:1 -

Auxiliary parameter for direct read-out of PSI parameters. The PSI parameter number indicates, which parameter (addressed via the number) is to be read-out directly from PSI.

P0320	PSI Array index	0 to 65535
-	PSI array index	
A	BM_u_PsiArrayIdx	1:1 -

Auxiliary parameter for direct read-out of PSI parameters. Array index for addressing arrays directly from the PSI.

Arrays can be read only element by element. On index-0 the array size can be read out.

P0321 Datenbreite PSI Parameter 0 to 65535

- **PSI parameter data width**

A BM_u_PsiDataSize 1:1 -

Feed back value for direct read-out of PSI parameters. Holds, in coded form, the data size of the read-back data from PSI.

Value	Meaning
0	16 bit
1	32 bit
2	String

P0322 PSI Parameterwert bis zu 32 Bit 0_{hex} to FFFFFFFF_{hex}

- **PSI parameter value (32 Bit)**

A BM_ud_PsiData32 1:1 -

Union for feed back values from data type: SINT, USINT, INT, UINT, DINT, UDINT, BYTE, WORD, DWORD. Leading bits are set to zero (cast).

P0323 PSI String-parameter 40 ASCII characters

- **PSI string parameter** ""

A BM_s_PsiDataString 1:1 -

Feed back parameters for strings under direct read access to PSI.

P0324 PSI data set selection 1 to 4

- **PSI data set selection**

A BM_u_PsiDatasetSelect 1:1 -

Data set selector for direct access on parameters in PSI.

P0325 Angelegte Datensätze im PSI 0 to 65535

- **PSI valid data sets**

A BM_w_ValidDataSets 1:1 -

Bit mask used to display the data held within the PSI

P0326 Betriebsart Datensatzverwaltung 0 to 65535

- **Data set manager mode**

A BM_w_DataSetMode 1:1 -

With these parameters you can select the operation mode for the data set manager.

Bit No.	Meaning
0	1: Automatic reading from PSI The data is automatically read at each new starting of the controller from the PSI.
1	1: Automatic writing The data of the PSI is automatically stored in the EEPROM of the controller.
15 ... 2	Reserved

P0327 Boot Datensatz 1 to 8

EE **Boot data set** 1

PO BM_u_BootDataset 1:1 -

Data set, which is activated after switching on of the device as start data set.

P0330 Stromregler Status 0_{hex} to FFFF_{hex}

- **Current controller status** 0_{hex}

A BM_w_CurrentCtrlStatus 1:1 -

Status of current controller (no functions implemented yet).

P0332 Stromregler Iq-Sollwert -200,00 to +200.00 %

- **Current Iq setpoint** 0.00 %

A BM_i_IqSetLimited 4000_{hex} :100 % -

Limited cross current setpoint.

Scaling: 100 % ↔ power unit maximum current ([▶P1241◀](#))

P0333 Stromregler Iq-Istwert -200,00 to +200.00 %

- **Current Iq actual value** 0.00 %

A BM_i_IqAct 4000_{hex} :100 % -

Display of cross current actual value.

Scaling: 100 % ↔ power unit maximum current ([▶P1241◀](#))

7.3 Parameter description

P0334	Stromregler Iq-Regler Ausgang	-200,00 to +200.00 %
-	Current Iq controller output	0.00 %
A	BM_i_CtrlOut_Uq	4000 _{hex} :100 %
	Display of cross voltage setpoint from cross current controller.	
	Scaling: 100 % ↔ power unit maximum current (▶P1241◀)	
P0335	Stromregler Id-Sollwert	-100.00 to +100.00 %
-	Current Id setpoint	0.00 %
A	BM_i_IdSetLimited	4000 _{hex} :100 %
	Limited direct-axis current setpoint.	
	Scaling: 100 % ↔ power unit maximum current (▶P1241◀)	
P0336	Stromregler Id-Istwert	-200,00 to +200.00 %
-	Current Id Actual value	0.00 %
A	BM_i_IdAct	4000 _{hex} :100 %
	Display of actual value of the magnetizing direct-axis current.	
	Scaling: 100 % ↔ power unit maximum current (▶P1241◀)	
P0337	Stromregler Id-Regler Ausgang	-200,00 to +200.00 %
-	Current Id controller output	0.00 %
A	BM_u_IdOut	4000 _{hex} :100 %
	Display of direct-axis voltage setpoint from direct-axis current controller.	
	Scaling: 100 % ↔ power unit maximum current (▶P1241◀)	
P0338	Spannung EMK-Sollwert	-200,00 to +200.00 %
-	Voltage EMF setpoint	0.00 %
A	BM_i_VemfSet	4000 _{hex} :100 %
	Display of torque generating voltage setpoint from EMF feed forward.	
	Scaling: 100 % ↔ Power unit DC link nominal voltage (▶P0020◀)/ $\sqrt{2}$	

P0339	Spannung Uq-Sollwert	-200,00 to +200.00 %
-	Voltage Vq setpoint	0.00 %
A	BM_i_VqSet	4000 _{hex} :100 % -

Effective cross voltage setpoint.

Scaling: 100 % ↔ Power unit DC link nominal voltage ([▶P0020◀](#))/ $\sqrt{2}$

P0340	Spannung Ud-Sollwert	-200,00 to +200.00 %
-	Voltage Vd setpoint	0.00 %
A	BM_i_VdSet	4000 _{hex} :100 % -

Effective direct axis voltage setpoint.

Scaling: 100 % ↔ Power unit DC link nominal voltage ([▶P0020◀](#))/ $\sqrt{2}$

P0341	Strom Phase U-Istwert	-200,00 to +200.00 %
-	Current phase U actual value	0.00 %
A	BM_i_IphaseU	4000 _{hex} :100 % -

Display of the current actual value of 'Phase U'.

Scaling: 100 % ↔ power unit maximum current ([▶P1241◀](#))

P0342	Strom Phase V-Istwert	-200,00 to +200.00 %
-	Current phase V actual value	0.00 %
A	BM_i_IphaseV	4000 _{hex} :100 % -

Display of 'phase V' current actual value.

Scaling: 100 % ↔ power unit maximum current ([▶P1241◀](#))

P0343	Scheinstrom-Istwert	-200,00 to +200.00 %
-	Apparent current actual value	0.00 %
A	BM_u_lamplitude	4000 _{hex} :100 % -

Display of apparent current in % (not yet implemented).

Scaling: 100 % ↔ power unit maximum current ([▶P1241◀](#))

P0410

Status der digitalen Eingänge in Modulschacht A 0_{hex} to FFFF_{hex}

- **Function module A: status digital input** 0_{hex}

A BM_w_DI_Status_SlotA 1:1 -

Display of channel conditions in module slot A.

Display is only valid, if a digital input/output module is plugged into the related slot.
In case no module is plugged, FFFF_{hex} is displayed.

Bit No.	Meaning
0	Status digital input 1 0: low 1: high
1	Status digital input 2 0: low 1: high
2	Status digital input 3 0: low 1: high
3	Status digital input 4 0: low 1: high
4	Status digital input 5 0: low 1: high
5	Status digital input 6 0: low 1: high
6	Status digital input 7 0: low 1: high
7	Status digital input 8 0: low 1: high
15 ... 8	Reserved

P0411

Status der digitalen Eingänge in Modulschacht B 0_{hex} to FFFF_{hex}

- **Function module B: status digital input** 0_{hex}

A BM_w_DI_Status_SlotB 1:1 -

Display of the status of the channels in module slot B.

Display is only valid, if a digital input/output module is plugged into the related slot.
In case no module is plugged, FFFF_{hex} is displayed.

Bit description see [▶P0410◀](#) on page 130.

P0412	Status der digitalen Eingänge in Modulschacht C	0_{hex} to FFFF_{hex}	
-	Function module C: status digital input	0_{hex}	
A	BM_w_DI_Status_SlotC	1:1	-
<p>Display of the status of the channels in module slot C.</p> <p>Display is only valid, if a digital input/output module is plugged into the related slot. In case no module is plugged, FFFF_{hex} is displayed.</p> <p>Bit description see ▶P0410◀ on page 130.</p>			
P0413	Status der digitalen Eingänge in Modulschacht D	0_{hex} to FFFF_{hex}	
-	Function module D: status digital input	0_{hex}	
A	BM_w_DI_Status_SlotD	1:1	-
<p>Display of the status of the channels in module slot D.</p> <p>Display is only valid, if a digital input/output module is plugged into the related slot. In case no module is plugged, FFFF_{hex} is displayed.</p> <p>Bit description see ▶P0410◀ on page 130.</p>			
P0414	Status der digitalen Eingänge in Modulschacht E	0_{hex} to FFFF_{hex}	
-	Function module E: status digital input	0_{hex}	
A	BM_w_DI_Status_SlotE	1:1	-
<p>Display of the status of the channels in module slot E.</p> <p>Display is only valid, if a digital input/output module is plugged into the related slot. In case no module is plugged, FFFF_{hex} is displayed.</p> <p>Bit description see ▶P0410◀ on page 130.</p>			

P0418 Status der digitalen Ausgänge in Modulschacht D 0_{hex} to FFFF_{hex}

- **Function module D: Status digital output** 0_{hex}

A BM_w_DO_Status_SlotD 1:1 -

Display of the status of the channels in module slot D.

The displayed information depends upon if a module with digital outputs is plugged in or not.

Bit No.	Meaning
0	Status digital output 1 0: low 1: high
1	Status digital output 2 0: low 1: high
2	Status digital output 3 0: low 1: high
3	Status digital output 4 0: low 1: high
4	Status digital output 5 0: low 1: high
5	Status digital output 6 0: low 1: high
6	Status digital output 7 0: low 1: high
7	Status digital output 8 0: low 1: high
15 ... 8	Reserved

P0419 Status der digitalen Ausgänge in Modulschacht E 0_{hex} to FFFF_{hex}

- **Function module E: Status digital output** 0_{hex}

A BM_w_DO_Status_SlotE 1:1 -

Display of the status of the channels in module slot E.

The displayed information depends upon if a module with digital outputs is plugged in or not.

Bit description see [▶P0418◀](#) on page 132.

P0420 Wert analoger Eingang 1 -100.00 to +100.00 %
 - **Analog input 1 actual value** 0.00 %
 A BM_i_AI1_Value 7FFF_{hex}:100% -

This parameter displays the respective actual input value considering the scaling.

P0421 Wert analoger Eingang 2 -100.00 to +100.00 %
 - **Analog input 2 actual value** 0.00 %
 A BM_i_AI2_Value 7FFF_{hex}:100% -

This parameter displays the respective actual input value considering the scaling.

P0430 Hochlaufgeber-Status 0_{hex} to FFFF_{hex}
 - **Ramp Function Generator status** 0_{hex}
 A BM_w_RFGStatus 1:1 -

Status of ramp function generator (RFG).

Bit No.	Meaning
3 ... 0	Reserved
4	1: RFG output is internally set to 0 (RFG_INHIBIT)
5	1: RFG is stopped on the ramp (HLG_STOP)
6	1: RFG input is internally set to set 0 (RFG_ZERO)
7	1: Quickstop ramp is active (RFG_SHALT)
8	1: Ramp-up is active
9	1: Ramp down is active
11 ... 10	Reserved
12	1: RFG output = RFG input (set reached)
15 ... 13	Reserved

Bit 12: Setpoint reached

The status bit „Setpoint reached“ is set, according to the meaning of the bits in the control word ([►P0300◄](#)) as follows:

Control word bits			Operation	Bit 12 RFG output = RFG input (setpoint reached)
6	5	4		
0	0	0	Normal	Ramp function generator is active, bit 12 is set, if the following is valid: Ramp function generator output - ramp function generator input <= Ramp function generator setpoint-reached-bandwidth
0	0	1	Inhibit RFG	Ramp function generator is active, bit 12 is set immediately. RFG output is set to 0-value.
0	1	0	RFG stop	Ramp function generator is deactivated. RFG output is frozen. Bit 12 is always FALSE.
1	0	0	RFG zero	Ramp function generator is active, bit 12 is set, if RFG output has reached value 0, i. e. the drive stands still.

P0440	Sollwertgenerator Modus	0_{hex} to FFFF_{hex}
EE	Setpoint generator mode	0_{hex}
	BM_w_SvgMode	1:1 -

See also [►Setpoint generator◄](#) from page 79.

Operation mode of setpoint generator.

Bit No.	Meaning
1 ... 0	000: Switched off 001: Ramp function generator input 1
15 ... 2	Reserved

P0441	SWG Zeit 1	0.001 to 65.535 s
EE	SVG time 1	1.000
	BM_u_SvgTime1	1000:1 s -

See also [►Setpoint generator◄](#) from page 79.

These parameters can be parameterized with values from 1 ms to 65 s. The setpoint generator has a cycle time of 16 ms. Therefore, only settings with a multiple of 16 ms are reasonable.

For these time values, the respective setpoints are switched onto the output of the setpoint generator.

P0443	SWG Zeit 2	0.001 to 65.535 s
EE	SVG time 2	1.000
	BM_u_SvgTime2	1000:1 s -

See also [►Setpoint generator◄](#) from page 79.

These parameters can be parameterized with values from 1 ms to 65 s. The setpoint generator has a cycle time of 16 ms. Therefore, only settings with a multiple of 16 ms are reasonable. For these time values, the respective setpoints are switched onto the output of the setpoint generator.

P0445	SWG Zeit 3	0.001 to 65.535 s
EE	SVG time 3	1.000
	BM_u_SvgTime3	1000:1 s -

See also [►Setpoint generator◄](#) from page 79.

These parameters can be parameterized with values from 1 ms to 65 s. The setpoint generator has a cycle time of 16 ms. Therefore, only settings with a multiple of 16 ms are reasonable. For these time values, the respective setpoints are switched onto the output of the setpoint generator.

P0447	SWG Zeit 4	0.001 to 65.535 s	
EE	SVG time 4	1.000	
	BM_u_SvgTime4	1000:1 s	-

See also [►Setpoint generator◄](#) from page 79.

These parameters can be parameterized with values from 1 ms to 65 s. The setpoint generator has a cycle time of 16 ms. Therefore, only settings with a multiple of 16 ms are reasonable. For these time values, the respective setpoints are switched onto the output of the setpoint generator.

P0449	Sollwertgenerator Ausgang	0 to 65535	
-	Setpoint generator output	600	
A	BM_i_SvgOutput	1:1	-

See also [►Setpoint generator◄](#) from page 79.

Output of setpoint generator.

P0480	Leistungsteil Status	0 _{hex} to FFFF _{hex}	
-	Power unit status	0 _{hex}	
A	BM_w_AmpStatus	1:1	-

Status messages from power unit.

Bit No.	Meaning
0	0: fan is controlled via the heatsink temperature of the power unit 1: fan is switched on with mains-on signal
7 ... 1	Reserved
8	1: there is no error message from the power unit.
9	Reserved
10	1: pulses are enabled, power unit is operating in the switching mode (monitoring signal from the power unit)
11	0: normal operation, no current reduction of I _{xt} -monitoring 1: I _{xt} via the limit value, current reduction in intervention, current reduction to 100 % I _{nominal}
12	0: fan is switched off 1: fan is switched on
13	0: 24 V is switched off 1: 24 V is o.k.
15 ... 14	Reserved

7.3 Parameter description

P0481	Leistungsteil Geräte-Innentemperatur-Istwert	0 to 125 °C	
-	Power unit internal device actual temperature	0 °C	
A	BM_u_AmpActAmbientTemp	1:1 °C	-
	Display of the power unit inside temperature of the device.		
P0482	Leistungsteil Kühlkörpertemperatur-Istwert	0 to 125 °C	
-	Power unit heatsink actual temperature	0 °C	
A	BM_u_AmpActHeatsinkTemp	1:1 °C	-
	Display of power unit heatsink temperature.		
P0484	Leistungsteil Uzk-Istwert	0 to 10290 V	
-	Power unit DC-link actual value	0 V	
A	BM_u_AmpActDCLinkVolt	4000 _{hex} :540 V	-
	Measured actual value of DC link voltage.		
P0485	Leistungsteil Ixt-Wert	0 to 400.0 %	
-	Power unit Ixt actual value	0.0 %	
A	BM_u_AmpAct_Ixt	2000 _{hex} :100 %	-
	This parameter shows the current Ixt value (computation result of an internal temperature model consisting of heatsink and IGBT) of the overload monitoring. At a value of 100 % the current limit occurs to the power unit nominal current. If the Ixt-value falls below 95 %, the current limit is set to power unit maximum current of the drive (▶P1241◀) again.		
P0487	PWM Modus Umschaltung	0.00 to 100.00 %	
EE	Switching PWM mode	100.00 %	
ON	BM_u_PWM_Mode	4000 _{hex} :100 %	CW
	(from FW 03.06)		
	With this parameter you select, from which modulation of the PWM the MRZM (modified space vector modulation) is activated. This parameter is settable from 0.00 to 100.00 %. A value of 0.00 % accords to zero voltage of the converter output (0.00 % modulation) and 100 % accord to 100 % modulation of PWM. From 80 % modulation on the switching losses with MRZM are reduced by on third, without increasing the switching current ripples compared with RZM (space vector modulation).		

P0490	Einspeiseeinheit Status	0_{hex} to FFFF_{hex}	
-	PSU status 3	0_{hex}	
A	BM_w_PSU_Status	1:1	-

Status messages from power supply (mains supply) unit.

Bit	Meaning
0	0: DC-link voltage is generated by the device from the mains. 1: DC-link voltage is provided by external supply.
7 ... 1	Reserved
8	1: message mains power failure
15 ... 9	Reserved

P0540	CAN Modus	0 to 1	
EE	CAN mode	0	
	BM_w_CAN_Mode	1:1	-
	Reserved.		

P0541	CAN Status	0_{hex} to FFFF_{hex}	
-	CAN status	0_{hex}	
A	BM_w_CAN_Status	1:1	-
	Reserved.		

P0542	CAN Baudrate (Konfig)	125 to 1000 kBit/s	
EE	CAN baud rate (config)	125 kBit/s	
	BM_u_CAN_BaudrateSet	1:1 kBit/s	-
	Reserved.		

P0543	CAN Baudrate (DIP-Schalter)	125 to 1000 kBit/s	
EE	CAN baud rate (DIP switch)	125 kBit/s	
A	BM_u_CAN_BaudrateDIP	1:1 kBit/s	-
	Reserved.		

7.3 Parameter description

P0544	CAN Baudrate (aktiv)	125 to 1000 kBit/s	
-	CAN baud rate (active)	125 kBit/s	
A	BM_u_CAN_BaudrateAct	1:1 kBit/s	-
	Reserved.		
P0545	CAN Slave Nummer (Konfig)	0 to 128	
EE	CAN slave number (config)	0	
	BM_u_CAN_SlaveNrSet	1:1	-
	Reserved.		
P0546	CAN Slave Nummer (DIP-Schalter)	0 to 128	
EE	CAN slave number (DIP-switch)	0	
A	BM_u_CAN_SlaveNrDIP	1:1	-
	Reserved.		
P0547	CAN Slave Nummer (aktiv)	0 to 128	
-	CAN slave number (active)	0	
A	BM_u_CAN_SlaveNrAct	1:1	-
	Reserved.		

P0550

Modultyp Steckplatz A

0_{hex} to FFFF_{hex}

-

Module type slot A0_{hex}

A

BM_w_ModSlotAIdent

1:1

-

Code of module in slot A.

Bit No.	Meaning
4 ... 0	Reserved
7 ... 5	Module version (see table ▶Page 140◀)
10 ... 8	Hardware version of modules 000: Development 001: Hardware-version A 002: Hardware-version B 003: Hardware-version C 004: Hardware-version D 005: Hardware-version E 006: Hardware-version F 007: Hardware-version G
15 ... 11	Module function (see bit bar ▶Page 139◀)

- Module functions P0550

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Module					Hardware status			Module-specific			Reserved				
15	14	13	12	11											
0	0	0	0	0	no module										
0	0	0	0	1	Reserved										
0	0	0	1	0	Reserved										
0	0	0	1	1	AIO-03			analog I/O, 12 bit D/A - 12 bit A/D							
0	0	1	0	0	Reserved										
0	0	1	0	1	DIO-01			digital I/O, 4 inputs, 4 outputs							
0	0	1	1	0	Reserved										
0	0	1	1	1	Reserved										
0	1	0	0	0	Reserved										
0	1	0	0	1	Reserved										
0	1	0	1	0	Reserved										
0	1	0	1	1	Reserved										
0	1	1	0	0	Reserved										
0	1	1	0	1	Reserved										
0	1	1	1	0	Reserved										
0	1	1	1	1	Reserved										
1	0	0	0	0	Reserved										
1	0	0	0	1	AIO-01			analog I/O, 8 bit D/A - 10 bit A/D							
1	0	0	1	0	SRM-01			monitoring signal for NWR* (standard slot B)							
1	0	0	1	1	Reserved										
1	0	1	0	0	Reserved										
1	0	1	0	1	FIO-01			digital I/O, 4 fast inputs 4 outputs							

7.3 Parameter description

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Module					Hardware status			Module-specific			Reserved				
1	0	1	1	0	UME-01 voltage access NWR * (standard slot A)										
1	0	1	1	1	Reserved										
1	1	0	0	0	Reserved										
1	1	0	0	1	AIO-02 analog I/O, 16 bit D/A - 16 bit A/D										
1	1	0	1	0	Reserved										
1	1	0	1	1	Reserved										
1	1	1	0	0	Reserved										
1	1	1	0	1	Reserved										
1	1	1	1	0	Reserved										
1	1	1	1	1	SEA-01 main contactor control for NWR * (standard slot C)										

*) NWR: Mains inverter

- Module-specific meaning of bit 7 ... 5

Examples:

Module		Value P0550
AIO-01	Analog I/O, 8 bit D/A - 10 bit A/D	8800 _{hex}
AIO-02	Analog I/O, 16 bit D/A - 16 bit A/D	CBF0 _{hex}
AIO-03	Analog I/O, 12 bit D/A - 12 bit A/D	1A00 _{hex}
DIO-01	Digital I/O, 4 inputs, 4 outputs	2800 _{hex}
FIO-01	Digital I/O, 4 fast inputs 4 outputs	5800 _{hex}
UME-01	Mains voltage sensing	B000 _{hex}
SEA-01	Control of the main contactor	F800 _{hex}
SRM-01	Monitoring signal of the main contactor	9000 _{hex}

P0551

Modultyp Steckplatz B

0_{hex} to FFFF_{hex}

-

Module type slot B

0_{hex}

A

BM_w_ModSlotBIdent

1:1

-

Code of module in slot B.

Description see [▶P0550◀](#) on page 139.

P0552

Modultyp Steckplatz C

0_{hex} to FFFF_{hex}

-

Module type slot C

0_{hex}

A

BM_w_ModSlotCIdent

1:1

-

Code of module in slot C.

Description see [▶P0550◀](#) on page 139.

P0553	Modultyp Steckplatz D	0_{hex} to FFFF_{hex}	
-	Module type slot D	0_{hex}	
A	BM_w_ModSlotDIdent	1:1	-
	Code of module in slot D.		
	Description see ▶P0550◀ on page 139.		
P0554	Modultyp Steckplatz E	0_{hex} to FFFF_{hex}	
-	Module type slot E	0_{hex}	
A	BM_w_ModSlotEIdent	1:1	-
	Code of module in slot E.		
	Description see ▶P0550◀ on page 139.		
P0555	FPGA-Version	0_{hex} to FFFF_{hex}	
-	FPGA version	0	
A	BM_w_FpgaVersion	1:1	-
	Firmware version of programmable logic module situated in the controller.		
P0556	Bootloader-Firmware-Version	0 to 65535	
-	Bootloader firmware version	0	
A	BM_u_BootloaderVersion	1:1	-
	Firmware version of bootstrap loader.		
P0557	Programmier-Anforderung	0 to 1	
-	Programming request	0	
ON	BM_w_ProgRequest	1:1	-
	Special parameter to start a firmware update over WinBASS II/ProDrive.		
P0558	Konfigurations-Identifikationsnummer	0 to 4294967295	
EE	Configuration ID	0	
ON	BM_ud_ConfigId	1:1	-
	This parameter acts as a storage of an item number or similar in the controller. The value is not processed by the controller, but is stored in the central data during storage of data sets.		

P0559	Gerätename	80 ASCII characters
EE	Drive name	""
ON	BM_s_DriveName	1:1 -

This parameter serves for the storage of an device name for example for the system configuration. The string is not evaluated by the controller, but stored during storage of data sets.

P0575	Digitaler Input-Kanal für Fehlerquittierung	0 _{hex} to FFFF _{hex}
EE	Digital input channel for error acknowledge	0 _{hex}
	BM_w_DI_AckErrInpChannel	1:1 -

Slot and channel select of digital inputs, which will be used to reset drive error messages.

Bit No.	Meaning
7 ... 0	Channel selection (possible value 1 to 8, depending on function module)
15 ... 8	Selection of input module slot (possible values 1 to 5, corresponding to slot A to E)

Value 0 means that no input channel is selected. Resetting of errors by use of a digital input is deactivated then.

Example:

►P0575◄ = 0502_{hex}; That means digital input for error reset is connected with pin 2 in the slot E (= 5) of the input module.

P0579	Funktionsmodul-Auswahl für PLC-I/O-Zugriffe	0 _{hex} to 1F _{hex}
EE	Function module selection for PLC I/O-access	0 _{hex}
PO	BM_w_PlcModSelect	1:1 -

Selection of, which digital- or analog-I/O function module can trigger the PLC direct-reading/or writing. In principle an access of the PLC on other function module types (e. g. touch probe, ...) is not possible.

Bit No.	Meaning
0	Function module slot A 0: access by PLC not permitted 1: access by PLC permitted
1	Function module slot B 0: access by PLC not permitted 1: access by PLC permitted
2	Function module slot C 0: access by PLC not permitted 1: access by PLC permitted
3	Function module slot D 0: access by PLC not permitted 1: access by PLC permitted
4	Function module slot E 0: access by PLC not permitted 1: access by PLC permitted
5 to 15	Reserved

The directly access on I/Os of the controller are only possible by controllers with special FPGA version.

7.3 Parameter description

P0800 Optionsmodul 1 Master Zykluszeit 0 to 32000 µs

EE **Option module 1 master cycle time** 4000 µs

PO BM_u_Baci1M1Period 1:125 µs -

This parameter is accepted after switching on, it also can be changed by the option module, but then it only acts as display.

This parameter specifies with which cycle time the new set-/actual values are transmitted. The value refers to a multiple of 125 µs.

Value	Meaning
0	no cyclic data exchange
1	not permissible
2	250 µs
3	375 µs
and so on	

P0801 Optionsmodul 1 Master 1 Para-Nummer Sollwert 1 0_{hex} to FFFF_{hex}

EE **Option module 1 master 1 parameter no. setpoint 1** 0_{hex}

PO BM_u_Baci1M1SetVal1 1:1 -

Configuration for the selected option module by parameter option module selection ([▶P0827◀](#)).

Parameter of the first setpoint (1 ... 8) for the cyclic communication. Only the numbers of the parameters may be specified, which are cyclic writeable (attribute CW).

This parameter is accepted after switching on, it also can be changed by the option module, but then it only serves as display.

P0802 Optionsmodul 1 Master 1 Para-Nummer Sollwert 2 0_{hex} to FFFF_{hex}

EE **Option module 1 master 1 parameter no. setpoint 2** 0_{hex}

PO BM_u_Baci1M1SetVal2 1:1 -

2nd setpoint. Description of the parameters see [▶P0801◀](#) on page 144.

P0803 Optionsmodul 1 Master 1 Para-Nummer Sollwert 3 0_{hex} to FFFF_{hex}

EE **Option module 1 master 1 parameter no. setpoint 3** 0_{hex}

PO BM_u_Baci1M1SetVal3 1:1 -

3rd setpoint. Description of the parameters see [▶P0801◀](#) on page 144.

P0804	Optionsmodul 1 Master 1 Para-Nummer Sollwert 4	0_{hex} to FFFF_{hex}	
EE	Option module 1 master 1 parameter no. setpoint 4	0_{hex}	
PO	BM_u_Baci1M1SetVal4	1:1	-
	4th setpoint. Description of the parameters see ▶P0801◀ on page 144.		
P0805	Optionsmodul 1 Master 1 Para-Nummer Sollwert 5	0_{hex} to FFFF_{hex}	
EE	Option module 1 master 1 parameter no. setpoint 5	0_{hex}	
PO	BM_u_Baci1M1SetVal5	1:1	-
	5th setpoint. Description of the parameters see ▶P0801◀ on page 144.		
P0806	Optionsmodul 1 Master 1 Para-Nummer Sollwert 6	0_{hex} to FFFF_{hex}	
EE	Option module 1 master 1 parameter no. setpoint 6	0_{hex}	
PO	BM_u_Baci1M1SetVal6	1:1	-
	6th setpoint. Description of the parameters see ▶P0801◀ on page 144.		
P0807	Optionsmodul 1 Master 1 Para-Nummer Sollwert 7	0_{hex} to FFFF_{hex}	
EE	Option module 1 master 1 parameter no. setpoint 7	0_{hex}	
PO	BM_u_Baci1M1SetVal7	1:1	-
	7th setpoint. Description of the parameters see ▶P0801◀ on page 144.		
P0808	Optionsmodul 1 Master 1 Para-Nummer Sollwert 8	0_{hex} to FFFF_{hex}	
EE	Option module 1 master 1 parameter no. setpoint 8	0_{hex}	
PO	BM_u_Baci1M1SetVal8	1:1	-
	8th setpoint. Description of the parameters see ▶P0801◀ on page 144.		
P0809	Optionsmodul 1 Master 1 Para-Nummer Istwert 1	0_{hex} to FFFF_{hex}	
EE	Option module 1 master 1 parameter no. act value 1	0_{hex}	
PO	BM_u_Baci1M1ActVal1	1:1	-
	Configuration for the selected option module by parameter option module selection (▶P0827◀).		
	Parameter of the actual values (1 ... 8) for the cyclic communication. The parameter specified by the number must be data type INT, UINT, DINT, UDINT, WORD or DWORD.		

7.3 Parameter description

This parameter is accepted after switching on, it also can be changed by the option module, but then it only serves as display.

P0810 Optionsmodul 1 Master 1 Para-Nummer Istwert 2 0_{hex} to FFFF_{hex}
EE **Option module 1 master 1 parameter no. act value 2** 0_{hex}
PO BM_u_Baci1M1ActVal2 1:1 -
2nd actual value Description of the parameters see [▶P0809◀](#) on page 145.

P0811 Optionsmodul 1 Master 1 Para-Nummer Istwert 3 0_{hex} to FFFF_{hex}
EE **Option module 1 master 1 parameter no. act value 3** 0_{hex}
PO BM_u_Baci1M1ActVal3 1:1 -
3rd actual value Description of the parameters see [▶P0809◀](#) on page 145.

P0812 Optionsmodul 1 Master 1 Para-Nummer Istwert 4 0_{hex} to FFFF_{hex}
EE **Option module 1 master 1 parameter no. act value 4** 0_{hex}
PO BM_u_Baci1M1ActVal4 1:1 -
4th actual value Description of the parameters see [▶P0809◀](#) on page 145.

P0813 Optionsmodul 1 Master 1 Para-Nummer Istwert 5 0_{hex} to FFFF_{hex}
EE **Option module 1 master 1 parameter no. act value 5** 0_{hex}
PO BM_u_Baci1M1ActVal5 1:1 -
5th actual value Description of the parameters see [▶P0809◀](#) on page 145.

P0814 Optionsmodul 1 Master 1 Para-Nummer Istwert 6 0_{hex} to FFFF_{hex}
EE **Option module 1 master 1 parameter no. act value 6** 0_{hex}
PO BM_u_Baci1M1ActVal6 1:1 -
6th actual value Description of the parameters see [▶P0809◀](#) on page 145.

P0815 Optionsmodul 1 Master 1 Para-Nummer Istwert 7 0_{hex} to FFFF_{hex}
EE **Option module 1 master 1 parameter no. act value 7** $0_{\text{hex}}0$
PO BM_u_Baci1M1ActVal7 1:1 -
7th actual value Description of the parameters see [▶P0809◀](#) on page 145.

P0816	Optionsmodul 1 Master 1 Para-Nummer Istwert 8	0_{hex} to FFFF_{hex}	
EE	Option module 1 master 1 parameter no. act value 8	0_{hex}	
PO	BM_u_Baci1M1ActVal8	1:1	-
	8th actual value Description of the parameters see ▶P0809◀ on page 145.		
P0817	Optionsmodul 1 Master 1 Trigger-Offset	0_{hex} to FFFF_{hex}	
EE	Option module 1 master 1 trigger offset	0_{hex}	
PO	BM_u_Baci1M1TriggOffset	1:1	-
	Not yet implemented.		
P0818	Optionsmodul 1 Master 1 Zyklus-Offset Sollwerte	0_{hex} to FFFF_{hex}	
EE	Option module 1 master 1 cycle offset setpoints	2	
PO	BM_u_Baci1M1CycleSetOffset	1:1	-
	Configuration for the selected option module by parameter option module selection (▶P0827◀).		
	Cycle offset for setpoint transmission. Exact description see software module BACI.		
	This parameter is accepted after switching on, it also can be changed by the option module, but then it only serves as display.		
P0819	Optionsmodul 1 Master 1 Zyklus-Offset Istwerte	0_{hex} to FFFF_{hex}	
EE	Option module 1 master 1 cycle offset act. values	0_{hex}	
PO	BM_u_Baci1M1CycleActOffset	1:1	-
	Configuration for the selected option module by parameter option module selection (▶P0827◀).		
	Cycle offset for actual value transmission. Exact description see software module BACI.		
	This parameter is accepted after switching on, it also can be changed by the option module, but then it only serves as display.		
P0827	Optionsmodul Auswahl	0 to 6	
EE	Option module select	0	
PO	BM_u_BaciModuleSelect	1:1	-
	The controller only evaluates this parameter after the switching off/switching on of the system.		

7.3 Parameter description

The controller has two separate configuration parameter blocks:

- BACI1-master1-parameters (▶P0800◀ to ▶P0819◀) and
- BACI2-master1-parameters (▶P0860◀ to ▶P0879◀)

This parameter acts as an allocation between option module slot and one or both BACI configuration parameter blocks according to the following table:

Value	Slave G	Slave H	Allocation of the BACI configuration parameters
0	X	-	P0800 to P0819 are valid for the slave on slot G
	-	X	P0800 to P0819 are valid for the slave on slot H
	X	X	P0800 to P0819 are valid for the slave on slot G P0860 to P0879 are valid for the slave on slot H
1	X	-	P0800 to P0819 are valid for the slave on slot G
	-	X	P0860 to P0879 are valid for the slave on slot H
	X	X	P0800 to P0819 are valid for the slave on slot G P0860 to P0879 are valid for the slave on slot H
2	X	-	P0860 to P0879 are valid for the slave on slot G
	-	X	P0800 to P0819 are valid for the slave on slot H
	X	X	P0860 to P0879 are valid for the slave on slot G P0800 to P0819 are valid for the slave on slot H
3 to 65535			Reserved

P0830

Optionsmodul G Konfiguration 1

0_{hex} to FFFF_{hex}

EE

Option module G configuration 1

0_{hex}

PO

BM_w_BaciSlaveGConfig1

1:1

-

First word for the software module configuration of the option module on slot G. The meaning of the parameter is module-dependent.

- Option module CANSync

CAN-Mapping for setpoint 1

Bit No.	Meaning
0	Validity 0: setpoint is not used 1: setpoint is used
2 ... 1	Position in set- or actual value telegram 00: setpoint begins with WORD 0 01: setpoint begins with WORD 1 10: setpoint begins with WORD 3 11: setpoint begins with WORD 4 (for WORD-format only)
5 ... 3	Set- or actual value telegram No. 000: telegram 1 001: telegram 2 010: reserved to 111: reserved

Bit No.	Meaning
6	Format 0: setpoint has WORD-format (16 bit) 1: setpoint has DWORD-format (32 bit)
7	Setpoint/actual value telegram 0: setpoint is in setpoint telegram 1: setpoint is in actual value telegram of slave No. (see bits 8 to 12)
12 ... 8	Slave No., if setpoint from actual value telegram 00000: slave 0 00001: slave 1 to 11111: slave 31
15 ... 13	Reserved

P0831	Optionsmodul G Konfiguration 2	0_{hex} to FFFF_{hex}
EE	Option module G configuration 2	0_{hex}
PO	BM_w_BaciSlaveGConfig2	1:1 -

Second word acts as software module configuration of the option module on slot G. The meaning of the parameter is module-dependent.

- CANsync: CAN-Mapping for setpoint 2.

Bit-assignment see [▶P0830◀](#) on page 148.

P0832	Optionsmodul G Konfiguration 3	0_{hex} to FFFF_{hex}
EE	Option module G configuration 3	0_{hex}
PO	BM_w_BaciSlaveGConfig3	1:1 -

Third word acts as software module configuration of the option module on slot G. The meaning of the parameter is module-dependent.

- CANsync: CAN-Mapping for setpoint 3.

Bit-assignment see [▶P0830◀](#) on page 148.

P0833	Optionsmodul G Konfiguration 4	0_{hex} to FFFF_{hex}
EE	Option module G configuration 4	0_{hex}
PO	BM_w_BaciSlaveGConfig4	1:1 -

Fourth word acts as software module configuration of the optional module on slot G. The meaning of the parameter is module-dependent.

- CANsync: CAN-Mapping for setpoint 4.

Bit-assignment see [▶P0830◀](#) on page 148.

P0834	Optionsmodul G Konfiguration 5	0_{hex} to FFFF_{hex}
EE	Option module G configuration 5	0_{hex}
PO	BM_w_BaciSlaveGConfig5	1:1 -

Fifth word acts as software module configuration of the option module on slot G. The meaning of the parameter is module-dependent.

- CANsync: CAN-Mapping for actual value 1

Bit No.	Meaning
0	Validity 0: actual value is not used 1: actual value is used
2 ... 1	Position in actual value telegram 00: actual value begins with WORD 0 01: actual value begins with WORD 1 10: actual value begins with WORD 3 11: actual value begins with WORD 4 (for WORD-format only)
4 ... 3	Actual value telegram No. 00: telegram 1 01: telegram 2 10: reserved 11: reserved
5	Reserved
6	Format 0: actual value has WORD-format (16 bit) 1: actual value has DWORD-format (32 bit)
7 ... 15	Reserved

P0835	Optionsmodul G Konfiguration 6	0_{hex} to FFFF_{hex}
EE	Option module G configuration 6	0_{hex}
PO	BM_w_BaciSlaveGConfig6	1:1 -

Sixth word acts as software module configuration of the option module on slot G. The meaning of the parameter is module-dependent.

- CANsync: CAN-Mapping for actual value 2.

Bit-assignment see [▶P0834◀](#) on page 150.

P0836	Optionsmodul G Konfiguration 7	0_{hex} to FFFF_{hex}
EE	Option module G configuration 7	0_{hex}
PO	BM_w_BaciSlaveGConfig7	1:1 -

Seventh word acts as software module configuration of the option module on slot G. The meaning of the parameter is module-dependent.

- CANsync: CAN-Mapping for actual value 3.

Bit-assignment see [▶P0834◀](#) on page 150.

P0837	Optionsmodul G Konfiguration 8	0_{hex} to FFFF_{hex}
EE	Option module G configuration 8	0_{hex}
PO	BM_w_BaciSlaveGConfig8	1:1 -
	Eighth word acts as software module configuration of the option module on slot G. The meaning of the parameter is module-dependent.	
	<ul style="list-style-type: none"> • CANsync: CAN-Mapping for actual value 4 	
	Bit-assignment see ▶P0834◀ on page 150.	
P0838	Timeout Hochlaufphase der BACI-Initialisierung	0 to 65535 s
EE	BACI Setup Timeout	60 s
PO	BM_u_BaciSetupTimeout	1:1 s -
	Timeout value for the time-monitoring of the configuration phase after a system-starting.	
P0839	Timeout für zyklische BACI-Kommunikation	0 to 65535 ms
EE	BACI cyclic communication timeout	50 ms
PO	BM_u_BaciCyclicTimeout	1:1 ms -
	Timeout value for the time monitoring of the cyclic communication in the running operation.	
	The controller monitors the cyclic communication over a timeout mechanism. A timeout-counter starts at the first successful cyclic setpoint transmission. Every further successful cyclic setpoint transmission retriggers this time counter .	
	Parameter error reaction BACI communication (▶P0298◀ on page 114) acts as the setting of the according error reaction.	
P0840	Optionsmodul H Konfiguration 1	0_{hex} to FFFF_{hex}
EE	Option module H configuration 1	0_{hex}
PO	BM_w_BaciSlaveHConfig1	1:1 -
	First word acts as software module configuration of the optional module on slot H. The meaning of the parameter is module-dependent see parameter ▶P0830◀ on page 148.	
P0841	Optionsmodul H Konfiguration 2	0_{hex} to FFFF_{hex}
EE	Option module H configuration 2	0_{hex}
PO	BM_w_BaciSlaveHConfig2	1:1 -
	Second word acts as software module configuration of the option module on slot H. The meaning of the parameter is module-dependent see parameter ▶P0831◀ on page 149.	

P0842	Optionsmodul H Konfiguration 3	0_{hex} to FFFF_{hex}
EE	Option module H configuration 3	0_{hex}
PO	BM_w_BaciSlaveHConfig3	1:1 -

Third word acts as software module configuration of the option module on slot H. The meaning of the parameter is module-dependent see parameter [▶P0832◀](#) on page 149.

P0843	Optionsmodul H Konfiguration 4	0_{hex} to FFFF_{hex}
EE	Option module H configuration 4	0_{hex}
PO	BM_w_BaciSlaveHConfig4	1:1 -

Fourth word acts as software module configuration of the option module on slot H. The meaning of the parameter is module-dependent see parameter [▶P0833◀](#) on page 149.

P0844	Optionsmodul H Konfiguration 5	0_{hex} to FFFF_{hex}
EE	Option module H configuration 5	0_{hex}
PO	BM_w_BaciSlaveHConfig5	1:1 -

Fifth word acts as software module configuration of the option module on slot H. The meaning of the parameter is module-dependent see parameter [▶P0834◀](#) on page 150.

P0845	Optionsmodul H Konfiguration 6	0_{hex} to FFFF_{hex}
EE	Option module H configuration 6	0_{hex}
PO	BM_w_BaciSlaveHConfig6	1:1 -

Sixth word acts as software module configuration of the option module on slot H. The meaning of the parameter is module-dependent see parameter [▶P0835◀](#) on page 150.

P0846	Optionsmodul H Konfiguration 7	0_{hex} to FFFF_{hex}
EE	Option module H configuration 7	0_{hex}
PO	BM_w_BaciSlaveHConfig7	1:1 -

Seventh word acts as software module configuration of the option module on slot H. The meaning of the parameter is module-dependent see parameter [▶P0836◀](#) on page 150.

P0847	Optionsmodul H Konfiguration 8	0 _{hex} to FFFF _{hex}
EE	Option module H configuration 8	0 _{hex}
PO	BM_w_BaciSlaveHConfig8	1:1 -

Eighth word acts as software module configuration of the option module on slot H. The meaning of the parameter is module-dependent see parameter [▶P0837◀](#) on page 151.

P0848	Baci Fehlermeldungsverzögerung	0 to 65535 s
EE	Baci error detection delay	30 s
PO	BM_w_BaciSlaveHConfig8	1:1 s -

The setup of a coupled system over the BACI extends up to an application-dependent duration. During this setup, especially as long as the total system is not yet working synchronous, error messages, which come from BACI, can be unwanted. This parameter determines the time in seconds, how long the controller suppresses error messages after initialization of BACI.

7.3 Parameter description

P0860	Optionsmodul 2 Master Zykluszeit	0 to 32000 µs	
EE	Option module 2 master cycle time	4000 µs	
PO	BM_u_Baci2M1Period	1:125 µs	-

This parameter is accepted after switching on, it also can be changed by the option module, but then it only acts as display.

This parameter specifies after which number of control cycles the new set-/actual values are transmitted. The value refers to a multiple of 125 µs.

Value	Meaning
0	no cyclic data exchange
1	not permissible
2	250 µs
3	375 µs
and so on	

P0861	Optionsmodul 2 Master 1 Para-Nummer Sollwert 1	0 _{hex} to FFFF _{hex}	
EE	Option module 2 master 1 parameter No. setpoint 1	0 _{hex}	
PO	BM_u_Baci2M1SetVal1	1:1	-

Configuration for the selected option module by parameter option module selection ([▶P0827◀](#)).

Parameter of the first setpoint (1 ... 8) for the cyclic communication. Only the numbers of the parameters may be specified, which are cyclic (attribute CW).

This parameter is accepted after switching on, it also can be changed by the option module, but then it only serves as display.

P0862	Optionsmodul 2 Master 1 Para-Nummer Sollwert 2	0 _{hex} to FFFF _{hex}	
EE	Option module 2 master 1 parameter No. setpoint 2	0 _{hex}	
PO	BM_u_Baci2M1SetVal2	1:1	-

2. Setpoint. Description of the parameters see [▶P0861◀](#) on page 154.

P0863	Optionsmodul 2 Master 1 Para-Nummer Sollwert 3	0 _{hex} to FFFF _{hex}	
EE	Option module 2 master 1 parameter No. setpoint 3	0 _{hex}	
PO	BM_u_Baci2M1SetVal3	1:1	-

3. Setpoint. Description of the parameters see [▶P0861◀](#) on page 154.

P0864	Optionsmodul 2 Master 1 Para-Nummer Sollwert 4	0_{hex} to FFFF_{hex}	
EE	Option module 2 master 1 parameter No. setpoint 4	0_{hex}	
PO	BM_u_Baci2M1SetVal4	1:1	-

4. Setpoint. Description of the parameters see [▶P0861◀](#) on page 154.

P0865	Optionsmodul 2 Master 1 Para-Nummer Sollwert 5	0_{hex} to FFFF_{hex}	
EE	Option module 2 master 1 parameter No. setpoint 5	0_{hex}	
PO	BM_u_Baci2M1SetVal5	1:1	-

5. Setpoint. Description of the parameters see [▶P0861◀](#) on page 154.

P0866	Optionsmodul 2 Master 1 Para-Nummer Sollwert 6	0_{hex} to FFFF_{hex}	
EE	Option module 2 master 1 parameter No. setpoint 6	0_{hex}	
PO	BM_u_Baci2M1SetVal6	1:1	-

6. Setpoint. Description of the parameters see [▶P0861◀](#) on page 154.

P0867	Optionsmodul 2 Master 1 Para-Nummer Sollwert 7	0_{hex} to FFFF_{hex}	
EE	Option module 2 master 1 parameter No. setpoint 7	0_{hex}	
PO	BM_u_Baci2M1SetVal7	1:1	-

7. Setpoint. Description of the parameters see [▶P0861◀](#) on page 154.

P0868	Optionsmodul 2 Master 1 Para-Nummer Sollwert 8	0_{hex} to FFFF_{hex}	
EE	Option module 2 master 1 parameter No. setpoint 8	0_{hex}	
PO	BM_u_Baci2M1SetVal8	1:1	-

8. Setpoint. Description of the parameters see [▶P0861◀](#) on page 154.

P0869	Optionsmodul 2 Master 1 Para-Nummer Istwert 1	0_{hex} to FFFF_{hex}	
EE	Option module 2 master 1 parameter No. act value 1	0_{hex}	
PO	BM_u_Baci2M1ActVal1	1:1	-

Configuration for the selected option module by parameter option module selection ([▶P0827◀](#)).

Parameter of the 1. actual values (1 ... 8) actual value for the cyclic communication. The parameter specified by the number must be data type INT, UINT, DINT, UDINT, WORD or DWORD.

7.3 Parameter description

This parameter is accepted after switching on, it also can be changed by the option module, but then it only serves as display.

P0870 Optionsmodul 2 Master 1 Para-Nummer Istwert 2 0_{hex} to FFFF_{hex}
EE **Option module 2 master 1 parameter No. act value 2** 0_{hex}
PO BM_u_Baci2M1ActVal2 1:1 -
2. actual value. Description of the parameters see [▶P0869◀](#) on page 155.

P0871 Optionsmodul 2 Master 1 Para-Nummer Istwert 3 0_{hex} to FFFF_{hex}
EE **Option module 2 master 1 parameter No. act value 3** 0_{hex}
PO BM_u_Baci2M1ActVal3 1:1 -
3. actual value. Description of the parameters see [▶P0869◀](#) on page 155.

P0872 Optionsmodul 2 Master 1 Para-Nummer Istwert 4 0_{hex} to FFFF_{hex}
EE **Option module 2 master 1 parameter No. act value 4** 0_{hex}
PO BM_u_Baci2M1ActVal4 1:1 -
4. actual value. Description of the parameters see [▶P0869◀](#) on page 155.

P0873 Optionsmodul 2 Master 1 Para-Nummer Istwert 5 0_{hex} to FFFF_{hex}
EE **Option module 2 master 1 parameter No. act value 5** 0_{hex}
PO BM_u_Baci2M1ActVal5 1:1 -
5. actual value. Description of the parameters see [▶P0869◀](#) on page 155.

P0874 Optionsmodul 2 Master 1 Para-Nummer Istwert 6 0_{hex} to FFFF_{hex}
EE **Option module 2 master 1 parameter No. act value 6** 0_{hex}
PO BM_u_Baci2M1ActVal6 1:1 -
6. actual value. Description of the parameters see [▶P0869◀](#) on page 155.

P0875 Optionsmodul 2 Master 1 Para-Nummer Istwert 7 0_{hex} to FFFF_{hex}
EE **Option module 2 master 1 parameter No. act value 7** 0_{hex}
PO BM_u_Baci2M1ActVal7 1:1 -
7. actual value. Description of the parameters see [▶P0869◀](#) on page 155.

P0876	Optionsmodul 2 Master 1 Para-Nummer Istwert 8	0_{hex} to FFFF_{hex}
EE	Option module 2 master 1 parameter No. act value 8	0_{hex}
PO	BM_u_Baci2M1ActVal8	1:1 -

8. actual value. Description of the parameters see [▶P0869◀](#) on page 155.

P0877	Optionsmodul 2 Master 1 Trigger-Offset	0_{hex} to FFFF_{hex}
EE	Option module 2 master 1 trigger offset	0_{hex}
PO	BM_u_Baci2M1TriggOffset	1:1 -

Configuration for the selected option module by parameter option module selection ([▶P0827◀](#)).

In the chosen data exchange interval the controller can read out a cyclic trigger signal to the option module. The offset (unit μs) determines the temporal reference between the beginning of the communication interval and the reading out of the trigger signal output.

Parameter is accepted when switching on, it can also be changed by the option module, but then it only acts as display.

P0878	Optionsmodul 2 Master 1 Zyklus-Offset Sollwerte	0_{hex} to FFFF_{hex}
EE	Option module 2 master 1 cycle offset setpoints	2
PO	BM_u_Baci2M1CycleSetOffset	1:1 -

Configuration for the selected option module by parameter option module selection ([▶P0827◀](#)).

Cycle offset for setpoint transmission.

Exact description see [▶BACI◀](#) from page 63.

This parameter is accepted after switching on, it also can be changed by the option module, but then it only serves as display.

P0879	Optionsmodul 2 Master 1 Zyklus-Offset Istwerte	0_{hex} to FFFF_{hex}
EE	Option module 2 master 1 cycle offset act. values	0_{hex}
PO	BM_u_Baci2M1CycleActOffset	1:1 -

Configuration for the selected option module by parameter option module selection ([▶P0827◀](#)).

Cycle offset for actual value transmission. Exact description see [▶BACI◀](#) from page 63.

This parameter is accepted after switching on, it also can be changed by the option module, but then it only serves as display.

P1000	Soll-Betriebsart	-7 to 6	
DS	Operation mode desired	-3	
	BM_i_Ds0_OperationMode	1:1	CW

With this parameter you determine the operation mode of the drive.

Value	Meaning
-3	U _{DC} -control

P1001	Kommunikationsquelle	0 _{hex} to 000F _{hex}	
DS	Communication source	0001 _{hex}	
	BM_w_DS0_CommSource	1:1	CW

This parameter controls the access rights of the different communication sources to parameters. Communication sources we call modules, which exchange data with a superimposed control by use of a communication interface.

We distinguish between the following communication sources:

- WinBASS II/ProDrive
- Option modules connected by BACI-interface

Basically, read access on parameters is always possible. The read access has different access modes. Here, we have determined the following:

- Write access using request data
- Write access using cyclic data
- Write access for control (that means on the control word)

With respect to access rights, WinBASS II/ProDrive is an exception; it has full access (write and read) on all parameters at any time.

Write access for control should always be given to only one communication source, because otherwise writing conflicts occur. Then the source succeeds, which was the last one to write within the cycle, before the drive manager evaluates the control word.

Bit No.	Meaning
0	1: WinBASS II/ProDrive, control enabled ¹⁾
1	1: CANsync, control enabled ¹⁾
2	1: CANsync, write access via service channel data is enabled
3	1: CANsync, write access using cyclic communication (setpoints)
4	1: BACI, control enabled ¹⁾
5	1: BACI, write access using service channel data enabled
6	1: BACI, write access using cyclic communication (setpoints)
7 to 15	Reserved

¹⁾ Note :

Only then, if in the parameter communication source the total bits for control (bit 0, 1 and 4) are reset, a controller enable is possible using only the hardware inputs pulse enable.

P1002	Antriebsmanager-Optionen	0_{hex} to FFFF_{hex}	
DS	Drive manager options	0_{hex}	
	BM_w_Ds0_DrvManagerOptions	1:1	CW

See also [►Drive management◄](#) from page 70.

Settings for the drive manager

Bit No.	Meaning
0	Reserved
1	1: Errors are able to be accepted via hardware input „pulse enable“ (FX3-5).
15 ... 2	Reserved

P1007	Fehler-Reaktion	0 to 3	
DS	Error reaction code	0	
ON	BM_i_Ds0_ErrorReactionCode	1:1	-

With this parameter the general error reaction is set. This is valid for errors, which do not require a pulse inhibit and which are not set to “No reaction”. At errors with separately adjustable error reaction the reaction, which was set there, is valid.

Reaction code	Meaning
0	Pulse disable
1	Power reduction with unregulated DC link voltage: operation state activated (from firmware-version FW 03.07) When reaction code = 1 the customer is responsible for power reduction and no power feedback in this state, otherwise the device can be damaged.
3 ... 2	Reserved

P1008	Maske für interne Begrenzungen	0_{hex} to FFFF_{hex}	
DS	Mask for internal limits	FFFF_{hex}	
ON	BM_w_Ds0_InternalLimitMask	1:1	CW

With this parameter it can be selected, which internal limits via bit 11 are signaled in parameter status word [►P0301◄](#). Normally all limits are signaled.

Meaning of the individual bits:

Bit No.	Meaning
0	Current limit
1	U_{DC} -setpoint limit
7 ... 2	Reserved

If a bit is set to 0, the according limit is not shown in the status word anymore.

7.3 Parameter description

P1010	Datensatz Identifikations-Nummer	0 to 65535	
DS	Data set ID	0	
ON	BM_u_Ds0_RecordId	1:1	CW

See also [▶Data Set Management◀](#) from page 13.

Free selectable identification number of stored parameter set.

P1011	Datensatz Name	80 ASCII characters	
DS	Data set name	""	
ON	BM_s_Ds0_RecordName	1:1	-

See also [▶Data Set Management◀](#) from page 13.

Free selectable name of data set with maximal 80 characters.

P1020	Stromregler P-Verstärkung	0.01 to 655.35	
DS	Current controller P-gain	1.00	
	BM_u_Ds0_CurrentCtrl_PGain	100:1	-

Proportional gain (Kp) of the current controller.

P1021	Stromregler Nachstellzeit	0.0 to 1000.0 ms	
DS	Current controller integral-action time	2.5 ms	
	BM_u_Ds0_CurrentCtrl_ITime	10:1 ms	-

Integral-action time (Ti) of current controller.

P1023	Ausgangsbegrenzung der Stromregler	0 to 199.99 %	
DS	Current controller output limiter	199.99 %	
ON	BM_u_Ds0_VdqLimit	4000 _{hex} :100 %	-

Limit of output voltage of the d- and q-current controller.

P1037	Momenten-Grenze motorisch/MR1	0.00 to 100.00%	
DS	Torque limiter motor/TD1	100.00 %	
ON	BM_u_Ds0_TrqLimMot_TD1	4000 _{hex} :100 %	-

See also [▶P1037◀](#) on page 161.

This torque limiter limits the torque setpoint at generating operation and accordingly in torque direction 2 (according to settings in [▶P1037◀](#), bit 2).

The torque limit can either be separately be adjusted for each torque direction or can be separately adjusted for feeding-in or feeding-back operation. The type of limit is set via parameter [▶P1037◀](#) bit 2 - that means if torque is limited by torque direction or by motor-ing/generating operation.

Scaling: 100 % ↔ power unit maximum current ([▶P1241◀](#))

P1038	Momenten-Grenze generatorisch/MR2	0.00 to 100.00%	
DS	Torque limiter Generator/TD2	100.00 %	
ON	BM_u_Ds0_TrqLimGen_TD2	4000 _{hex} :100 %	-

See also [▶P1037◀](#) on page 161.

This torque limiter limits the torque setpoint at generating operation and accordingly in torque direction 2 (according to settings in [▶P1037◀](#), bit 2).

The torque limit can either be separately be adjusted for each torque direction or can be separately adjusted for feeding-in or feeding-back operation. The type of limit is set via parameter [▶P1037◀](#) bit 2 - that means if torque is limited by torque direction or by motor-ing/generating operation.

Scaling: 100 % ↔ power unit maximum current ([▶P1241◀](#))

P1090	Auswahl digitaler Eingang 1	0 _{hex} to 0508 _{hex}	
DS	Selection digital input 1	0 _{hex}	
ON	BM_w_Ds0_DI1_InputChannel	1:1	-

Selection of slot and channel for digital input 1.

Bit No.	Meaning
7 ... 0	Channel selection (possible value 1 to 8, depending on function module)
15 ... 8	Slot selection of input module (possible values 1 to 5, corresponds to slot A to E)

Value 0 means that no input channel is selected.

7.3 Parameter description

P1091	Zielnummer digitaler Eingang 1	0 to max. Para No.	
DS	Target number: digital input 1	0	
ON	BM_u_Ds0_DI1_TargetPxxx	1:1	-
	Number of parameter to be changed by digital input 1.		
P1092	Bit-Auswahl digitaler Eingang 1	0 _{hex} to FFFF _{hex}	
DS	Bit selection digital input 1	0 _{hex}	
ON	BM_w_Ds0_DI1_BitSelection	1:1	CW
	Selection of target parameter bits to be changed by digital input 1.		
P1093	Bit-Muster bei LOW des digitalen Eingang 1	0 _{hex} to FFFF _{hex}	
DS	Set bit pattern for LOW state digital input 1	0 _{hex}	
ON	BM_w_Ds0_DI1_LowPattern	1:1	CW
	Bit pattern, written to target parameter if digital input 1 is LOW.		
P1094	Bit-Muster bei HIGH des digitalen Eingang 1	0 _{hex} to FFFF _{hex}	
DS	Set bit pattern for HIGH state digital input 1	0 _{hex}	
ON	BM_w_Ds0_DI1_HighPattern	1:1	CW
	Bit pattern, written to target parameter if digital input 1 is HIGH.		
P1095	Auswahl digitaler Eingang 2	0 _{hex} to 0508 _{hex}	
DS	Selection digital input 2	0 _{hex}	
ON	BM_w_Ds0_DI2_InputChannel	1:1	-
	Selection of slot and channel for digital input 2.		

Bit No.	Meaning
7 ... 0	Channel selection (possible value 1 to 8, depending on function module)
15 ... 8	Slot selection of input module (possible values 1 to 5, correspond to slot A to E)

Value 0 means that no input channel is selected.

P1096 Zielnummer digitaler Eingang 2 0 to max. para No.
 DS **Target number: digital input 2** 0
 ON BM_u_Ds0_DI2_TargetPxxx 1:1 -
 Number of parameter to be changed by digital input 2.

P1097 Bit-Auswahl digitaler Eingang 2 0_{hex} to FFFF_{hex}
 DS **Bit selection digital input 2** 0_{hex}
 ON BM_w_Ds0_DI2_BitSelection 1:1 CW
 Selection of target parameter bits to be changed by digital input 2.

P1098 Bit-Muster bei LOW des digitalen Eingang 2 0_{hex} to FFFF_{hex}
 DS **Set bit pattern LOW state digital input 2** 0_{hex}
 ON BM_w_Ds0_DI2_LowPattern 1:1 CW
 Bit pattern, written to target parameter if digital input 2 is LOW.

P1099 Bit-Muster bei HIGH des digitalen Eingang 2 0_{hex} to FFFF_{hex}
 DS **Set bit pattern HIGH state digital input 2** 0_{hex}
 ON BM_w_Ds0_DI2_HighPattern 1:1 CW
 Bit pattern, written to target parameter if digital input 2 is HIGH.

P1100 Auswahl digitaler Eingang 3 0_{hex} to 0508_{hex}
 DS **Selection digital input 3** 0_{hex}
 ON BM_w_Ds0_DI3_InputChannel 1:1 -
 Selection of slot and channel for digital input 3.

Bit No.	Meaning
7 ... 0	Channel selection (possible value 1 to 8, depending on function module)
15 ... 8	Slot selection of input module (possible values 1 to 5, correspond to slot A to E)

Value 0 means that no input channel is selected.

7.3 Parameter description

P1101	Zielnummer digitaler Eingang 3	0 to max. para No.	
DS	Target number: digital input 3	0	
ON	BM_u_Ds0_DI3_TargetPxxx	1:1	-
	Number of parameter to be changed by digital input 3.		
P1102	Bit-Auswahl digitaler Eingang 3	0 _{hex} to FFFF _{hex}	
DS	Bit selection digital input 3	0 _{hex}	
ON	BM_w_Ds0_DI3_BitSelection	1:1	CW
	Selection of target parameter bits to be changed by digital input 3.		
P1103	Bit-Muster bei LOW des digitalen Eingang 3	0 _{hex} to FFFF _{hex}	
DS	Set bit pattern for LOW state digital input 3	0 _{hex}	
ON	BM_w_Ds0_DI3_LowPattern	1:1	CW
	Bit pattern, written to target parameter if digital input 3 is LOW.		
P1104	Bit-Muster bei HIGH des digitalen Eingang 3	0 _{hex} to FFFF _{hex}	
DS	Set bit pattern for HIGH state digital input 3	0 _{hex}	
ON	BM_w_Ds0_DI3_HighPattern	1:1	CW
	Bit pattern, written to target parameter if digital input 3 is HIGH.		
P1105	Auswahl digitaler Eingang 4	0 _{hex} to 0508 _{hex}	
DS	Selection digital input 4	0 _{hex}	
ON	BM_w_Ds0_DI4_InputChannel	1:1	-
	Selection of slot and channel for digital input 4.		

Bit No.	Meaning
7 ... 0	Channel selection (possible value 1 to 8, depending on function module)
15 ... 8	Slot selection of input module (possible values 1 to 5, correspond to slot A to E)

Value 0 means that no input channel is selected.

P1106	Zielnummer digitaler Eingang 4	0 to max. para No.	
DS	Target number: digital input 4	0	
ON	BM_u_Ds0_DI4_TargetPxxx	1:1	-
	Number of parameter to be changed by digital input 4.		
P1107	Bit-Auswahl digitaler Eingang 4	0 _{hex} to FFFF _{hex}	
DS	Bit selection digital input 4	0 _{hex}	
ON	BM_w_Ds0_DI4_BitSelection	1:1	CW
	Selection of target parameter bits to be changed by digital input 4.		
P1108	Bit-Muster bei LOW des digitalen Eingang 4	0 _{hex} to FFFF _{hex}	
DS	Set bit pattern for LOW state digital input 4	0 _{hex}	
ON	BM_w_Ds0_DI4_LowPattern	1:1	CW
	Bit pattern, written to target parameter if digital input 4 is LOW.		
P1109	Bit-Muster bei HIGH des digitalen Eingang 4	0 _{hex} to FFFF _{hex}	
DS	Set bit pattern for HIGH state digital input 4	0 _{hex}	
ON	BM_w_Ds0_DI4_HighPattern	1:1	CW
	Bit pattern, written to target parameter if digital input 4 is HIGH.		
P1110	Auswahl digitaler Ausgang 1	0 _{hex} to 0508 _{hex}	
DS	Selection digital output 1	0 _{hex}	
ON	BM_w_Ds0_DO1_OutputChannel	1:1	-
	Selection of slot and channel for digital output 1.		

Bit	Meaning
7 ... 0	Channel selection of output module (possible value 1 to 8, depending on function module)
15 ... 8	Slot selection of output module (possible values 1 to 5, correspond to slot A to E)

Value 0 means that no input channel is selected.

7.3 Parameter description

P1111 Quellnummer digitaler Ausgang 1 0 to max. para No.
 DS **Source number digital output 1** 0
 ON BM_u_Ds0_DO1_SourcePxxx 1:1 -
 Number of parameter for output by digital output 1.

P1112 Bit-Auswahl digitaler Ausgang 1 0_{hex} to FFFF_{hex}
 DS **Bit selection digital output 1** 0_{hex}
 ON BM_w_Ds0_DO1_BitSelection 1:1 CW
 Selection of bits in source parameter to be compared for digital output 1.

P1113 Bit-Muster digitaler Ausgang 1 0_{hex} to FFFF_{hex}
 DS **Bit pattern digital output 1** 0_{hex}
 ON BM_w_Ds0_DO1_BitPattern 1:1 CW
 Bit pattern to be compared with the bit pattern of source parameter for digital output 1.

P1114 Auswahl digitaler Ausgang 2 0_{hex} to 0508_{hex}
 DS **Selection digital output 2** 0_{hex}
 ON BM_w_Ds0_DO2_OutputChannel 1:1 -
 Selection of slot and channel for digital output 2.

Bit	Meaning
7 ... 0	Channel selection (possible value 1 to 8, depending on function module)
15 ... 8	Slot selection of input module (possible values 1 to 5, correspond to slot A to E)

The value 0 means no output channel selected.

P1115 Quellnummer digitaler Ausgang 2 0_{hex} to max. para-No.
 DS **Source number digital output 2** 0
 ON BM_u_Ds0_DO2_SourcePxxx 1:1 -
 Number of parameter for output by digital output 2.

P1116	Bit-Auswahl digitaler Ausgang 2	0_{hex} to 0508_{hex}	
DS	Bit selection digital output 2	0_{hex}	
ON	BM_w_Ds0_DO2_BitSelection	1:1	CW

Selection of bits in source parameter to be compared for digital output 2.

P1117	Bit-Muster digitaler Ausgang 2	0_{hex} to $FFFF_{\text{hex}}$	
DS	Bit pattern digital output 2	0_{hex}	
ON	BM_w_Ds0_DO2_BitPattern	1:1	CW

Bit pattern to be compared with the bit pattern of source parameter for digital output 2.

P1118	Auswahl digitaler Ausgang 3	0_{hex} to 0508_{hex}	
DS	Selection digital output 3	0_{hex}	
ON	BM_w_Ds0_DO3_OutputChannel	1:1	-

Selection of slot and channel for digital output 3.

Bit	Meaning
7 ... 0	Channel selection (possible value 1 to 8, depending on function module)
15 ... 8	Slot selection of input module (possible values 1 to 5, correspond to slot A to E)

The value 0 means, that an output channel has not been selected.

P1119	Quellnummer digitaler Ausgang 3	0 to max. para No.	
DS	Source number digital output 3	0	
ON	BM_u_Ds0_DO3_SourcePxxx	1:1	-

Number of parameter for output by digital output 3.

P1120	Bit-Auswahl digitaler Ausgang 3	0_{hex} to $FFFF_{\text{hex}}$	
DS	Bit selection digital output 3	0_{hex}	
ON	BM_w_Ds0_DO3_BitSelection	1:1	CW

Selection of bits in source parameter to be compared for digital output 3.

P1121	Bit-Muster digitaler Ausgang 3	0_{hex} to FFFF_{hex}	
DS	Bit pattern digital output 3	0_{hex}	
ON	BM_w_Ds0_DO3_BitPattern	1:1	CW

Bit pattern to be compared with the bit pattern of source parameter for digital output 3.

P1122	Auswahl digitaler Ausgang 4	0_{hex} to 0508_{hex}	
DS	Selection digital output 4	0_{hex}	
	BM_w_Ds0_DO4_OutputChannel	1:1	-

Selection of slot and channel for digital output 4.

Bit	Meaning
7 ... 0	Channel selection (possible value 1 to 8, depending on function module)
15 ... 8	Slot selection of input module (possible values 1 to 5, correspond to slot A to E)

The value 0 means, that an output channel has not been selected.

P1123	Quellnummer digitaler Ausgang 4	0 to max. para No.	
DS	Source number digital output 4	0	
ON	BM_u_Ds0_DO4_SourcePxxx	1:1	-

Number of parameter for output by digital output 4.

P1124	Bit-Auswahl digitaler Ausgang 4	0_{hex} to FFFF_{hex}	
DS	Bit selection digital output 4	0008_{hex}	
ON	BM_w_Ds0_DO4_BitSelection	1:1	CW

Selection of bits in source parameter to be compared for digital output 4.

P1125	Bit-Muster digitaler Ausgang 4	0_{hex} to FFFF_{hex}	
DS	Bit pattern digital output 4	0_{hex}	
ON	BM_w_Ds0_DO4_BitPattern	1:1	CW

Bit pattern to be compared with the bit pattern of source parameter for digital output 4.

P1130	Auswahl analoger Eingang 1	0_{hex} to 0508_{hex}	
DS	Selection analog input 1	0_{hex}	
ON	BM_w_Ds0_AI1_InputChannel	1:1	-

Selection of slot and channel for analog input 1.

Bit No.	Meaning
7 ... 0	Channel selection (possible value 1 to 8, depending on function module)
15 ... 8	Slot selection of input module (possible values 1 to 5, correspond to slot A to E)

Value 0 means that no input channel is selected.

P1131	Glättungszeit analoger Eingang 1	0.000 to 60.000 ms	
DS	Smoothing time analog input 1	1.000 ms	
ON	BM_u_Ds0_AI1_Smoothing	1000:1 ms	-

Smoothing time analog input 1.

In order to smooth errors on the analog input signal a smoothing time constant in ms can be entered.

Smoothing is off, if the particular parameter value = 0 ms is set.

P1132	Skalierungsfaktor analoger Eingang 1	-2.0 to 2.0	
DS	Scaling factor analog input 1	1.0	
ON	BM_i_Ds0_AI1_Scaling	$3FFF_{\text{hex}}$:1	-

Scaling factor analog input 1. These parameters enable a scaling of the analog input value.

The output values (see parameters [▶P0420◀](#) and [▶P0421◀](#)) are with unipolar target parameters from 0 to +100% and with bipolar target parameters from -100% to +100%. Which analog input voltage is used to reach these maximum values, is dependent on the scaling factor.

P1133	Zielnummer analoger Eingang 1	0 to max. para No.	
DS	Target number: analog input 10	0	
ON	BM_u_Ds0_AI1_TargetPxxx	1:1	-

Number of parameter to be controlled by "analog input 1".

P1134 Offset analoger Eingang 1 -100.00 % to +100.00 %
 DS **Offset analog input 1** 0.00 %
 ON BM_i_Ds0_AI1_Offset 7FFF_{hex}:100 % CW
 Offset correction of analog input 1.

P1135 Schwellenwert analoger Eingang 1 0.00 % to +100.00 %
 DS **Threshold value analog input 1** 0.00 %
 ON BM_u_Ds0_AI1_Threshold 7FFF_{hex}:100 % CW
 Threshold value of analog input 1. By using the threshold value, you can control the input threshold of sensitivity.

P1136 Auswahl analoger Eingang 2 0_{hex} to 0508_{hex}
 DS **Selection analog input 2** 0_{hex}
 ON BM_w_Ds0_AI2_InputChannel 1:1 -
 Selection of slot and channel for analog input 1.

Bit No.	Meaning
7 ... 0	Channel selection (possible value 1 to 8, depending on function module)
15 ... 8	Slot selection of input module (possible values 1 to 5, correspond to slot A to E)

Value 0 means that no input channel is selected.

P1137 Glättungszeit analoger Eingang 2 0.000 to 60.000 ms
 DS **Smoothing time analog input 2** 1.000 ms
 ON BM_u_Ds0_AI2_Smoothing 1000:1 ms -

Smoothing time analog input 2. In order to smooth errors on the analog input signal a smoothing time constant in ms can be entered. The smoothing is off, if the particular parameter value = 1 ms is set.

P1138 Skalierungsfaktor analoger Eingang 2 -2.0 to 2.0
 DS **Scaling factor analog input 2** 1.0
 ON BM_i_Ds0_AI2_Scaling 7FFF_{hex}:1 -

Scaling factor analog input 2.
 These parameters enable a scaling of the analog input value. The output values (see parameters [▶P0420◀](#) and [▶P0421◀](#)) are with unipolar target parameters from 0 to +100% and with bipolar target parameters from -100% to +100%. Which analog input voltage is used to reach these maximum values, is dependent on the scaling factor.

P1139 Zielnummer analoger Eingang 2 0 to max. para No.
 DS **Target number analog input 2** 0
 ON BM_u_Ds0_AI2_TargetPxxx 1:1 -

Number of parameter, which is to be changed by “analog input 2”.

P1140 Offset analoger Eingang 2 -100.00 % to +100.00 %
 DS **Offset analog input 2** 0.00 %
 ON BM_i_Ds0_AI2_Offset 7FFF_{hex}:100 % CW

Offset correction of analog input 2.

P1141 Schwellenwert analoger Eingang 2 0.00 % to +100.00 %
 DS **Threshold value analog input 2** 0.00 %
 ON BM_u_Ds0_AI2_Threshold 7FFF_{hex}:100 % CW

Threshold value of analog input 2. Responsiveness of input.

P1150 Auswahl schneller analoger Ausgang 1 0_{hex} to 0508_{hex}
 DS **Selection fast analog output 1** 0_{hex}
 ON BM_w_Ds0_AOF1_OutputChannel 1:1 -

Selection of slot and channel for fast analog output 1.

Bit No.	Meaning
7 ... 0	Channel selection (possible value 1 to 8, depending on function module)
15 ... 8	Slot selection of input module (possible values 1 to 5, correspond to slot A to E)

Value 0 means that no input channel is selected.

P1151 Quellnummer schneller analoger Ausgang 1 0 to max. para No.
 DS **Source number fast analog output 1** 0
 ON BM_u_Ds0_AOF1_SourcePxxx 1:1 -

You can select a parameter for output by filling in its parameter number.
 If this parameter is set to 0, the regarded channel is switched off.

P1152 Offset schneller analoger Ausgang 1 -10.00 to +10.00V
 DS **Offset fast analog output 1** 0 V
 ON BM_i_Ds0_AOF1_Offset 7FFF_{hex}:10 V CW
 Offset correction of fast analog output 1.

P1153 Skalierungsfaktor schneller analoger Ausgang 1 67108863.00 to 67108863.00
 DS **Scaling fast analog output 1** 1.00
 ON BM_di_Ds0_AOF1_Scaling 32:1 CW
 Scaling factor fast analog output 1.

P1154 Auswahl schneller analoger Ausgang 2 0_{hex} to 0508_{hex}
 DS **Selection fast analog output 2** 0_{hex}
 ON BM_w_Ds0_AOF2_OutputChannel 1:1 -
 Selection of slot and channel for fast analog output 2.

Bit No.	Meaning
7 ... 0	Channel selection (possible value 1 to 8, depending on function module)
15 ... 8	Slot selection of input module (possible values 1 to 5, correspond to slot A to E)

The value 0 means, that an output channel has not been selected.

P1155 Quellnummer schneller analoger Ausgang 2 0 to max. para No.
 DS **Source number fast analog output 2** 0
 ON BM_u_Ds0_AOF2_SourcePxxx 1:1 -
 You can select a parameter for output by filling in its parameter number.
 If this parameter is set to 0, the regarded channel is switched off.

P1156 Offset schneller analoger Ausgang 2 -10.00 to +10.00V
 DS **Offset fast analog output 2** 0.0 V
 ON BM_i_Ds0_AOF2_Offset 7FFF_{hex}:10 V CW
 Offset correction of fast analog output 2.

P1157	Skalierungsfaktor schneller analoger Ausgang 2	67108863.00 to 67108863.00	
DS	Scaling fast analog output 2	1.00	
ON	BM_i_Ds0_AOF2_Scaling	32:1	CW
	Scaling factor fast analog output 2.		

P1170	Hochlaufgeber Modus	0_{hex} to FFFF_{hex}	
DS	Ramp function generator mode	0_{hex}	
	BM_w_Ds0_RFGMode	4000_{hex} :100 %	CW

Settings for the ramp function generator.

Bit No.	Meaning
2 ... 0	Reserved
3	1: negative setpoints are inhibited
4	1: positive setpoints are inhibited
5	1: polarity reversal of the current setpoint
6	0: trapezoidal speed profile with ramp function generator smoothing (PT ₁ -element) 1: S-curve with square speed profile
15 ... 7	Reserved

P1172	Hochlaufgeber Hochlaufzeit	0.00 to 650.00 s	
DS	Ramp function generator ramp-up time	0.00 s	
	BM_u_Ds0_RFG1RampUpTime	100:1 s	CW

Acceleration ramp for speed-controlled operation modes.

The time selected here corresponds to 100 % setpoint change.

P1173	Hochlaufgeber Rücklaufzeit	0.00 to 650.00 s	
DS	Ramp function generator ramp-down time	0.00 s	
	BM_u_Ds0_RFG1RampDownTime	100:1 s	CW

Deceleration ramp for speed-controlled operation modes.

The time selected here corresponds to 100 % setpoint change.

P1175	Hochlaufgeber Verschleiß	0 to 32 ms	
DS	Ramp function generator smoothing time	0 ms	
	BM_u_Ds0_RFG1Smoothing	1:1 ms	

In order to achieve a smoothing of the ramp edges a PT₁-element is implemented. By use of this parameter, you can set the time constant of the PT₁-element. Smoothing is effective only if a trapezoidal profile is set as ramp form.

P1241	Leistungsteil Maximalstrom des Antriebs	0.1 to 6553.5 A	
DS	Power unit maximum drive current	2.5 A	
	BM_u_Ds0_CurrentDriveMax	10:1 A	-
	Maximum current output of power unit.		
	This parameter defines the current scaling, i.e. it is the reference value for all percental current parameters.		
P1251	Uzk-Regler P-Verstärkung	1.0 to 255.9	
DS	DC-link controller P-gain	50.0	
	BM_u_Ds0_DCLinkCtrl_PGain	10:1	-
	P-gain of the DC link controller.		
P1252	Uzk-Regler-Nachstellzeit	0.2 to 1000.0 ms	
DS	DC-link controller integral-action time	20.0 ms	
	BM_u_Ds0_DCLinkCtrl_ITime	10:1 ms	-
	Integral action time of DC link controller.		
P1260	Blockierzeit (Stromgrenzezeit)	0.0 to 6500.0 s	
DS	Blocking time	10.0 s	
	BM_u_Ds0_BlockingTime	10:1 s	-
	Release time for current limit monitoring.		
	Current limit monitoring becomes active, if the drive controller is at the current limit.		
	After operating sequence of release time for the current limit monitoring the drive is switched off with an error message.		
	With blocking time = 0.0 s, the current limit monitoring is switched off.		

7.3 Parameter description

P1290	Parameterauswahl Statusbit 14	0 to max. para No.	
DS	Parameter selection statusbit 14	0	
	BM_u_Ds0_StatusB14_IdSelect	1:1	-
	Selection of the parameter for the freely defined status bit 14 in the drive manager status word (▶P0301◀).		
	If in the selected parameter (▶P1291◀) a bit from the mask is set, the bit 14 in the status word is set.		
P1291	Bitmaske für Statusbit 14	0 _{hex} to FFFF _{hex}	
DS	Bit pattern status bit 14	0 _{hex}	
	BM_w_Ds0_StatusB14_Mask	1:1	-
	Mask for the freely defined status bit 14 in the drive manager status word (▶P0301◀).		
	If in the selected parameter (▶P1290◀) a bit from the mask is set, the bit 14 in the status word is set.		
P1292	Parameterauswahl Statusbit 15	0 to max. para No.	
DS	Parameter selection statusbit 15	0	
	BM_u_Ds0_StatusB15_IdSelect	1:1	-
	Selection of the parameter for the freely defined status bit 14 in the drive manager status word (▶P0301◀).		
	If in the selected parameter (▶P1293◀) a bit from the mask is set, the bit 15 in the status word is set.		
P1293	Bitmaske für Statusbit 15	0 _{hex} to FFFF _{hex}	
DS	Bit mask for status bit 15	0 _{hex}	
	BM_w_Ds0_StatusB15_Mask	1:1	-
	Mask for the freely defined status bit 15 in the drive manager status word (▶P0301◀).		
	If in the selected parameter (▶P1292◀) a bit from the mask is set, the bit 15 in the status word is set.		
P1340	Einspeiseeinheit Leistungsfaktor-Sollwert	-1.0 to 1.0	
DS	PSU power factor setpoint	1.0	
ON	BM_u_Ds0_PSU_PowerfactorSet	65535:1	CW
	Power factor correction		

P1342	Einspeiseeinheit Zwischenkreisspannung Glättungszeit	0 to 60.0 ms	
DS	PSU DC link voltage smoothing time	1.0 ms	
ON	BM_u_Ds0_PSU_DCLinkVoltsmoothtime	10:1 ms	CW

Smoothing time of the DC link.

P1343	Einspeiseeinheit max. UZK-Sollwert	300 to 800 V	
DS	PSU max. DC link voltage setpoint	760 V	
ON	BM_u_Ds0_PSU_DCLinkVoltSetBUC_ULim	1:1 V	CW

This voltage limit limits the DC link voltage setpoint. The DC link voltage is limited to this value, if the DC link voltage setpoint is greater than the limit.

P1344	Einspeiseeinheit min. UZK-Sollwert	280 to 800 V	
DS	PSU min. DC link voltage setpoint	360 V	
ON	BM_u_Ds0_PSU_DCLinkVoltSetBUC_LLim	1:1 V	CW

This voltage limit limits the DC link voltage setpoint. The DC link voltage is limited to this value, if the DC link voltage setpoint is smaller than this limit.

P1345	Einspeiseeinheit Faktor U Netz-Vorsteuerung	0% to 125 %	
DS	PSU main voltage feed forward factor	100 %	
ON	BM_u_Ds0_PSU_MainVoltfeedForFactor	4000 _{hex} :100 %	CW

Evaluation factor of mains voltage feed forward.

Scaling: 100 % ↔ Power unit U_{DC} nominal value ([▶P0020◀](#))/ $\sqrt{2}$

P1346	Einspeiseeinheit Netzspannungsvorsteuerung Glättungszeit	0 to 50 ms	
DS	PSU mains voltage feed forward smoothing time	1.0 ms	
ON	BM_u_Ds0_PSU_MainVoltSmoothTime	10:1 ms	CW

Smoothing time of mains voltage for mains feed forward.

P1347 Einspeiseeinheit Id-Sollwert -100.0 % to +100.0 %
 DS **PSU Id setpoint** 0.0 %
 ON BM_i_Ds0_PSU_IdSet 4000_{hex}:100 % CW
 Direct-axis current setpoint
 Scaling: 100 % ÷ power unit; maximum current ([▶P1241◀](#)).

P1348 Einspeiseeinheit Modus1 0000_{hex} to FFFF_{hex}
 DS **PSU mode 1** FFFD_{hex}
 ON BM_w_Ds0_PSU_Mode1 1:1 ms CW
 Operation mode of the mains inverter.

P1349 Einspeiseeinheit Id Regelabweichung Grenze -100.0 % to +100.0 %
 DS **PSU max. Id deviation** 0.0 %
 ON BM_i_Ds0_PSU_Id_Max_Dev 4000_{hex}:100 % CW
 Limit Id control deviation.
 Scaling: 100 % ÷ power unit; maximum current ([▶P1241◀](#))

P1350 Einspeiseeinheit Offset RHO -30.0 ° to +30.0 °
 DS **PSU offset rho** 0.0 °
 ON BM_u_Ds0_PSU_Offset_rho 4000_{hex}: 360 ° CW
 This parameter sets the power factor $\cos \varphi$, refer to [▶Setting the power rate \$\cos \varphi\$ ◀](#) on page 48.

P1351 Einspeiseeinheit Iq Regelabweichung Grenze -100.0 % to +100.0 %
 DS **PSU max. Iq deviation** 0.0 %
 ON BM_i_Ds0_PSU_Iq_Max_Dev 4000_{hex}: 100 % CW
 Limit Iq deviation.
 Scaling: 100 % ÷ power unit; maximum current ([▶P1241◀](#))

P1352	Einspeiseeinheit UZK Regelabweichung Grenze	-100.0 % to +100.0 %	
DS	PSU max. DC link voltage deviation	0.0 %	
ON	BM_i_Ds0_PSU_Vdc_Max_Dev	4000 _{hex} : 100 %	CW

Limited U_{DC} deviation.

Scaling: 100 % \leftrightarrow Power unit U_{DC} nominal value ([▶P0020◀](#))/ $\sqrt{2}$

P1353	Einspeiseeinheit Eingangswert des HLG	280 V to 800 V	
DS	PSU ramp function generator input	640 V	
ON	BM_u_Ds0_PSU_RFGInput	1:1 V	CW

Input value of the ramp function generator.

P1354	Einspeiseeinheit Warnungsschwelle der Netzunter- spannung	360 V to 500 V	
DS	PSU mains undervoltage warning	180 V	
ON	BM_u_Ds0_PSU_MainsUnderVolt_L	10:1 V	CW

Warning threshold of mains undervoltage.

P1355	Einspeiseeinheit Warnungsschwelle der Netzüber- spannung	400 V to 528 V	
DS	PSU mains overvoltage warning	400 V	
ON	BM_u_Ds0_PSU_MainsOverVolt_L	10:1 V	CW

Warning threshold of mains overvoltage.

P1356	Einspeiseeinheit Überwachungszeit der Rückmel- dung	0,000 to 10,000 s	
DS	PSU contactor confirmation supervision time	1,000 s	
ON	BM_u_Ds0_PSU_Cconfirm_Rdelay	1000:1 s	CW

Monitoring time of main contactor feedback. After monitoring time an error message is generated. With monitoring time = 0.0 s the monitoring of the feedback is switched-off.

P1357	Einspeiseeinheit Zyklen der Vorladung	0,000 bis 120,000 s	
DS	PSU Precharge cycle	0 s	
ON	BM_ud_Ds0_PSU_Prechargecycle	1000:1 s	CW

Cycle time of the pre-charge. The charge circuit cannot be activated, as long as this time is not expired.

P1358	Einspeiseeinheit Warnungsschwelle der Netzleistung	0,000 bis 3276,7 kW
DS	PSU Mains warning power	30,0 kW
ON	BM_ud_Ds0_PSU_Main_OverPower_L	10:1 kW

Warning threshold limit of the mains power is exceeded.

P1359	Einspeiseeinheit Max. Ladezeit	1,00 bis 600,00 s
DS	PSU Mains max. load time	30,00 s
ON	BM_ud_Ds0_PSU_PrechargeTimeMax	1000:1 s

Warning threshold limit of power supply unit load time.

P2000	Quellnummer Oszilloskop, Kanal 1	0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$
EE	Oscilloscope source channel 1	0_{hex}
	BM_ud_Transient_Source1Pxxx	1:1 -
	Parameter numbers of the recording parameter (1 ... 8) for the oscilloscope function. For recording, all 16- and 32-bit parameters can be used. String- and array parameters cannot be used for oscilloscope recording.	
	At 0 the channel is switched off.	
P2001	Quellnummer Oszilloskop, Kanal 2	0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$
EE	Oscilloscope source channel 2	0_{hex}
	BM_ud_Transient_Source2Pxxx	1:1 -
	2. recording parameters for the oscilloscope function. Description see parameters ▶P2000◀ on page 181.	
P2002	Quellnummer Oszilloskop, Kanal 3	0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$
EE	Oscilloscope source channel 3	0_{hex}
	BM_ud_Transient_Source3Pxxx	1:1 -
	3. recording parameters for the oscilloscope function. Description see parameters ▶P2000◀ on page 181.	
P2003	Quellnummer Oszilloskop, Kanal 4	0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$
EE	Oscilloscope source channel 4	0_{hex}
	BM_ud_Transient_Source4Pxxx	1:1 -
	4. recording parameters for the oscilloscope function. Description see parameters ▶P2000◀ on page 181.	
P2004	Quellnummer Oszilloskop, Kanal 5	0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$
EE	Oscilloscope source channel 5	0_{hex}
	BM_ud_Transient_Source5Pxxx	1:1 -
	5. recording parameters for the oscilloscope function. Description see parameters ▶P2000◀ on page 181.	

P2005	Quellnummer Oszilloskop, Kanal 6	0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$
EE	Oscilloscope source channel 6	0_{hex}
	BM_ud_Transient_Source6Pxxx	1:1 -

6. recording parameters for the oscilloscope function.
Description see parameters [▶P2000◀](#) on page 181.

P2006	Quellnummer Oszilloskop, Kanal 7	0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$
EE	Oscilloscope source channel 7	0_{hex}
	BM_ud_Transient_Source7Pxxx	1:1 -

7. recording parameters for the oscilloscope function.
Description see parameters [▶P2000◀](#) on page 181.

P2007	Quellnummer Oszilloskop, Kanal 8	0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$
EE	Oscilloscope source channel 8	0_{hex}
	BM_ud_Transient_Source8Pxxx	1:1 -

8. recording parameters for the oscilloscope function.
Description see parameters [▶P2000◀](#) on page 181.

P2008	Quellnummer Triggerquelle 1	0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$
EE	Oscilloscope trigger source 1	0_{hex}
	BM_ud_Transient_TriggSrc1Pxxx	1:1 -

Number of the parameters of the first trigger source for the oscilloscope function.

All 16- and 32-bit parameters can be used as trigger source parameters. String- and array parameters cannot be used as trigger.

If the value is 0, it can not be triggered.

P2009	Quellnummer Triggerquelle 2	0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$
EE	Oscilloscope trigger source 2	0_{hex}
	BM_ud_Transient_TriggSrc2Pxxx	1:1 -

Number of the parameters of the second trigger source for the oscilloscope function.

All 16- and 32-bit parameters can be used as trigger source parameters. String- and array parameters cannot be used as trigger.

If the value is 0, it can not be triggered.

P2010 Maske Triggerquelle 1 0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$
 EE **Mask trigger source 1** $\text{FFFFFFFF}_{\text{hex}}$
 BM_d_Transient_TriggerMask1 1:1 -

Mask for trigger source 1.

At evaluation of trigger condition the controller ANDs the value of the first trigger source parameter with this bit mask and compare the value which was masked out with the trigger comparison value 1.

P2011 Maske Triggerquelle 2 0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$
 EE **Mask trigger source 2** $\text{FFFFFFFF}_{\text{hex}}$
 BM_d_Transient_TriggerMask2 1:1 -

Mask for trigger source 2.

At evaluation of trigger condition the controller ANDs the value of the second trigger source parameter with this bit mask and compares the value, which was masked out with the trigger comparison value 2.

P2012 Trigger-Vergleichsoperator 1 0 to 3
 EE **Trigger compare operator 1** 0
 BM_u_Transient_TriggerOp1 1:1 -

The transient operator compares the trigger source with the trigger comparison value according to the following formula:

Trigger result 1 =
 (content of source number trigger source 1 [▶P2008◀](#))
 AND
 Mask trigger source 1 [▶P2010◀](#)) OPERATOR 1 → Trigger comparison value 1 [▶P2014◀](#)

Value	Operation
0	greater than
1	less than
2	equal
3	not equal

According to data type of the trigger source parameter the comparison operation is signed or unsigned 16- bitwise or 32-bitwise.

P2013 Trigger-Vergleichsoperator 2 0 to 3

EE **Trigger compare operator 2** 0

BM_u_Transient_TriggerOp2 1:1 -

The transient operator compares the trigger source with the trigger comparison value according to the following formula:

Trigger result 2 =

(content of source number trigger source 2 >P2009<)

AND

Mask trigger source 2 >P2011<) OPERATOR 2 → Trigger comparison value 2 >P2015<

Value	Operation
0	greater than
1	less than
2	equal
3	not equal

According to data type of the trigger source parameter the comparison operation is signed or unsigned 16- bitwise or 32-bitwise.

P2014 Trigger-Vergleichswert 1 0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$

EE **Trigger compare value 1** $\text{FFFFFFFF}_{\text{hex}}$

BM_ud_Transient_TriggerCmpVal1 1:1 -

Comparison value for trigger condition 1.

P2015 Trigger-Vergleichswert 2 0_{hex} to $\text{FFFFFFFF}_{\text{hex}}$

EE **Trigger compare value 2** $\text{FFFFFFFF}_{\text{hex}}$

BM_ud_Transient_TriggerCmpVal2 1:1 -

Comparison value for trigger condition 2.

P2016 Triggerquellen-Verknüpfungs-Operator 1 to 3

EE **Trigger source combination operator** 1

BM_u_Transient_TriggerCompi 1:1 -

The operator compares the results of two trigger conditions and sets the trigger, if the linking is logically combined.

Trigger = trigger result 1 OPERATOR trigger result 2

Trigger operators:

Value	Operation
1	AND
2	or
3	Exclusively-OR

P2017 Triggerzeitpunkt in % der Speichertiefe 0 to 100 %

EE **Trigger delay in %** 0 %

BM_u_Transient_TriggerDelay 1:1 % -

This parameter specifies, how many data is to be recorded before the trigger event. The percent specification refers to the entire recording memory.

Examples:

At 0 % the controller stores all values starting from the trigger event.

At 33 % the trigger time instant (identified by a vertical dashed line) lies at the end of the first third of the recording window.

P2018 Status der Triggerung 0_{hex} to $FFFF_{\text{hex}}$

A **Trigger status** 0_{hex}

- BM_u_Transient_TriggerStatus 1:1 -

This parameter shows the current status of the oscilloscope function.

Value	Status
1	Non-operated
2	Trigger monitoring ready, but no recording
3	Recording is running
4	Recording completed
5	Preparations in order to store are completed
6	Recording interrupted - drop memory contents
7	Waiting for the trigger event, but recording is already running, in order to record the history

P2019 Trigger-Kommando 1 to 6

EE **Trigger command** 1

BM_u_Transient_TriggerComand 1:1 -

This parameter controls the oscilloscope function.

Value	Status
1	IDLE command
2	Stop recording
3	Start trigger monitoring
4	Start recording independent on trigger event
5	Recording data assured, transition to IDLE
6	Resetting of status machine. Standard value for source- and trigger parameter

P2020 Speichertiefe pro Kanal 0_{hex} to $\text{FFFFFFF}_{\text{hex}}$

A **Transient samples** 0_{hex}

BM_ud_Transient_Samples 1:1 -

After a recording this parameter provides the number of the executed measuring points.

The possible number of the measured values is dependent on:

- o the measuring memory which is available
(see parameters size oscilloscope memory [▶P2023◀](#)),
- o the number and
- o the word width of each parameter, which is to be recorded.

P2021 Abtastrate 0.125 ms to 8191 ms

EE **Sample rate** 0.125 ms

BM_u_Transient_SampleTime 1:0.125 ms -

Sampling rate in multiples of 125 μs .

P2022 Aufzeichnungsdauer 0 to 32 ms

A **Measurement time** 0 ms

BM_ud_Transient_Duration 1:1 ms -

After a recording this parameter shows the recording duration of the prior measurement.

This value is generated from:

(memory depth per channel [▶P2020◀](#)) * (sampling rate [▶P2021◀](#))

P2023 Größe Oszilloskopspeicher 1024 to 16384

EE **Oscilloscope memory length** 1024

BM_ud_Transient_Memory 1:1 -

This parameter defines the usable memory depth for the oscilloscope function in words. The larger the memory depth, the longer data transmission of controller to WinBASS/Pro-Drive lasts.

For testing purposes (e. g. For testing purposes (e.g. optimization of trigger parameters) it is recommendable, to set memory depth low and to maximize not before in fact a lot of data shall be recorded.

P2024 Startadresse Oszilloskopspeicher 0_{hex} to $\text{FFFFFFF}_{\text{hex}}$

A **Oscilloscope memory start address** 0_{hex}

BM_ud_Transient_MemoryStartAdr 1:1 -

Constant, which specifies the starting address of measured value memory.

P2025 Oszilloskop Fehlercode 0 to 65535

A **Oscilloscope error code** 0_{hex}

BM_u_Transient_ErrorCode 1:1 -

Error code of oscilloscope function:

Value	Status
0	No error
1	Parameter number for data source 1 is faulty
2	Parameter number for data source 2 is faulty
3	Parameter number for data source 3 is faulty
4	Parameter number for data source 4 is faulty
5	Parameter number for data source 5 is faulty
6	Parameter number for data source 6 is faulty
7	Parameter number for data source 7 is faulty
8	Parameter number for data source 8 is faulty
9	Parameter number for data source 8 or trigger source is incorrect
10	Parameter number for trigger source 1 is faulty
11	Parameter number for trigger source 2 is faulty
12	Wrong trigger operator
13	No source parameter specified
14...65535	Reserved

P2030	Passwort	0 to 65535	
	Password	0	
ON	BM_u_Password	1:1	-
<p>Parameter used for the input of a system password and for the display of the current password level.</p> <p>Special functions only can be changed or activated after input of a password (also see ▶P2032◀ system commands). Thereby there are different password levels with different passwords.</p> <p>After input of a valid password in this parameter the password level is shown. After switching-on and after input of an incorrect password the password level is set to 0.</p> <p>The password for password level 1 is: 1234.</p>			
P2032	Systemzeit	0 to 4294967295 s	
	System time	0 s	
ON	BM_u_SystemTime	1:1 s	-
<p>This parameter contains the system time in seconds. Time starts at each booting operation with 0 and is incremented every second.</p> <p>By writing of the parameter, the system time can be set to any time. The format „seconds since 01.01.1970 0:00:00 o'clock“ should be used, which is common in the PC range.</p>			
P2034	Zeit seit letzten Boot-Vorgang	0 to 4294967295 s	
	Time since last boot	0 s	
ON	BM_ud_UpTime	1:1 s	-
<p>This parameter indicates the operating time in seconds, since the last switch-on. With every booting operation time starts with 0 again.</p>			
P2035	Betriebs-Sekundenzähler	0 to 4294967295 s	
	Power on seconds	0 s	
A	BM_ud_UpTimeSum	1:1 s	-
<p>Not yet implemented.</p>			

P3314	Applikationsparameter 1	-2147483648 to 2147483647	
EE	Application parameter 1	0	
ON	BM_di_ApplicationParam1	1:1 s	CW

Application parameter is placed at ones disposal, e. g.:

- Linking of in- and outputs
- Access via field busses or PLC

All application parameters are stored at the storing of data sets (retained).

P3315	Applikationsparameter 2	-2147483648 to 2147483647	
EE	Application parameter 2	0	
ON	BM_di_ApplicationParam2	1:1 s	CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3316	Applikationsparameter 3	-2147483648 to 2147483647	
EE	Application parameter 3	0	
ON	BM_di_ApplicationParam3	1:1 s	CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3317	Applikationsparameter 4	-2147483648 to 2147483647	
EE	Application parameter 4	0	
ON	BM_di_ApplicationParam4	1:1 s	CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3318	Applikationsparameter 5	-2147483648 to 2147483647	
EE	Application parameter 5	0	
ON	BM_di_ApplicationParam5	1:1 s	CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3319	Applikationsparameter 6	-2147483648 to 2147483647	
EE	Application parameter 6	0	
ON	BM_di_ApplicationParam6	1:1 s	CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

7.3 Parameter description

P3320	Applikationsparameter 7	-2147483648 to 2147483647
EE	Application parameter 7	0
ON	BM_di_ApplicationParam7	1:1 s CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3321	Applikationsparameter 8	-2147483648 to 2147483647
EE	Application parameter 8	0
ON	BM_di_ApplicationParam8	1:1 s CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3322	Applikationsparameter 9	-2147483648 to 2147483647
EE	Application parameter 9	0
ON	BM_di_ApplicationParam9	1:1 s CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3323	Applikationsparameter 10	-2147483648 to 2147483647
EE	Application parameter 10	0
ON	BM_di_ApplicationParam10	1:1 s CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3324	Applikationsparameter 11	-2147483648 to 2147483647
EE	Application parameter 11	0
ON	BM_di_ApplicationParam11	1:1 s CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3325	Applikationsparameter 12	-2147483648 to 2147483647
EE	Application parameter 12	0
ON	BM_di_ApplicationParam12	1:1 s CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3326	Applikationsparameter 13	-2147483648 to 2147483647	
EE	Application parameter 13	0	
ON	BM_di_ApplicationParam13	1:1 s	CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3327	Applikationsparameter 14	-2147483648 to 2147483647	
EE	Application parameter 14	0	
ON	BM_di_ApplicationParam14	1:1 s	CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3328	Applikationsparameter 15	-2147483648 to 2147483647	
EE	Application parameter 15	0	
ON	BM_di_ApplicationParam15	1:1 s	CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3329	Applikationsparameter 16	0 to 4294967295	
EE	Application parameter 16	0	
ON	BM_ud_ApplicationParam16	1:1 s	CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3330	Applikationsparameter 17	0 to 4294967295	
EE	Application parameter 17	0	
ON	BM_ud_ApplicationParam17	1:1 s	CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3331	Applikationsparameter 18	0 _{hex} to FFFFFFFF _{hex}	
EE	Application parameter 18	0	
ON	BM_d_ApplicationParam18	1:1 s	CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

7.3 Parameter description

P3332	Applikationsparameter 19	0 _{hex} to FFFFFFFF _{hex}	
EE	Application parameter 19	0	
ON	BM_d_ApplicationParam19	1:1 s	CW
	Description of the parameters see parameter ▶P3314◀ on page 189.		
P3333	Applikationsparameter 20	-32768 to 32767	
EE	Application parameter 20	0	
ON	BM_i_ApplicationParam20	1:1 s	CW
	Description of the parameters see parameter ▶P3314◀ on page 189.		
P3334	Applikationsparameter 21	-32768 to 32767	
EE	Application parameter 21	0	
ON	BM_i_ApplicationParam21	1:1 s	CW
	Description of the parameters see parameter ▶P3314◀ on page 189.		
P3335	Applikationsparameter 22	-32768 to 32767	
EE	Application parameter 22	0	
ON	BM_i_ApplicationParam22	1:1 s	CW
	Description of the parameters see parameter ▶P3314◀ on page 189.		
P3336	Applikationsparameter 23	0 to 65535	
EE	Application parameter 23	0	
ON	BM_u_ApplicationParam23	1:1 s	CW
	Description of the parameters see parameter ▶P3314◀ on page 189.		
P3337	Applikationsparameter 24	0 to 65535	
EE	Application parameter 24	0	
ON	BM_u_ApplicationParam24	1:1 s	CW
	Description of the parameters see parameter ▶P3314◀ on page 189.		

P3338	Applikationsparameter 25	0 to 65535	
EE	Application parameter 25	0	
ON	BM_u_ApplicationParam25	1:1 s	CW

Description of the parameters see parameter [▶P3314◀](#) on page 189.

P3344	BACI Status	0 _{hex} to FFFF _{hex}	
	BACI status	0 _{hex}	
A	BM_u_BaciStatus	1:1	-

Internal BM_u_BaciStatus.

Value	Meaning
0	Initialization phase
1	Waiting for the hardware enable signal RST of the BACI slaves
2	Ramp-up-/configuration phase
3	Ramp-up completed
4	Normal operation

P3345	BACI Zugriffsfehler Steckplatz G	0 _{hex} to FFFF _{hex}	
	BACI access error slot G	0 _{hex}	
A	BM_w_BaciCntrAccessErrG	1:1	-

Counter for access conflicts with option module.

High byte: Number of access errors at the transmission of actual values

Low byte: Number of access error at the transmission of setpoints.

P3346	BACI Zugriffsfehler AliveCounter Steckplatz G	0 _{hex} to FFFF _{hex}	
	BACI Alive Counter Error Slot G	0 _{hex}	
A	BM_w_BaciCntrAliveG	1:1	-

Counter for alive counter errors (also see [▶Delay errors◀](#) on page 69).

High byte: Number of alive counter error at transmission of actual values

Low byte: Number of alive counter errors at the transmission of setpoints

P3347	Zähler für BACI-Rekonfigurierungsvorgänge Steckplatz G	0_{hex} to FFFF_{hex}	
	BACI reconfiguration counter slot G	0_{hex}	
A	BM_w_BaciCntrReconfigG	1:1	-
	Counter for reconfiguration operations during the current operation		
	High byte: Number of initiation of reconfiguration operations during transmission of actual values		
	Low byte: Number of initiations of reconfiguration operations during setpoint transmissions		
	The characteristic, if a reconfiguration operation was started via actual values or via setpoints, is specified by the firmware of the particular option modules.		
P3348	Zähler zyklischer Austausch von BACI-Sollwerten Steckplatz G	0_{hex} to FFFF_{hex}	
	BACI set data exchange counter slot G	0_{hex}	
A	BM_w_BaciCntrCyclSetValG	1:1	-
	Counter for the cyclic data exchange of setpoints. If, e. g., the cycle time is set to 4 (1 ms), then this counter should have counted to 1000 after error-free cyclic transfer for one second.		
P3349	Zähler zyklischer Austausch von BACI-Istwerten Steckplatz G	0_{hex} to FFFF_{hex}	
	BACI act data exchange counter slot G	0_{hex}	
A	BM_w_BaciCntrCyclActValG	1:1	-
	Counter for den cyclic data exchange of actual values.		
P3350	BACI Kommandozähler Steckplatz G	0_{hex} to FFFF_{hex}	
	BACI command counter slot G	0_{hex}	
A	BM_w_BaciCntrCmdG	1:1	-
	Counter for BACI commands		
	High byte: Number of errors, which have occurred at command processing		
	Low byte: Number of commands		

P3351	BACI Kommandozähler Steckplatz G	0_{hex} to FFFF_{hex}	
	BACI command counter slot G	0_{hex}	
A	BM_w_BaciCntrSrvDataG	1:1	-
	Counter for service data communication. High byte: Number of the reading service data transfer Low byte: Number of the writing service data transfer		
P3385	BACI Zugriffsfehler Steckplatz H	0_{hex} to FFFF_{hex}	
	BACI access error slot H	0_{hex}	
A	BM_w_BaciCntrAccessErrH	1:1	-
	Parameter description see ▶P3345◀ on page 193.		
P3386	BACI Zugriffsfehler AliveCounter Steckplatz H	0_{hex} to FFFF_{hex}	
	BACI alive counter error slot H	0_{hex}	
A	BM_w_BaciCntrAliveH	1:1	-
	Parameter description see ▶P3346◀ on page 193.		
P3387	Zähler für BACI-Rekonfigurierungsvorgänge Steckplatz H	0_{hex} to FFFF_{hex}	
	BACI reconfiguration counter slot H	0_{hex}	
A	BM_w_BaciCntrReconfigH	1:1	-
	Parameter description see ▶P3347◀ on page 194.		
P3388	Zähler zyklischer Austausch von BACI-Sollwerten Steckplatz H	0_{hex} to FFFF_{hex}	
	BACI set data exchange counter slot H	0_{hex}	
A	BM_w_BaciCntrCyclSetValH	1:1	-
	Parameter description see ▶P3348◀ on page 194.		
P3389	Zähler zyklischer Austausch von BACI-Istwerten Steckplatz H	0_{hex} to FFFF_{hex}	
	BACI act data exchange counter slot H	0_{hex}	
A	BM_w_BaciCntrCyclActValH	1:1	-
	Parameter description see ▶P3349◀ on page 194.		

P3390 BACI Kommandozähler Steckplatz H 0_{hex} to FFFF_{hex}
BACI Command Counter Slot H 0_{hex}
A BM_w_BaciCntrCmdH 1:1 -
Parameter description see [▶P3350◀](#) on page 194.

P3391 BACI Kommandozähler Steckplatz H 0_{hex} to FFFF_{hex}
BACI Command Counter Slot H 0_{hex}
A BM_w_BaciCntrSrvDataH 1:1 -
Parameter description see [▶P3351◀](#) on page 195.



APPENDIX A - LIST OF PARAMETERS

Parameter		Range	Standard value	Internal standardization	Page
P0001	Controller type	1 to 2	1	1:1	91
P0002	Controller firmware type	0 to 65535	0	1:1	91
P0003	Controller firmware ID	0 to 65535	0	1:1	91
P0004	Controller firmware version	0.00 to 655.35	0.00	100:1	91
P0005	Parameter table version	0 to 65535	0	1:1	92
P0006	Power unit type code	20 ASCII characters	""	1:1	92
P0007	Power unit serial number	0 to 65535	0	1:1	92
P0008	Power unit data configuration	0 to 65535	0	1:1	92
P0009	Power unit firmware version	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	92
P0012	Power unit nominal current 8kHz	0.0 to 6553.5 A	2.5 A	10:1 A	93
P0013	Power unit peak current 8kHz	0.0 to 6553.5 A	2.5 A	10:1 A	93
P0014	Power unit overload time 1	0.00 to 655.35 s	1.00 s	100:1 s	93
P0015	Power unit overload time 2	0.00 to 655.35 s	1.00 s	100:1 s	93
P0016	Power unit internal device warning temperature	0 to 125 °C	75 °C	1:1	93
P0017	Power unit internal device shutdown temperature	0 to 125 °C	1:1 °C		94
P0018	Power unit heatsink warning temperature	0 to 125 °C	75 °C	1:1 °C	94
P0019	Power unit heatsink shutdown temperature	0 to 125 °C	1:1 °C		94
P0020	Power unit nominal voltage	280 to 1000 V	540 V	1:1 V	94
P0021	Power unit dead time	0.0 to 6553.5 µs	0.0 µs	10:1 µs	94
P0022	Power unit burden factor Iac	-1.65 to 1.65 V	0 V	100:1 V	95
P0023	Power unit burden factor Vdc	0.00 to 10.00 V	0 V	100:1 V	95
P0024	Power unit mode	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	95
P0030	Power unit burden factor Vmain	0 to 65535	0	1:1	95
P0170	PSU actual mains voltage (filtered)	0 to 763.6 V	0 V	4000 _{hex} :100 %	95
P0171	PSU DC link actual mains voltage (filtered)	0 to 1080 V	0 V	4000 _{hex} :100 %	96
P0172	PSU actual mains power	-3276.8 to 3276.7 kW	0 kW	10:1 kW	96
P0173	PSU actual mains frequency	0 to 312.5 Hz	0 Hz	65535/312.5 Hz	96
P0174	PSU status1	0 _{hex} to FFFF _{hex}	0	1:1	96
P0175	PSU status2	0 _{hex} to FFFF _{hex}	0	1:1	97
P0176	PSU status 3	0 _{hex} to FFFF _{hex}	0	1:1	98

Parameter		Range	Standard value	Internal standardization	Page
P0177	PSU DC link controller status	0 _{hex} to FFFF _{hex}	0	1:1	98
P0178	PSU ramp function generator output	0 _{hex} to FFFFFFFF _{hex}	0	1:1	98
P0179	PSU DC link voltage set voltage	280 V to 800 V	640 V	1:1	98
P0180	PSU SVG setpoint 1	280 V to 800 V	640 V	1:1 V	98
P0181	PSU SVG setpoint 2	280 V to 800 V	640 V	1:1 V	99
P0182	PSU SVG setpoint 3	280 V to 800 V	640 V	1:1 V	99
P0183	PSU SVG setpoint 4	280 V to 800 V	640 V	1:1 V	99
P0184	PSU DIO status	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	99
P0200	Error System 1	0 _{hex} to FFFFFFFF _{hex}	0 _{hex}	1:1	100
P0201	Error Processor	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	100
P0202	Error Operating System	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	101
P0203	Error in module Proprog communication	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	101
P0204	Error in function- or option modules	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	102
P0205	Error PSU	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	103
P0206	Error Power Unit	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	104
P0211	Error drive manager	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	105
P0212	Error data set manager	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	105
P0215	Error in module free control section.	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	106
P0216	Error CANsync	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	106
P0233	Error Power Unit serial interface	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	107
P0240	Error function module A	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	108
P0241	Error function module B	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	108
P0242	Error function module C	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	108
P0243	Error function module D	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	109
P0244	Error function module E	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	109
P0245	Error option module G	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	109
P0246	Error in option module H	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	111
P0251	Error communication parameter No.	0 to 65535	0	1:1	111
P0260	Warning System 1	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	112
P0261	Warning PSU	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	112
P0262	Warning Power Unit	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	113
P0290	Client alive timeout	0 to 65535 ms	2000 ms	1:1 ms	113
P0291	Receive timeout proprog protocol	300 to 65535 ms	500 ms	1:1 ms	113
P0298	Error reaction BACI communication	-1 to 3	-1	1:1	114
P0300	Control word	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	114
P0301	Status word	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	117
P0302	Control word 2	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	119
P0303	Status word 2	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	119
P0304	Operation mode actual	-7 to 6	-3	1:1	119
P0305	Drive status	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	120
P0306	Status digital inputs drive manager	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	120
P0308	Status word 3	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	121
P0310	Data set command	0 to 16	0	1:1	121
P0311	Data set status	0 _{hex} to FFFF _{hex}	0	1:1	122
P0312	Active data set number	1 to 8	1	1:1	123

Parameter		Range	Standard value	Internal standardization	Page
P0313	Valid data sets	00 _{hex} to FF _{hex}	01 _{hex}	1:1	124
P0314	Data set source	0 to 8	0	1:1	124
P0315	Data set target	0 to 8	1	1:1	124
P0316	Error data set parameter No.	1 to max. Para No.	-	1:1	125
P0317	EEPROM write count	1 to 65535	1:1		125
P0318	PSI write count	1 to 65535	1:1		125
P0319	PSI parameter number	1 to 65535	1:1		125
P0320	PSI array index	0 to 65535	1:1		125
P0321	PSI parameter data width	0 to 65535	1:1		126
P0322	PSI parameter value (32 Bit)	0 _{hex} to FFFFFFFF _{hex}	1:1		126
P0323	PSI string parameter	40 ASCII characters	""	1:1	126
P0324	PSI data set selection	1 to 4	1:1		126
P0325	PSI valid data sets	0 to 65535	1:1		126
P0326	Data set manager mode	0 to 65535	1:1		127
P0327	Boot data set	1 to 8	1	1:1	127
P0330	Current controller status	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	127
P0332	Current Iq setpoint	-200,00 to +200.00 %	0.00 %	4000 _{hex} :100 %	127
P0333	Current Iq actual value	-200,00 to +200.00 %	0.00 %	4000 _{hex} :100 %	127
P0334	Current Iq controller output	-200,00 to +200.00 %	0.00 %	4000 _{hex} :100 %	128
P0335	Current Id setpoint	-100.00 to +100.00 %	0.00 %	4000 _{hex} :100 %	128
P0336	Current Id Actual value	-200,00 to +200.00 %	0.00 %	4000 _{hex} :100 %	128
P0337	Current Id controller output	-200,00 to +200.00 %	0.00 %	4000 _{hex} :100 %	128
P0338	Voltage EMF setpoint	-200,00 to +200.00 %	0.00 %	4000 _{hex} :100 %	128
P0339	Voltage Vq setpoint	-200,00 to +200.00 %	0.00 %	4000 _{hex} :100 %	129
P0340	Voltage Vd setpoint	-200,00 to +200.00 %	0.00 %	4000 _{hex} :100 %	129
P0341	Current phase U actual value	-200,00 to +200.00 %	0.00 %	4000 _{hex} :100 %	129
P0342	Current phase V actual value	-200,00 to +200.00 %	0.00 %	4000 _{hex} :100 %	129
P0343	Apparent current actual value	-200,00 to +200.00 %	0.00 %	4000 _{hex} :100 %	129
P0410	Function module A: status digital input	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	130
P0411	Function module B: status digital input	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	130
P0412	Function module C: status digital input	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	131
P0413	Function module D: status digital input	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	131
P0414	Function module E: status digital input	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	131
P0418	Function module D: Status digital output	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	132
P0419	Function module E: Status digital output	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	132
P0420	Analog input 1 actual value	-100.00 to +100.00 %	0.00 %	7FFF _{hex} :100%	133
P0421	Analog input 2 actual value	-100.00 to +100.00 %	0.00 %	7FFF _{hex} :100%	133
P0430	Ramp Function Generator status	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	133
P0440	Setpoint generator mode	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	134
P0441	SVG time 1	0.001 to 65.535 s	1.000	1000:1 s	134
P0443	SVG time 2	0.001 to 65.535 s	1.000	1000:1 s	134
P0445	SVG time 3	0.001 to 65.535 s	1.000	1000:1 s	134
P0447	SVG time 4	0.001 to 65.535 s	1.000	1000:1 s	135
P0449	Setpoint generator output	0 to 65535	600	1:1	135
P0480	Power unit status	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	135

Parameter		Range	Standard value	Internal standardization	Page
P0481	Power unit internal device actual temperature	0 to 125 °C	0 °C	1:1 °C	136
P0482	Power unit heatsink actual temperature	0 to 125 °C	0 °C	1:1 °C	136
P0484	Power unit DC-link actual value	0 to 10290 V	0 V	4000 _{hex} :540 V	136
P0485	Power unit Ixt actual value	0 to 400.0 %	0.0 %	2000 _{hex} :100 %	136
P0487	Switching PWM mode	0.00 to 100.00 %	100.00 %	4000 _{hex} :100 %	136
P0490	PSU status 3	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	137
P0540	CAN mode	0 to 1	0	1:1	137
P0541	CAN status	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	137
P0542	CAN baud rate (config)	125 to 1000 kBit/s	125 kBit/s	1:1 kBit/s	137
P0543	CAN baud rate (DIP switch)	125 to 1000 kBit/s	125 kBit/s	1:1 kBit/s	137
P0544	CAN baud rate (active)	125 to 1000 kBit/s	125 kBit/s	1:1 kBit/s	138
P0545	CAN slave number (config)	0 to 128	0	1:1	138
P0546	CAN slave number (DIP-switch)	0 to 128	0	1:1	138
P0547	CAN slave number (active)	0 to 128	0	1:1	138
P0550	Module type slot A	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	139
P0551	Module type slot B	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	140
P0552	Module type slot C	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	140
P0553	Module type slot D	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	141
P0554	Module type slot E	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	141
P0555	FPGA version	0 _{hex} to FFFF _{hex}	0	1:1	141
P0556	Bootloader firmware version	0 to 65535	0	1:1	141
P0557	Programming request	0 to 1	0	1:1	141
P0558	Configuration ID	0 to 4294967295	0	1:1	141
P0559	Drive name	80 ASCII characters	""	1:1	142
P0575	Digital input channel for error acknowledge	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	142
P0579	Function module selection for PLC I/O-access	0 _{hex} to 1F _{hex}	0 _{hex}	1:1	143
P0800	Option module 1 master cycle time	0 to 32000 µs	4000 µs	1:125 µs	144
P0801	Option module 1 master 1 parameter No. setpoint 1	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	144
P0802	Option module 1 master 1 parameter No. setpoint 2	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	144
P0803	Option module 1 master 1 parameter No. setpoint 3	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	144
P0804	Option module 1 master 1 parameter No. setpoint 4	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	145
P0805	Option module 1 master 1 parameter No. setpoint 5	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	145
P0806	Option module 1 master 1 parameter No. setpoint 6	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	145
P0807	Option module 1 master 1 parameter No. setpoint 7	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	145
P0808	Option module 1 master 1 parameter No. setpoint 8	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	145
P0809	Option module 1 master 1 parameter No. act value 1	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	145
P0810	Option module 1 master 1 parameter No. act value 2	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	146
P0811	Option module 1 master 1 parameter No. act value 3	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	146
P0812	Option module 1 master 1 parameter No. act value 4	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	146
P0813	Option module 1 master 1 parameter No. act value 5	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	146
P0814	Option module 1 master 1 parameter No. act value 6	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	146
P0815	Option module 1 master 1 parameter No. act value 7	0 _{hex} to FFFF _{hex}	0 _{hex} ⁰	1:1	146
P0816	Option module 1 master 1 parameter No. act value 8	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	147
P0817	Option module 1 master 1 trigger offset	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	147
P0818	Option module 1 master 1 cycle offset setpoints	0 _{hex} to FFFF _{hex}	2	1:1	147

Parameter		Range	Standard value	Internal standardization	Page
P0819	Option module 1 master 1 cycle offset act. values	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	147
P0827	Option module select	0 to 6	0	1:1	147
P0830	Option module G configuration 1	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	148
P0831	Option module G configuration 2	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	149
P0832	Option module G configuration 3	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	149
P0833	Option module G configuration 4	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	149
P0834	Option module G configuration 5	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	150
P0835	Option module G configuration 6	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	150
P0836	Option module G configuration 7	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	150
P0837	Option module G configuration 8	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	151
P0838	BACI Setup Timeout	0 to 65535 s	60 s	1:1 s	151
P0839	BACI cyclic communication timeout	0 to 65535 ms	50 ms	1:1 ms	151
P0840	Option module H configuration 1	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	151
P0841	Option module H configuration 2	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	151
P0842	Option module H configuration 3	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	152
P0843	Option module H configuration 4	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	152
P0844	Option module H configuration 5	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	152
P0845	Option module H configuration 6	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	152
P0846	Option module H configuration 7	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	152
P0847	Option module H configuration 8	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	153
P0848	Baci error detection delay	0 to 65535 s	30 s	1:1 s	153
P0860	Option module 2 master cycle time	0 to 32000 μs	4000 μs	1:125 μs	154
P0861	Option module 2 master 1 parameter No. setpoint 1	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	154
P0862	Option module 2 master 1 parameter No. setpoint 2	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	154
P0863	Option module 2 master 1 parameter No. setpoint 3	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	154
P0864	Option module 2 master 1 parameter No. setpoint 4	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	155
P0865	Option module 2 master 1 parameter No. setpoint 5	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	155
P0866	Option module 2 master 1 parameter No. setpoint 6	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	155
P0867	Option module 2 master 1 parameter No. setpoint 7	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	155
P0868	Option module 2 master 1 parameter No. setpoint 8	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	155
P0869	Option module 2 master 1 parameter No. act value 1	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	155
P0870	Option module 2 master 1 parameter No. act value 2	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	156
P0871	Option module 2 master 1 parameter No. act value 3	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	156
P0872	Option module 2 master 1 parameter No. act value 4	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	156
P0873	Option module 2 master 1 parameter No. act value 5	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	156
P0874	Option module 2 master 1 parameter No. act value 6	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	156
P0875	Option module 2 master 1 parameter No. act value 7	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	156
P0876	Option module 2 master 1 parameter No. act value 8	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	157
P0877	Option module 2 master 1 trigger offset	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	157
P0878	Option module 2 master 1 cycle offset setpoints	0 _{hex} to FFFF _{hex}	2	1:1	157
P0879	Option module 2 master 1 cycle offset act. values	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	157
P1000	Operation mode desired	-7 to 6	-3	1:1	158
P1001	Communication source	0 _{hex} to 000F _{hex}	0001 _{hex}	1:1	158
P1002	Drive manager options	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	159
P1007	Error reaction code	0 to 3	0	1:1	159

Parameter		Range	Standard value	Internal standardization	Page
P1008	Mask for internal limits	0 _{hex} to FFFF _{hex}	FFFF _{hex}	1:1	159
P1010	Data set ID	0 to 65535	0	1:1	160
P1011	Data set name	80 ASCII characters	""	1:1	160
P1020	Current controller P-gain	0.01 to 655.35	1.00	100:1	160
P1021	Current controller integral-action time	0.0 to 1000.0 ms	2.5 ms	10:1 ms	160
P1023	Current controller output limiter	0 to 199.99 %	199.99 %	4000 _{hex} :100 %	160
P1037	Torque limiter motor/TD1	0.00 to 100.00%	100.00 %	4000 _{hex} :100 %	161
P1038	Torque limiter Generator/TD2	0.00 to 100.00%	100.00 %	4000 _{hex} :100 %	161
P1090	Selection digital input 1	0 _{hex} to 0508 _{hex}	0 _{hex}	1:1	161
P1091	Target number: digital input 1	0 to max. Para No.	0	1:1	162
P1092	Bit selection digital input 1	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	162
P1093	Set bit pattern for LOW state digital input 1	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	162
P1094	Set bit pattern for HIGH state digital input 1	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	162
P1095	Selection digital input 2	0 _{hex} to 0508 _{hex}	0 _{hex}	1:1	162
P1096	Target number: digital input 2	0 to max. para No.	0	1:1	163
P1097	Bit selection digital input 2	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	163
P1098	Set bit pattern LOW state digital input 2	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	163
P1099	Set bit pattern HIGH state digital input 2	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	163
P1100	Selection digital input 3	0 _{hex} to 0508 _{hex}	0 _{hex}	1:1	163
P1101	Target number: digital input 3	0 to max. para No.	0	1:1	164
P1102	Bit selection digital input 3	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	164
P1103	Set bit pattern for LOW state digital input 3	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	164
P1104	Set bit pattern for HIGH state digital input 3	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	164
P1105	Selection digital input 4	0 _{hex} to 0508 _{hex}	0 _{hex}	1:1	164
P1106	Target number: digital input 4	0 to max. para No.	0	1:1	165
P1107	Bit selection digital input 4	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	165
P1108	Set bit pattern for LOW state digital input 4	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	165
P1109	Set bit pattern for HIGH state digital input 4	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	165
P1110	Selection digital output 1	0 _{hex} to 0508 _{hex}	0 _{hex}	1:1	165
P1111	Source number digital output 1	0 to max. para No.	0	1:1	166
P1112	Bit selection digital output 1	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	166
P1113	Bit pattern digital output 1	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	166
P1114	Selection digital output 2	0 _{hex} to 0508 _{hex}	0 _{hex}	1:1	166
P1115	Source number digital output 2	0 _{hex} to max. para-No.	0	1:1	166
P1116	Bit selection digital output 2	0 _{hex} to 0508 _{hex}	0 _{hex}	1:1	167
P1117	Bit pattern digital output 2	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	167
P1118	Selection digital output 3	0 _{hex} to 0508 _{hex}	0 _{hex}	1:1	167
P1119	Source number digital output 3	0 to max. para No.	0	1:1	167
P1120	Bit selection digital output 3	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	167
P1121	Bit pattern digital output 3	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	168
P1122	Selection digital output 4	0 _{hex} to 0508 _{hex}	0 _{hex}	1:1	168
P1123	Source number digital output 4	0 to max. para No.	0	1:1	168
P1124	Bit selection digital output 4	0 _{hex} to FFFF _{hex}	0008 _{hex}	1:1	168
P1125	Bit pattern digital output 4	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	168
P1130	Selection analog input 1	0 _{hex} to 0508 _{hex}	0 _{hex}	1:1	169

Parameter		Range	Standard value	Internal standardization	Page
P1131	Smoothing time analog input 1	0.000 to 60.000 ms	1.000 ms	1000:1 ms	169
P1132	Scaling factor analog input 1	-2.0 to 2.0	1.0	3FFF _{hex} :1	169
P1133	Target number: analog input 10	0 to max. para No.	0	1:1	169
P1134	Offset analog input 1	-100.00 % to +100.00 %	0.00 %	7FFF _{hex} :100 %	170
P1135	Threshold value analog input 1	0.00 % to +100.00 %	0.00 %	7FFF _{hex} :100 %	170
P1136	Selection analog input 2	0 _{hex} to 0508 _{hex}	0 _{hex}	1:1	170
P1137	Smoothing time analog input 2	0.000 to 60.000 ms	1.000 ms	1000:1 ms	170
P1138	Scaling factor analog input 2	-2.0 to 2.0	1.0	7FFF _{hex} :1	170
P1139	Target number analog input 2	0 to max. para No.	0	1:1	171
P1140	Offset analog input 2	-100.00 % to +100.00 %	0.00 %	7FFF _{hex} :100 %	171
P1141	Threshold value analog input 2	0.00 % to +100.00 %	0.00 %	7FFF _{hex} :100 %	171
P1150	Selection fast analog output 1	0 _{hex} to 0508 _{hex}	0 _{hex}	1:1	171
P1151	Source number fast analog output 1	0 to max. para No.	0	1:1	171
P1152	Offset fast analog output 1	-10.00 to +10.00V	0 V	7FFF _{hex} :10 V	172
P1153	Scaling fast analog output 1	67108863.00 to 67108863.00	1.00	32:1	172
P1154	Selection fast analog output 2	0 _{hex} to 0508 _{hex}	0 _{hex}	1:1	172
P1155	Source number fast analog output 2	0 to max. para No.	0	1:1	172
P1156	Offset fast analog output 2	-10.00 to +10.00V	0.0 V	7FFF _{hex} :10 V	172
P1157	Scaling fast analog output 2	67108863.00 to 67108863.00	1.00	32:1	173
P1170	Ramp function generator mode	0 _{hex} to FFFF _{hex}	0 _{hex}	4000 _{hex} :100 %	174
P1172	Ramp function generator ramp-up time	0.00 to 650.00 s	0.00 s	100:1 s	174
P1173	Ramp function generator ramp-down time	0.00 to 650.00 s	0.00 s	100:1 s	174
P1175	Ramp function generator smoothing time	0 to 32 ms	0 ms	1:1 ms	174
P1241	Power unit maximum drive current	0.1 to 6553.5 A	2.5 A	10:1 A	175
P1251	DC-link controller P-gain	1.0 to 255.9	50.0	10:1	175
P1252	DC-link controller integral-action time	0.2 to 1000.0 ms	20.0 ms	10:1 ms	175
P1260	Blocking time	0.0 to 6500.0 s	10.0 s	10:1 s	175
P1290	Parameter selection statusbit 14	0 to max. para No.	0	1:1	176
P1291	Bit pattern status bit 14	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	176
P1292	Parameter selection statusbit 15	0 to max. para No.	0	1:1	176
P1293	Bit mask for status bit 15	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	176
P1340	PSU power factor setpoint	-1.0 to 1.0	1.0	65535:1	176
P1342	PSU DC link voltage smoothing time	0 to 60.0 ms	1.0 ms	10:1 ms	177
P1343	PSU max. DC link voltage setpoint	300 to 800 V	760 V	1:1 V	177
P1344	PSU min. DC link voltage setpoint	280 to 800 V	360 V	1:1 V	177
P1345	PSU main voltage feed forward factor	0% to 125 %	100 %	4000 _{hex} :100 %	177
P1346	PSU mains voltage feed forward smoothing time	0 to 50 ms	1.0 ms	10:1 ms	177
P1347	PSU Id setpoint	-100.0 % to +100.0 %	0.0 %	4000 _{hex} :100 %	178
P1348	PSU mode 1	0000 _{hex} to FFFF _{hex}	FFFD _{hex}	1:1 ms	178
P1349	PSU max. Id deviation	-100.0 % to +100.0 %	0.0 %	4000 _{hex} :100 %	178
P1350	PSU offset rho	-30.0 ° to +30.0 °	0.0 °	4000 _{hex} : 360 °	178
P1351	PSU max. Iq deviation	-100.0 % to +100.0 %	0.0 %	4000 _{hex} : 100 %	178
P1352	PSU max. DC link voltage deviation	-100.0 % to +100.0 %	0.0 %	4000 _{hex} : 100 %	179
P1353	PSU ramp function generator input	280 V to 800 V	640 V	1:1 V	179
P1354	PSU mains undervoltage warning	360 V to 500 V	180 V	10:1 V	179

Parameter		Range	Standard value	Internal standardization	Page
P1355	PSU mains overvoltage warning	400 V to 528 V	400 V	10:1 V	179
P1356	PSU contactor confirmation supervision time	0,000 to 10,000 s	1,000 s	1000:1 s	179
P1357	PSU Precharge cycle	0,000 bis 120,000 s	0 s	1000:1 s	179
P1358	PSU Mains warning power	0,000 bis 3276,7 kW	30,0 kW	10:1 kW	180
P1359	PSU Mains max. load time	1,00 bis 600,00 s	30,00 s	1000:1 s	180
P2000	Oscilloscope source channel 1	0 _{hex} to FFFFFFFF _{hex}	0 _{hex}	1:1	181
P2001	Oscilloscope source channel 2	0 _{hex} to FFFFFFFF _{hex}	0 _{hex}	1:1	181
P2002	Oscilloscope source channel 3	0 _{hex} to FFFFFFFF _{hex}	0 _{hex}	1:1	181
P2003	Oscilloscope source channel 4	0 _{hex} to FFFFFFFF _{hex}	0 _{hex}	1:1	181
P2004	Oscilloscope source channel 5	0 _{hex} to FFFFFFFF _{hex}	0 _{hex}	1:1	181
P2005	Oscilloscope source channel 6	0 _{hex} to FFFFFFFF _{hex}	0 _{hex}	1:1	182
P2006	Oscilloscope source channel 7	0 _{hex} to FFFFFFFF _{hex}	0 _{hex}	1:1	182
P2007	Oscilloscope source channel 8	0 _{hex} to FFFFFFFF _{hex}	0 _{hex}	1:1	182
P2008	Oscilloscope trigger source 1	0 _{hex} to FFFFFFFF _{hex}	0 _{hex}	1:1	182
P2009	Oscilloscope trigger source 2	0 _{hex} to FFFFFFFF _{hex}	0 _{hex}	1:1	182
P2010	Mask trigger source 1	0 _{hex} to FFFFFFFF _{hex}	FFFFFFF _{hex}	1:1	183
P2011	Mask trigger source 2	0 _{hex} to FFFFFFFF _{hex}	FFFFFFF _{hex}	1:1	183
P2012	Trigger compare operator 1	0 to 3	0	1:1	183
P2013	Trigger compare operator 2	0 to 3	0	1:1	184
P2014	Trigger compare value 1	0 _{hex} to FFFFFFFF _{hex}	FFFFFFF _{hex}	1:1	184
P2015	Trigger compare value 2	0 _{hex} to FFFFFFFF _{hex}	FFFFFFF _{hex}	1:1	184
P2016	Trigger source combination operator	1 to 3	1	1:1	185
P2017	Trigger delay in %	0 to 100 %	0 %	1:1 %	185
P2018	Trigger status	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	185
P2019	Trigger command	1 to 6	1	1:1	186
P2020	Transient samples	0 _{hex} to FFFFFFFF _{hex}	0 _{hex}	1:1	186
P2021	Sample rate	0.125 ms to 8191 ms	0.125 ms	1:0.125 ms	186
P2022	Measurement time	0 to 32 ms	0 ms	1:1 ms	186
P2023	Oscilloscope memory length	1024 to 16384	1024	1:1	187
P2024	Oscilloscope memory start address	0 _{hex} to FFFFFFFF _{hex}	0 _{hex}	1:1	187
P2025	Oscilloscope error code	0 to 65535	0 _{hex}	1:1	187
P2030	Password	0 to 65535	0	1:1	188
P2032	System time	0 to 4294967295 s	0 s	1:1 s	188
P2034	Time since last boot	0 to 4294967295 s	0 s	1:1 s	188
P2035	Power on seconds	0 to 4294967295 s	0 s	1:1 s	188
P3314	Application parameter 1	-2147483648 to 2147483647	0	1:1 s	189
P3315	Application parameter 2	-2147483648 to 2147483647	0	1:1 s	189
P3316	Application parameter 3	-2147483648 to 2147483647	0	1:1 s	189
P3317	Application parameter 4	-2147483648 to 2147483647	0	1:1 s	189
P3318	Application parameter 5	-2147483648 to 2147483647	0	1:1 s	189
P3319	Application parameter 6	-2147483648 to 2147483647	0	1:1 s	189
P3320	Application parameter 7	-2147483648 to 2147483647	0	1:1 s	190
P3321	Application parameter 8	-2147483648 to 2147483647	0	1:1 s	190
P3322	Application parameter 9	-2147483648 to 2147483647	0	1:1 s	190
P3323	Application parameter 10	-2147483648 to 2147483647	0	1:1 s	190

Parameter		Range	Standard value	Internal standardization	Page
P3324	Application parameter 11	-2147483648 to 2147483647	0	1:1 s	190
P3325	Application parameter 12	-2147483648 to 2147483647	0	1:1 s	190
P3326	Application parameter 13	-2147483648 to 2147483647	0	1:1 s	191
P3327	Application parameter 14	-2147483648 to 2147483647	0	1:1 s	191
P3328	Application parameter 15	-2147483648 to 2147483647	0	1:1 s	191
P3329	Application parameter 16	0 to 4294967295	0	1:1 s	191
P3330	Application parameter 17	0 to 4294967295	0	1:1 s	191
P3331	Application parameter 18	0 _{hex} to FFFFFFFF _{hex}	0	1:1 s	191
P3332	Application parameter 19	0 _{hex} to FFFFFFFF _{hex}	0	1:1 s	192
P3333	Application parameter 20	-32768 to 32767	0	1:1 s	192
P3334	Application parameter 21	-32768 to 32767	0	1:1 s	192
P3335	Application parameter 22	-32768 to 32767	0	1:1 s	192
P3336	Application parameter 23	0 to 65535	0	1:1 s	192
P3337	Application parameter 24	0 to 65535	0	1:1 s	192
P3338	Application parameter 25	0 to 65535	0	1:1 s	193
P3344	BACI status	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	193
P3345	BACI access error slot G	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	193
P3346	BACI Alive Counter Error Slot G	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	193
P3347	BACI reconfiguration counter slot G	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	194
P3348	BACI set data exchange counter slot G	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	194
P3349	BACI act data exchange counter slot G	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	194
P3350	BACI command counter slot G	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	194
P3351	BACI command counter slot G	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	195
P3385	BACI access error slot H	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	195
P3386	BACI alive counter error slot H	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	195
P3387	BACI reconfiguration counter slot H	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	195
P3388	BACI set data exchange counter slot H	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	195
P3389	BACI act data exchange counter slot H	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	195
P3390	BACI Command Counter Slot H	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	196
P3391	BACI Command Counter Slot H	0 _{hex} to FFFF _{hex}	0 _{hex}	1:1	196



Table of figures

Overview	10
Current controller	11
U_{DC} link controller	12
Data set management controller - PSI	14
Active data set.....	16
Start screen PorDrive.....	31
ProDrive - start	32
ProDrive - startpage b maXX 4100	33
ProDrive: Navigation	34
Starting sequence	35
ProDrive: Navigation	36
ProDrive: Device manager	37
ProDrive: Navigation	38
ProDrive: Power unit	38
ProDrive: Start page with the used modules.....	39
ProDrive 1.14: Data set management window	40
ProDrive: Ramp function generator.....	40
ProDrive: Ramp function generator - icon bar.....	41
ProDrive: Drive manager.....	41
ProDrive: Drive manager.....	41
ProDrive: Ramp function generator - icon bar.....	42
WinBASS II: Data set management	42
WinBASS II: Project tree	43
Example for a motor overload monitoring	45
Characteristic curve power factor.....	48
Edge evaluation of digital inputs	49
Example characteristics analog input.....	57
b maXX [®] option card bus.....	63
BACI timing cyclic communication	67
Introduction of the device control	73
Device control status machine	74
Setpoint generator U_{DC} -setpoint variation	80
DC link voltage depending on the mains voltage	81
Parameter description scheme	89
Construction of internal parameter name.....	89
Controller software version	91
Software version of power unit.....	92



Table of figures



Index

A			
Analog inputs	54	Filtered mains voltage	95
Analog outputs	57	Fix setpoint	79
Application	69	Following parameters	90
Attributes	88	FPGA	141
B			
BACI	114, 195	H	
Boot data set	19	Heatsink temperature	94
C			
Calculation basis	58	I	
CANopen	86	I/O modules	61
Command interface	15	L	
Commissioning	29	LED H-2	36
Communication source	158	LED H-3	36
Configuration	45	LED H-4	36
Configuration phase	151	Load data set	22
Control word	114	M	
Controller type	91	Main contactor	97
Create data set	21	Mains frequency	96, 97
Cycle time	144	Mains voltage	81
Cyclic transfer	66	Module slot	130
D		Module type	140
Data set	123, 127	Monitoring time	179
marking	18	N	
start-up action	17	Note	7
switching	26	O	
Data set management	13, 19, 105, 121	Operating system	101
Data set parameter	16	Operation mode	119
Data type	87	Option module	144, 152, 154
DC link voltage	94	Oscilloscope function	181
Dead time	94	Overload monitoring	45
Deviation	179	Overload time	93
Diagnosis	69, 82	Overvoltage	96
Digital input	165	P	
Digital inputs	49	Parameter	
Digital output	168	change	18
Digital outputs	52	load	18
Drive management	70	store	18
Drive manager	105	Parameter description	91
E		Structure	89
EEPROM	122	Parameter descriptions	89
EMF feed forward	128	Parameter name	89
Error monitoring	68	Parameter Storage Interface	14
Evaluation factor	177	Peak current	93
Executing commissioning	36	Phase failure	96
F		Phase sequence	97
Field bus	86	PLC	59
Field buses	86	Power failure	96
Filtered DC-link voltage	96	Power unit	45
		Precharging	97



Index

Preconditions	30
Preparations	30
Processor	100
Project tree	43
Proprog	101
PSI	14, 125
Pulse enable	30

R

Ramp function generator	79, 133, 174
Range of numbers	85
Record set command	21
Reserved bits	88
Reset error	116
RS232	30
RS232-cable connector	36

S

Scaling factor	169
Sercos	86
Serial number	92
Setpoint generator	99, 134
Setpoint generators	79
Shutdown temperature	94
Starting sequence	35
Status bit	176
Status machine	74
Status word	117
Store data set	23
Switching elements	30
System overview	63
System time	188

T

Temperature	93
Time controlled setpoint	80
Time slices	44
Torque limit	161

U

Undervoltage	96
--------------	----

W


WarnIng	7
Warning	112
WinBASS II	36



Revision survey

Version	Date of issue	Changing
5.04054.03	21.06.2006	First issue
5.04054.04	10.11.2006	P0022, P0171 modified, P0487 inserted, default values P1090 to P1094 and P1110 to P1125 modified
5.04054.05	13.03.2008	Unregulated DC link voltage
5.04054.06	09.11.2012	Setting of the power factor, new parameters P1350/1359
5.04054.0	26.05.2014	P0449 and P1344: errors eliminated Chapter Commissioning updated

be in motion



Baumüller Nürnberg GmbH Ostendstraße 80-90 90482 Nürnberg T: +49(0)911-5432-0 F: +49(0)911-5432-130 www.baumueller.de

All information given in this manual is customer information, subject to change without notice. We reserve the right to further develop and actualize our products continuously using our permanent revision service. Please notice, that specifications/data/information are current values according to the printing date. These statements are not legally binding according to the measurement, computation and calculations. Before you make any information given in this manual to the basis of your own calculations and/or applications, please make sure that you have the latest edition of the information in hand. No liability can be accepted concerning the correctness of the information.