







Title	Application Manual
Product	b maXX drive PLC BM4-O-PLC-01
Last Revision:	01 March 2007
Copyright	Owners may make as many copies as they like of this Application Manual exclusively for their own internal use. You are not allowed to copy or duplicate even extracts from this Application Manual for any other purposes. You are not permitted to exploit or communicate the contents of this Application Manual. Any other designations or company logos used in this Application Manual may be trademarks whose use by third parties for their own purposes may affect the rights of the owner of the trademark.
Binding nature	This Application Manual is a part of the unit/machine. This Application Manual must always be available to operators and be legible. If the unit/machine is sold, the owner must pass on this Application Manual together with the unit/ma- chine. After selling the unit/machine you must pass on this origi- nal and all the copies that you made to the purchaser. After disposing of the machine in any way, you must destroy this original and all the copies that you made.
	 When you pass on this Application Manual, all earlier revisions of the corresponding Application Manual are invalidated. Note that all the data/numbers/information that are quoted are current values at the time of printing. This information is not legally binding for dimensioning, calculation and costing. Within the scope of further-development of our products, Baumüller Nürnberg GmbH reserve the right to change the technical data and handling.
	We cannot guarantee this Application Manual is complete- ly error-free unless this is expressly indicated in our Gen- eral Conditions of Business and Delivery.
Manufacturer	Baumüller Nürnberg GmbH Ostendstr. 80 - 90 90482 Nuremberg Germany Tel. +49 9 11 54 32 - 0 Fax: +49 9 11 54 32 - 1 30 www.baumueller.de



TABLE OF CONTENTS

1 Int	roduction
1.1	First Steps
1.2	Terms Used
2 Ba	sic Safety Instructions
21	Hazard information and instructions
211	Structure of hazard information 8
212	Hazard advisories that are used
2.1.2	Information signs
2.3	Legal information 11
2.0	Appropriate Lise 11
2.5	Inappropriate Lise 12
2.6	Protective equipment 12
27	Personnel training
2.8	Safety measures in normal operation 13
2.9	Responsibility and liability 13
291	Observing the hazard information and safety instructions 13
292	Danger arising from using this module
2.9.3	Warranty and Liability 14
	· · · · ·
3 Cc	mmissioning
3.1	General safety regulations
3.2	Requirements of the personnel carrying out work
3.3	Description/inspection of the safety and monitoring systems
3.4	Description and inspection of the controls and displays
3.4.1	LEDs for displaying operating status of BM4-O-PLC-01
3.4.2	S1 switch/pushbutton for changing operating status conditions of the BM4-O-PLC-01. 17
3.5	Commissioning sequence
3.5.1	Activation
3.5.2	Testing the function
3.5.3	Sending a boot project 19
4 Or	peration
4.1	Programming systems PROPROG wt II and ProProg wt III
4.2	b maXX drive PLC project
4.3	b maXX drive PLC configuration 27
4.4	b maXX drive PLC resource
4.4.1	Communication and Connection
4.4.2	Control Dialog for Resources
4.4.3	Data Area
4.4.4	b maXX drive PLC event tasks 45
4.5	b maXX drive PLC user libraries 47
4.5.1	b maXX drive PLC firmware 49
4 = 0	h maXX drive PLC Board functions
4.5.2	
4.5.2 4.5.3	b maXX drive PLC data types
4.5.2 4.5.3 4.5.4	b maXX drive PLC data types
4.5.2 4.5.3 4.5.4 4.5.5	b maXX drive PLC data types
4.5.2 4.5.3 4.5.4 4.5.5 4.5.6	b maxx drive PLC data types 55 The Standard Function Block Libraries 59 b maXX drive PLC technology components 60 Inserting a User Library into a Project 60







4

INTRODUCTION

This b maXX drive PLC Application Manual is an important component of your b maXX 4400; this means that you must thoroughly read this document, not least to ensure your own safety.

It is assumed that you have understood and used the b maXX drive PLC Operating Instructions.

In this chapter, we will describe the first steps that you should carry out after getting this unit. We will define terms that are used in this documentation on a consistent basis and will inform you about the responsibilities you must consider when using this unit.

1.1 First Steps

- Check the shipment.
- Pass on all the documentation that was supplied with the plug-in module to the appropriate departments in your company.
- Deploy suitable personnel for assembly and commissioning.
- Pass on these operating instructions to this personnel and ensure that they have read and understood the safety instructions and that they are following them.

1.2 Terms Used

In this documentation, we will also refer to Baumüller's "**b maXX drive PLC**" product as "option module", "plug-in module", "b maXX PLC" or only "PLC". Furthermore we will use the term BM4-O-PLC-01.

For a list of the abbreviations that are used, refer to ▷Appendix A Abbreviations ◄ from page 165 onward.

We will also use the term "b maXX" for the "Basic Unit b maXX 4400" product.

The controller in the basic unit is also referred to as the "b maXX controller".



1.2 Terms Used

BASIC SAFETY INSTRUCTIONS

We have designed and manufactured each Baumüller plug-in module in accordance with the strictest safety regulations. Despite this, working with the plug-in module can be dangerous for you.

In this chapter, we will describe the risks that can occur when working with a Baumüller plug-in module. Risks are illustrated by icons. All the symbols that are used in this documentation are listed and explained.

In this chapter, we cannot explain how you can protect yourself from specific risks in individual cases. This chapter contains only general protective measures. We will go into concrete protective measures in subsequent chapters directly after information about the individual risk.

2.1 Hazard information and instructions



WARNING

The following **may occur**, if you do not observe this warning information:

• serious personal injury • death

The hazard information is showing you the hazards which can lead to injury or even to death.

Always observe the hazard information given in this documentation.

Hazards are always divided into three danger classifications. Each danger classification is identified by one of the following words:

DANGER

• Considerable damage to property • Serious personal injury • Death will occur

WARNING

• Considerable damage to property • Serious personal injury • Death can occur



CAUTION

• Damage to property • Slight to medium personal injury can occur

2.1.1 Structure of hazard information

the hazard is.

The following two examples show how hazard information is structured in principle. A triangle is used to warn you about danger to living things. If there is no triangle, the hazard information refers exclusively to damage to property.



A triangle indicates that there is danger to living things. The color of the border shows how severe the hazard is: the darker the color, the more severe the hazard is.



The icon in the circle represents an instruction. Users must follow this instruction. (The circle is shown dashed, since an instruction is not available as an icon for each hazard advisory).

The color of the border shows how severe the hazard is: the darker the color, the more severe



The circle shows that there is a risk of damage to property.

The icon in the rectangle represents the hazard.



8

of 168

The icon in the rectangle represents the hazard. The color of the border shows how severe the hazard is: the darker the color, the more severe the hazard is. (The rectangle is shown dashed, since the danger is not represented as an icon with every hazard advisory)

The text next to the icons is structured as follows:

THE SIGNAL WORD IS HERE THAT SHOWS THE DEGREE OF RISK

Here we indicate whether one or more of the results below occurs if you do not observe this warning.

• Here, we describe the possible results. The worst result is always at the extreme right.

Here, we describe the hazard.

Here, we describe what you can do to avoid the hazard.

2.1.2 Hazard advisories that are used

If a signal word is preceded by one of the following danger signs: Λ or Λ or Λ , the safety information refers to injury to people.

If a signal word is preceded by a round danger sign: (]) , the safety information refers to damage to property.

2.1.2.1 Hazard advisories about injuries to people

To be able to differentiate visually, we use a separate border for each class of hazard information with the triangular and rectangular pictograms.

For danger classification **DANGER**, we use the Λ danger sign. The following hazard information of this danger classification is used in this documentation.



DANGER

The following **will occur**, if you do not observe this danger information:

serious personal injury
 death

Danger from: electricity. The hazard may be described in more detail here.

Here, we describe what you can do to avoid the hazard.



DANGER

The following **will occur**, if you do not observe this danger information:

• serious personal injury • death

Danger from: mechanical effects. The hazard may be described in more detail here.

Here, we describe what you can do to avoid the hazard.

For danger classification **WARNING**, we use the \triangle danger sign. The following hazard information of this danger classification is used in this documentation.



WARNING

The following **may occur**, if you do not observe this warning information:

serious personal injury
 death

Danger from: electricity. The hazard may be described in more detail here.

Here, we describe what you can do to avoid the hazard.

For danger classification **CAUTION**, we use the \triangle danger sign. The following hazard information of this danger classification is used in this documentation.



CAUTION



The following may occur, if you do not observe this caution information:

• minor to medium personal injury.

Danger from: **sharp edges.** *The hazard may be described in more detail here.* Here, we describe what you can do to avoid the hazard.

CAUTION

The following **may occur**, if you do not observe this danger information:



• environmental pollution.

Danger from: incorrect disposal. The hazard may be described in more detail here. Here, we describe what you can do to avoid the hazard.

2.1.2.2 Hazard advisories about damage to property

If a signal word is preceded by a round danger sign: (1), the safety information refers to damage to property.



CAUTION

The following may occur, if you do not observe this caution information:

property damage.

Danger from: **electrostatic discharge.** The hazard may be described in more detail here.

Here, we describe what you can do to avoid the hazard.

2.1.2.3 Instruction signs that are used



wear safety gloves



Sicherheitsschuhe tragen

2.2 Information signs

NOTE



This indicates particularly important information.

2.3 Legal information

This documentation is intended for technically qualified personnel that has been specially trained and is completely familiar with all warnings and maintenance measures.

The equipment is manufactured to the state of the art and is safe in operation. It can be put into operation and function without problems if you ensure that the information in the documentation is complied with.

Operators are responsible for carrying out servicing and commissioning in accordance with the safety regulations, applicable standards and any and all other relevant national or local regulations with regard to cable rating and protection, grounding, isolators, overcurrent protection, etc.

Operators are legally responsible for any damage that occurs during assembly or connection.

2.4 Appropriate Use

You must always use the plug-in module appropriately. Some important information is listed below. The information below should give you an idea of what is meant by appropriate use of the plug-in module. The information below has no claim to being complete; always observe all the information that is given in the operating instructions of this module.

- You must only install the plug-in module in series b maXX 4400 units.
- Configure the application such that the plug-in module is always operating within its specifications.
- Ensure that only qualified personnel works with this plug-in module.
- Mount the plug-in module only in the specified slot/slots.
- Install the plug-in module as specified in this documentation.
- Ensure that connections always comply with the stipulated specifications.
- Operate the plug-in module only when it is in technically perfect condition.
- Always operate the plug-in module in an environment that is specified in the technical data.
- Always operate the plug-in module in a standard condition.
 For safety reasons, you must not make any changes to the plug-in module.
- Observe all the information on this topic if you intend to store the plug-in module.

You will be using the plug-in module in an appropriate way if you observe all the comments and information in the operating instructions of this module.



2.5 Inappropriate Use

Below, we will list some examples of inappropriate use. The information below should give you an idea of what is meant by inappropriate use of the plug-in module. We cannon, however, list all possible cases of inappropriate use here. Any and all applications in which you ignore the information in this documentation are inappropriate; particularly, in the following cases:

- You installed the plug-in module in units that are not Series b maXX 4400.
- You ignored information in the operating instructions of this module.
- You did not use the plug-in module as intended.
- You handled the plug-in module as follows
 - you mounted it incorrectly,
 - you connected it incorrectly,
 - you commissioned it incorrectly,
 - you operated it incorrectly,
 - you allowed non-qualified or insufficiently qualified personnel to mount the module, commission it and operate it,
 - you overloaded it,
 - You operated the module
 - with defective safety devices,
 - with incorrectly mounted guards or without guards at all,
 - · with non-functional safety devices and guards
 - outside the specified environmental operating conditions
- You modified the plug-in module without written permission from Baumüller Nürnberg GmbH.
- You ignored the maintenance instructions in the component descriptions.
- You incorrectly combined the plug-in module with third-party products.
- You combined the drive system with faulty and/or incorrectly documented third-party products.
- Your self-written PLC software contains programming errors that lead to a malfunction.

Version 1.1 of Baumüller Nürnberg GmbH's General Conditions of Sale and Conditions of Delivery dated 2/15/02 or the respective latest version applies in all cases. These will have been available to you since the conclusion of the contract at the latest.

2.6 Protective equipment

In transit, the plug-in modules are protected by their packaging. Do not remove the plugin module from its packaging until just before you intend to mount it.

The cover on the b maXX units' controller sections provides IP20 protection to the plugin modules from dirt and damage due to static discharges from contact. This means that you must replace the cover after successfully mounting the plug-in module.

2.7 Personnel training

	 WARNING The following may occur, if you do not observe this warning information: serious personal injury • death Only qualified personnel are allowed to mount, install, operate and maintain equipment made by Baumüller Nürnberg GmbH.
	Qualified personnel (specialists) are defined as follows:
Qualified Personnel	Electrical engineers and electricians of the customer or of third parties who are authorized by Baumüller Nürnberg GmbH and who have been trained in installing and commission- ing Baumüller drive systems and who are authorized to commission, ground and mark cir- cuits and equipment in accordance with recognized safety standards.
	Qualified personnel has been trained or instructed in accordance with recognized safety standards in the care and use of appropriate safety equipment.
Requirements of the operating staff	The drive system may only be operated by persons who have been trained and are authorized.
	Only trained personnel are allowed to eliminate disturbances, carry out preventive main- tenance, cleaning, maintenance and to replace parts. These persons must be familiar with the Operating Instructions and act in accordance with them.

Commissioning and instruction must only be carried out by qualified personnel.

2.8 Safety measures in normal operation

- At the unit's place of installation, observe the applicable safety regulations for the plant in which this unit is installed.
- Provide the unit with additional monitoring and protective equipment if the safety regulations demand this.
- Observe the safety measures for the unit in which the plug-in module is installed.

2.9 Responsibility and liability

To be able to work with this plug-in module in accordance with the safety requirements, you must be familiar with and observe the hazard information and safety instructions in this documentation.

2.9.1 Observing the hazard information and safety instructions

In these operating instructions, we use visually consistent safety instructions that are intended to prevent injury to people or damage to property.



WARNING



The following may occur, if you do not observe this warning information:

• serious personal injury • death

Any and all persons who work on and with Series b maXX units must always have available the Operating Instructions of this module and must observe the instructions and information they contain – this applies in particular to the safety instructions.

Apart from this, any and all persons who work on this unit must be familiar with and observe all the rules and regulations that apply at the place of use.

2.9.2 Danger arising from using this module

The plug-in module has been developed and manufactured to the state of the art and complies with applicable guidelines and standards. It is still possible that hazards can arise during use. For an overview of possible hazards, refer to the chapter entitled ▷Basic Safety Instructions ◄ from page 7 onward and to the Operating Instructions. We will also warn you of acute hazards at the appropriate locations in this documentation.

2.9.3 Warranty and Liability

All the information in this documentation is non-binding customer information; it is subject to ongoing further development and is updated on a continuous basis by our permanent change management system.

Warranty and liability claims against Baumüller Nürnberg GmbH are excluded; this applies in particular if one or more of the causes listed in ▶Inappropriate Use ◄ from page 12 onward or below caused the fault:

• Disaster due to the influence of foreign bodies or force majeure.



COMMISSIONING

In this chapter, we will describe how you commission the b maXX drive PLC plug-in module that you just assembled and installed (see "b maXX PLC Operating Instructions"). Commissioning ensures that the plug-in module functions correctly.

Before starting commissioning, ensure that the following conditions have been met:

- 1 The plug-in module has been assembled correctly.
- 2 The plug-in module has been installed correctly.
- 3 All the safety equipment has been commissioned.
- 4 The b maXX unit is ready for use.

3.1 General safety regulations

Observe the ►Basic Safety Instructions < from page 7 onward.



DANGER

The following **will occur**, if you do not observe this danger information:

• serious personal injury • death

Danger from: mechanical effects. At commissioning, the drive can rotate.

Keep far enough away from the rotating parts. Note that when drives are starting up machine parts can be set in motion. In all cases, activate the machine's safety devices.

3.2 Requirements of the personnel carrying out work

Commissioning work must only be carried out by trained specialists who have understood the safety regulations and information and can implement them.



3.3 Description/inspection of the safety and monitoring systems

Before you commission the b maXX drive PLC, you must eliminate any errors/error messages that may be present on the b maXX 4400 unit. These errors may be due to faulty assembly (e.g. defective cables) or faulty installation (e.g. no power supply). You must not continue with commissioning until you have eliminated the errors.

3.4 Description and inspection of the controls and displays

3.4.1 LEDs for displaying operating status of BM4-O-PLC-01

The b maXX drive PLC option module has two red (H2 and H4) and two green (H1 and H3) LEDs as display elements.

These LEDs are used by the operating system of the b maXX drive PLC during initialisation (start-up phase).

During operation (after the start-up phase of the operating system) the LEDs can be used in the application program of the b maXX drive PLC.



Figure 1: LEDs of the BM4-O-PLC-01 plug-in module

3.4.1.1 Switching on and initialisation of BM4-O-PLC-01

- All the option modules in the b maXX 4400 unit must have reached a specific internal operating status after switching in the supply voltage before they may be actuated by the b maXX controller and the b maXX drive PLC.
 This stage, in which the system waits for a global ready message of all the boards is displayed by a counterclockwise-rotating LED bit pattern. (This means that an LED lights up every 500 ms in the sequence H4 -> H2 -> H1 -> H3 -> H4 etc.)
- After the global ready message of all option modules has been issued, the b maXX drive PLC must wait until the b maXX controller recognizes and preinitializes it. This stage is indicated by a clockwise-rotating bit pattern. This means an LED sequence of H4 -> H3 -> H1 -> H2 -> H4 etc. every 500 ms.

The two sequences that we have just described can be completed very quickly, which means that you do not necessarily have to observe the associated operating displays.

After this, a PC and the b maXX drive PLC can, in principle, carry out PROPROG communication via the serial RS232 port on the b maXX controller.

From now on, PROPROG communication is also possible by means of TCP/IP if an option module with Ethernet functionality is present that has been configured for communication with the b maXX drive PLC.

• If a boot project is present, the system now loads it (boot project will be read from flash, translated and stored in SDRAM as an executable program code). The top two LEDs (H2 and H1) flash rapidly to show that the boot project is being loaded.

At the end of the start-up phase, the LEDs show the following PLC-specific operating status conditions:

- No project available, status "POWER ON":
 → bottom green LED and red one (H3 and H4) light up.
- Project available, status "STOP":
 → only the bottom right-hand red LED (H4) lights up.
- Project available, status "INIT", the controller is at the cold boot or warm restart stage:
 → Only the bottom left-hand green LED (H3) lights up.
- Project available, status "RUN":
 → both green LEDs (at the bottom and at the top left, H3 and H1) light up.

In the "RUN" status, users can freely program the four LEDs. For information on programming, see ▶ Function block LED ◄ from page 55 onward.

3.4.1.2 Operation of BM4-O-PLC-01

At the end of the start-up phase, the LEDs show the following PLC-specific operating status conditions:

- No project available, status "POWER ON":
 → bottom green LED and red one (H3 and H4) light up.
- Project available, status "STOP":
 → only the bottom right-hand red LED (H4) lights up.
- Project available, status "INIT", the controller is at the cold boot or warm restart stage:
 → Only the bottom left-hand green LED (H3) lights up.
- Project available, status "RUN":
 → both green LEDs (at the bottom and at the top left, H3 and H1) light up.

In the "RUN" status, users can freely program the four LEDs. For information on programming, see ▶ Function block LED ◄ from page 55 onward.

3.4.2 S1 switch/pushbutton for changing operating status conditions of the BM4-O-PLC-01

For changing the operating status' there is a switch/pushbutton S1 on the b maXX drive PLC option module.





Figure 2: Switch S1 on the BM4-O-PLC-01 front panel



NOTE

The user project is only able to start, if the switch/pushbutton S1 is at the buttom "RUN".

The pushbutton upward resets **only** the b maXX drive PLC option module and not the controller. After resetting, the PLC may no longer be able to communicate with the option modules. In this case, you must reboot the system mandatory.



DANGER

The following **will occur**, if you do not observe this danger information:

• serious personal injury • death

Danger from: **mechanical effects.** You can program the boot project such that the drive and the machine parts respectively rotate or move!

Keep far enough away from the rotating parts. Note that when drives are starting up machine parts can be set in motion. In all cases, activate the machine's safety devices.

3.5 Commissioning sequence

Commissioning is divided into the following procedures:

- 1 Activation.
- 2 Testing the function.

3.5.1 Activation

- Read and observe the ▶General safety regulations < from page 15 onward.
- You must have carried out correctly section "Assembly and Installation" (see ▷Operating Instructions b maXX drive PLC<).
- Set switch/pushbutton S1 on the b maXX drive PLC to "STOP" (centre position).
- Switch on the b maXX 4400 basic unit.

NOTE

You must not remove or plug in the b maXX drive PLC plug-in module while the b maXX 4400 basic unit is switched on. Switch the unit off first.

3.5.2 Testing the function

- After you switch on the b maXX unit, two status conditions can apply:
 - No boot project (= no user project on the PLC): LED H2 (at the top right) lights up briefly after a short time, the bottom LEDs H3 and H4 (red and green) are permanently lit up. This means that no project is present. In this "POWER ON" status, the PLC is waiting for communication.
 - Boot project present: When you switch on, the system loads the boot project. When you do this, the top LEDs flash. After a short time, LED H4 (at the bottom right) lights up red. The PLC is in the "STOP" status.
- While switch S1 on the b maXX drive PLC option module is set to "STOP" (centre position), an existing boot project cannot start up.

If you want to start an existing boot project by setting switch S1 on the b maXX drive PLC option module to the "RUN" (bottom) position, **first** ensure that you have loaded the **correct** boot project for your application for **this** plant in **this** unit on the PLC!

Refer to the b maXX PLC Application Manual for more information on how to ensure that this is the case or how you can send a boot project to the PLC, for example, see ► Operation < from page 25 onward.

How you can send a boot project to the b maXX drive PLC, for example, see ▶Sending a boot project ◄ from page 19 onward.

DANGER

The following **will occur**, if you do not observe this danger information:

• serious personal injury • death

Danger from: **mechanical effects.** A boot project on the PLC can start up if you set switch S1 from "STOP" (center position) to "RUN" (bottom position) or if switch S1 is set to "RUN" when you switch on the b maXX unit. You can program the boot project such that the drive and the machine parts respectively rotate or move!

Keep far enough away from the rotating parts. Note that when drives are starting up machine parts can be set in motion. In all cases, activate the machine's safety devices.

3.5.3 Sending a boot project

 Connect your PC's serial port to the female Sub-D connector on the b maXX controller (slot F).



NOTE

Do **not** connect to the female Sub-D connector on the b maXX drive PLC! This functions as a serial RS485 terminal interface and you cannot use it for communication with PROPROG wt II / ProProg wt III.

- 2 Start the PROPROG wt II (or ProProg wt III) operation software on your PC and choose a project for b maXX drive PLC. This project must have already been successfully compiled. You can also recompile the project using menu item "Build -> Rebuild Project".
- 3 In the operator control program, click on resource control in menu "Online".





Figure 3: PROPROG wt II user interface

The system opens the following window:

RES1	
State: On	
<u>S</u> top	C <u>o</u> ld
<u>R</u> eset	<u>₩</u> arm
	Ho <u>t</u>
<u>D</u> ownload	Upload
Error	<u>I</u> nfo
<u>C</u> lose	<u>H</u> elp

Figure 4: Resource control "On"

4 Click on the "Download" pushbutton. The system displays the following image:

Download	×
Project	Bootproject
[Download
□ Include 0 <u>P</u> C data	Activate
Download <u>S</u> ource	
☐ Include <u>U</u> ser-Libraries	Delete on Farget
I Include Pagejayouts	
Delete Source on Target	Download <u>F</u> ile
<u>C</u> lose	<u>H</u> elp

Figure 5: Send

- 5 Click on "Download boot project".
 - Stage 1: Clear flash memory:

A boot project that may be present is deleted. In the operator control program, the system now displays a white bar at the bottom of the screen. On the b maXX drive PLC all four LEDs flash at the same time.

• Stage 2: Send project:

The system sends the boot project. The bar at the bottom of the screen turns blue and shows the progress of the transfer. On the b maXX drive PLC the LEDs (H1 (green), H2 (red), H3 (green), H4 (red)) flash diagonally during transfer.

$\frac{1}{2}$

NOTE

After sending is completed, you should switch the b maXX 4400 basic unit off and back on so that the b maXX controller can correctly initialize all the option modules in the correct time order.

Alternatively, it may be enough to start the project on the b maXX drive PLC either by means of menu item "Download" / "Activate boot project" and "Cold boot" or by resetting on the b maXX drive PLC. However, this procedure is highly application-dependent, which means that the commissioning engineer bears the responsibility for using it.

You can stop or restart execution of a project on the b maXX drive PLC using resource control. As an alternative, you can achieve the same effect using switch S1 on the b maXX drive PLC.



NOTE

Commissioning engineers should always be aware that in the "Stop" status no application projects can be executed, which means that there is no more communication between the b maXX controller and other option modules.



RES1	
State: Run	L
<u>S</u> top	C <u>o</u> ld
<u>R</u> eset	<u>₩</u> arm
	Ho <u>t</u>
<u>D</u> ownload	<u>U</u> pload
Error	<u>I</u> nfo
Close	<u>H</u> elp

Figure 6: "Operation" resource control

When you click on the "Info" pushbutton, the system displays the following image containing information:

Resource: RES1						X
Version					PLC state	
	OmegaOS V3.	1.2089 Feb 3	2003		Run	
- Firmware					Error	
	1314.0101/12	76.0102/1284.	0101		None	
- Project					-Access rights	
Tioject	bma	XX_demo			Global	
CPU load	Default-T	ask	System tick		Powerflow	
1%	20 r	ns Cyc. time	10r	ns	None	
Retain data 0 kB free	Prog. me 20	m. 17 kB free	System data 1457 kB	free	Bootproject	
Breakpoints		Force			bmaXX_demo	
No breakpoints active No variables forced			- Project source None			
,,					- Logic Analyser	
Time between transmissions : 10 ms				inactive		
	[<u> 0</u> k	<u>C</u> an		lelp		

Figure 7: Resource information window

NOTE						
Meanings of the dis	Meanings of the displayed versions strings in the information window:					
PLC string:	"OmegaOS V3.1.2078 Feb 3 2003"					
	-> "OmegaOS": Product designation					
	-> "V3.1.2078": OmegaOS compiler information					
	-> "Feb 3 2003": Date on which the PLC version was created.					
Firmware string:	"1290.0101/1276.0102/1284.0101"					
	-> "1314.0101": Version OmegaOS software 6.1314.0101					
	-> "1276.0102": Version FPGA software 6.1276.0102					
	-> "1284.0101": Version BOOT software 6.1284.0101"					

Within the scope of the further technical development of the products higher versions and newer dates can be installed here.

Click on "OK" to acknowledge and go back to resource control (see ►Figure4 on page 20).



3.5 Commissioning sequence

OPERATION

4.1 Programming systems PROPROG wt II and ProProg wt III

PROPROG wt is a standard programming system that is based on the IEC 61131-3 standard.

The programming system provides powerful functions for the various development stages of PLC applications, like:

- editing
- compiling
- debugging
- printing

The PROPROG wt programming system is based on modern 32-bit Windows technology and allows users to operate the system easily using tools like zoom, scroll, special toolbars, drag & drop, a shortcut manager and dockable windows.

In particular, the system makes possible processing of several configurations and resources within a project as well as integration of project libraries. Apart from this, it has a powerful system for debugging. Using the easy-to-use project tree editor, you can display and edit projects. This makes it possible to represent easily and transparently the complex structure of the IEC 61131-3 standard. This feature allows users to easily paste and edit in the project tree POEs, data types, libraries and configuration elements.

The PROPROG wt programming system consists of a PLC-independent core for programming in the various IEC programming languages: these include the text languages Structured Text (ST) and Statement List (STL) as well as the graphic languages Function Block Diagram (FBD), Ladder Diagram (LAD) and Sequential Function Chart (SFC).

An editor wizard is available for programming in each of the languages, which allows you to quickly and easily paste prepared keywords, statements, operators, functions and function blocks into the individual work sheets. You can also use the editor wizard for declaring variables and data types. The independent core of the system is complemented by special sections that are matched to various PLCs.

The new easy online handling and the 32-bit simulation allow you options for debugging the address status and a real-time multitasking test environment.

An easy-to-use tool for project documentation allows you to print the project in a time-saving optimized form (using less paper) with a page layout that can be specified by individual users.



DANGER



The following will occur, if you do not observe this danger information:

• serious personal injury • death

Danger from: **mechanical effects.** A boot project on the b maXX drive PLC starts up, if the switch/pushbutton S1 is switched from "STOP" (center position) to "RUN" (bottom position) or if the switch is on "RUN" at start up of the b maXX system. The boot project can be programmed in such a way that the machine/system or parts of the machine/system can be set in motion.

Keep far enough the moving parts of the machine/system. Note that from the other modules which are connected (to the b maXX drive PLC), machine parts can be set in motion. In all cases, activate the machine's safety devices.



DANGER

The following **will occur**, if you do not observe this danger information:

• serious personal injury • death

Danger from: **mechanical effects.** Online changes are sent automatically to the PLC and operate immediately without stopping the program execution at the PLC before.

Keep far enough the moving parts of the machine/system. Note that from the other modules which are connected (to the b maXX drive PLC), machine parts can be set in motion. In all cases, activate the machine's safety devices.



DANGER

The following **will occur**, if you do not observe this danger information:

• serious personal injury • death

Danger from: mechanical effects. If you force or overwrite variables during PLC runtime, the PLC program is running with the forced or overwrite variables.

Keep far enough the moving parts of the machine/system. Note that from the other modules which are connected (to the b maXX drive PLC), machine parts can be set in motion. In all cases, activate the machine's safety devices.

DANGER

The following will occur, if you do not observe this danger information:

• serious personal injury • death

Danger from: mechanical effects. If you use breakpoints during PLC runtime, the PLC program is stopped when reaching a breakpoint.

Keep far enough the moving parts of the machine/system. Note that from the other modules which are connected (to the b maXX drive PLC), machine parts can be set in motion. In all cases, activate the machine's safety devices.

4.2 b maXX drive PLC project

You start a new maXX drive PLC project under PROPROG wt by means of menu item "File/New project". Using the "Template for BM4_O_PLC01", you open a b maXX drive PLC project. Processor type BM4_O_PLC01 is preset in this project in the configuration.

Ne	w Project		R Ma	×
	Project Wizard	empty project	Template for Simulation	OK Cancel
	Template for BM4_0_PLC01	Template for Single Axis Motion Control		
				<u><u>a</u></u>

Figure 8: BM4_O_PLC01 project template under "New Project".

4.3 b maXX drive PLC configuration

As an IEC 61131-3 programming environment, you can use PROPROG wt to program different target systems (CPUs). It is also possible to program different target systems in one project. You create a program for the BM4_O_PLC01 target system under "Physical Hardware" using resource BM4_O_PLC01.

You open the template for BM4_O_PLC01 by means of the "New project" menu. Under properties, configuration CONF1 has PLC type SH03_30.



A configuration consists of at least one resource. The resource contains the specific data range for the b maXX drive PLC, the communication source, global variable worksheets and the tasks containing the program parts.



Figure 9: Setting the property of a b maXX drive PLC configuration under "Physical Hardware".

Overview of the settings within the physical hardware:

Project template	Configuration	Resource
BM4_O_PLC01	SH03_30	BM4_O_PLC01

A project can include several configurations each with several resources.

4.4 b maXX drive PLC resource

The resource contains the b maXX drive PLC-specific settings for one program:

- Data Area
- Communication source

- Global variable worksheets
- Various tasks using the program
- Documentation worksheets and I/O configuration (The I/O configuration is already set and you do not need to change it.)

You can assign several resources with different ports to one configuration. This makes it possible to implement a complete application with several drives in one project.







4.4.1 Communication and Connection

You configure communication with data transfer under "Setting" in the resource's context menu.

You set communication via the selected RS232 port as follows:

8

- Baud: 38400
- Stop bits: 1
- Data bits:
- Parity: None
- Timeout: Default is 2000 ms; communications monitoring during online representation.

The connection is established via the COM1 serial port on the PC:

Resource settings for SH	103_30		×			
Port:	<u>B</u> aud:	38400 💌	Ok			
	St <u>o</u> pbits:	1	Cancel			
C COM <u>2</u> C COM <u>3</u>	D <u>a</u> tabits:	8 💌	Data ar <u>e</u> a			
○ СОМ <u>4</u>	Parity:	None 💌				
	<u>T</u> imeout:	2000 ms	<u>H</u> elp			
	 Index check o Stack check o Array boundary 	n PLC m PLC) check on PLC				
○ <u>D</u> LL Image: Force BOOL8 for boolean variables □ Generate bootproject during compile						
DLL: TCP/I	DLL: TCP/IP local host					
Parameter: ip 127	.0.0.1 -TO2000					
PDD						
 All global variables Marked variables 		All global variables	:			
Use reser <u>v</u> e						
All POUs	O Marked F	POUs O No	reserve			

Figure 11: Resource setting within a b maXX drive PLC configuration.

- "Index check on PLC": The system checks the declared field size (index) of an ARRAY at runtime. Important: this increases the code execution time!
- "Stack check on PLC": The system checks for a stack overrun at runtime. The stack memory is reserved with the program task. There is an increase in the data on the stack if you program nested FB instances, for example. Important: this increases the code execution time!



- "Array boundary check on PLC": With absolute addressing, the system checks whether the field exceeds the parameterized data area limits. This check is carried out during compilation on the PC. This does not increase the code execution time.
- "Force BOOL8 for Boolean variables": Activate 8-bit access to Boolean variables. For the b maXX drive PLC, the setting must be activated.
- "Generate boot project during compile": With this function activated, the system generates for each resource a bootfile.pro at compiling of the project and not just at activation of the Send boot project function via the resource control.
- "PDD": Settings for the process data directory. (See also the PROPROG wt II programming manual and the Online Help System of ProProg wt III respectively).
- "CSV": Settings for providing variables for the OPC server. (See also the PROPROG wt II programming manual and the Online Help System of ProProg wt III respectively).
- "Use reserve": Use spare memory to be able to make changes in the function blocks and functions using the "Patch POU" function. (See also the PROPROG wt II programming manual and the Online Help System of ProProg wt III respectively).

The resource setting can be made separately for each b maXX drive PLC resource. Serial or Ethernet communications source

- COM1
- COM2
- COM3
- COM4
- DLL

is used

- for resource control.
- for online representation of variables and structures in the Watch window
- for sending the compiled project.
- for debugging.
- for connecting to the OPC server.

Resource settings	for 5H03_30				×
Port: C COM <u>1</u> C COM <u>2</u> C COM <u>3</u> C COM <u>4</u>	Baud: Stopbits: Databits: Parity:	38400]]]	Ok Cancel Data ar <u>e</u> a	
• <u>DIL</u>	Timeout: Index cher Stack cher Array bour Force BOD	2000 ms ck on PLC ck on PLC ndary check on PLC DL8 for boolean variab	les	<u>H</u> elp	
D <u>L</u> L: Pa <u>r</u> ameter:	TCP/IP bmaXX_PLC (fa	ctory default)	npile		•
EDD All global varia	ibles iles	CSV ☐ All global v ☐ Marked va	ariables riables		
Use reser <u>v</u> e	O Mark	ed POUs	O No re	serve	

Setting the Ethernet communication source by choosing or stating the TCP/IP address

Figure 12: Setting the TCP/IP address

After changing the port to "DLL", users can use the DLL menu to choose applications "Soft-PLC" (=TCP/IP local host (this PC)) and "b maXX drive PLC access via Ethernet" (=TCP/IP bmaXX_PLC (brand new)):

• Soft-PLC:

You do not need to change the preset TCP/IP address in field "Parameter" if the Soft-PLC is installed on the same computer. If installing Soft-PLC on another computer, users must enter here the appropriate TCP/IP target address (or the appropriate network name) to be able to access Soft-PLC via TCP/IP from PROPROG wt.

• b maXX drive PLC:

To be able to access the b maXX drive PLC via Ethernet, an Ethernet-capable option module (e.g. a BM4-O-ETH-02) must be fitted in the b maXX 4400 basic unit in addition to the b maXX drive PLC. TCP/IP address "192.168.1.1", which is preset in the parameter field, corresponds to the IP address that is preinstalled when the Ethernet card leaves the factory. This means that users can make an initial connection to the module for basic initialization in which they must then enter the TCP/IP address of their TCP/ IP network on the machine.



Refer to the respective operating instructions and application manuals of the Ethernet option modules you use for an exact description of the basic initialization procedure.

4.4.2 Control Dialog for Resources

Using the control dialog for resources, you set program transfer to the b maXX drive PLC and the operating status of the b maXX drive PLC.

If several resources are active in a project, you must choose the desired resource. Select a resource in PROPROG wt II:

Select re	source			
Resou RES1 RES2	ce	Configuration CONF1 CONF1	1	Cancel
,				

Figure 13: After you choose the resource, the system displays the control dialog for the resource of the assigned b maXX PLC.

The control dialog will be opened.

Select a resource in ProProg wt III:

Click on the desired resource and then press the button "Connect".

Project control							
Resource		Configuratio	on	Statu	s	Info	
RES1 RES2		CONF1 CONF1		Offline Offline	e e		
Online	_ Dov	vnload ——	Contro	I			
Connect		Project		oļd	V	√arm	Ho <u>t</u>
Disconnect		More	<u>S</u> t	op	E	leset	Control
Select <u>a</u> ll					Ŀ	<u>l</u> elp	<u>C</u> lose

Figure 14: Select the resource in ProProg wt III - connect

Press the button "Control..." now.

Project control						×	
Resour	се	Configuration		Status		Info	
RES1		CONF1		Run			
RES2		CONF1		Offline			
					_		
_ Online -		vnload	- Contro	I			
Conr	rect	Project	Co	d	W	arm	Hot
Djscor	nnect	More	<u>S</u> t	ор	Be	eset	C <u>o</u> ntrol
Se	lect <u>a</u> ll				He	elp	<u>C</u> lose

Figure 15: Select the resource in ProProg wt III - open control dialog

The control dialog will be opened.

RES1					
State: Run					
<u>S</u> top	Cold				
<u>R</u> eset	<u>₩</u> arm				
	Ho <u>t</u>				
<u>D</u> ownload	<u>U</u> pload				
Error	<u>I</u> nfo				
<u>C</u> lose	<u>H</u> elp				



Clicking on **Download** transfers the compiled project to the target system.

Sending the project to the target system.

Download	X
Project	Bootproject
[Download	Download
☐ Include 0 <u>P</u> C data	Activate
Download <u>S</u> ource	
Include User-Libraries	Delete on Target
Include Pagejayouts	
Delete Source on Target	Download <u>F</u> ile
<u>lose</u>	<u>H</u> elp

Figure 17: b maXX drive PLC resource transfer to flash memory or to RAM.

Clicking on **Download boot project**, deletes the resource's current boot project, sends the compiled project as a boot project and saves it in the b maXX drive PLC's flash memory. Clicking on **Activate**, loads the project from the b maXX drive PLC's flash memory to RAM.

Clicking on **Delete on Target**, deletes the boot project in flash memory.

Clicking on "**Project / Download**", transmits the compiled project of the resource directly into RAM and you can then start it by means of the control dialog ("Cold" pushbutton). The boot project is retained unchanged in the b maXX drive PLC's flash memory. After the next hardware reset or the next time you switch the controller off and on again, the boot project is loaded again!


NOTE

Menu items "Download source", "Download file" and attribute "Include OPC data" are not currently supported and you must not select them.

If you want to use menu item **Boot project / Download** to activate the project that you stored in flash memory, proceed as follows

• Directly: by switching the voltage off and on again

or

• Via PROPROG wt:

In the program that is loaded in RAM use menu item "**Stop**"" to halt it and delete it using menu item "**Reset**". The operating status changes to "**On**".

RES1	
State: On	
<u>S</u> top	C <u>o</u> ld
<u>R</u> eset	<u>₩</u> arm
	Ho <u>t</u>
Download	<u>U</u> pload
Error	<u>I</u> nfo
<u>C</u> lose	<u>H</u> elp

Figure 18: Resource control "ON" status

In the "Download" menu of the control dialog, click on "Boot project / Activate". This installs the flash RAM project in the b maXX drive PLC's RAM.

Download	×
Project	Bootproject
[Download
☐ Include O <u>P</u> C data Download <u>S</u> ource	Activate
 Include User-Libraries Include Pagelayouts 	Delete on Target
Delete Source on Target	Download <u>F</u> ile
Close	<u>H</u> elp

Figure 19: "Download" control dialog



RES1	_ 🗆 🗙
State: Stop	
<u>S</u> top	C <u>o</u> ld
<u>R</u> eset	<u>W</u> arm
	Ho <u>t</u>
<u>D</u> ownload	<u>U</u> pload
Error	<u>I</u> nfo
<u>C</u> lose	<u>H</u> elp

Then, you can start the program by means of **"Cold"** in the control dialog:

Figure 20: b maXX drive PLC resource control in status "STOP".

Description of the pushbuttons in maXX drive PLC resource control

- "Stop": This stops execution of the program; the PLC operating status changes from "Run" to "Stop" (The system displays the status at the top of the screen in resource control).
- The "Reset" pushbutton: Deletes the RAM project that is stored on the b maXX drive PLC (not the boot project that is stored in flash memory!) The status changes from "Stop" to "On".
- The "**Download"** pushbutton: Calls the page for program transfer (transfer of b maXX drive PLC resource to RAM or flash memory).
- The "Error" pushbutton: Here, you can read out error and warning messages that are pending on the b maXX drive PLC if the pushbutton is activated. Clicking on the active error pushbutton inquires the controller's error entries and displays them in the error or warning message window.
- The "Close" pushbutton: Closes maXX resource control again.
- Pushbuttons "Cold"/"Warm"/"Hot": Using these PROPROG commands, you can manually start the b maXX drive PLC. The status changes from "Stop" to "Run". You can, however, only start the PLC using the pushbuttons if you set switch S1 on option module BM4-O-PLC-01 to "RUN". Otherwise, the controller stays in the "Stop" status.

In this connection, the three start buttons are differentiated as follows:

 "Cold" pushbutton: The PLC cycles once through PROPROG system task "cold boot (SPG1)" in which user program initialization takes place and then switches to cyclical program processing.

Cold booting is characterized by all the variables being initialized with their default values. If a user did not state a default value in the project, the system sets a default value of "0" (or "FALSE" for Boolean variables).

 "Warm" pushbutton: The PLC cycles once through PROPROG system task "warm restart (SPG0)" in which user program initialization takes place and then switches to cyclical program processing.

By contrast with cold boot, the retain flags retain their values, which means that they are not reset to default values.

If there are no retain flags on the b maXX drive PLC and the same user code is integrated in the cold boot and the warm restart task, there is no difference between the cold boot and warm restart. • "Hot" pushbutton: The system does not cycle through an initialization task; rather, it switches directly to cyclical program processing.

NOTE

You can only start the PLC using one of the cold boot/warm restart/hot restart pushbuttons or by switching the power off and on again if switch S1 on option module BM4-O-PLC-01 is set to "RUN". Otherwise, the controller stays in the "Stop" status and no user code is executed.

If you carry out a hardware reset on switch S1, this switch must also be set to "RUN" afterward.

In the case of a b maXX drive PLC with retain flags, the system cold boots once – whereby the retain flags are also set to the specified default values – after sending of a new boot project and subsequent automatic starting of the program (by turning the power off and on again or a hardware reset at switch S1 of the BM4-O-PLC-01 option module). The system stores "Kalt-start wurde durchlaufen" (Cold boot executed) to the retain area.

At each further automatic change to the "Run" status, the system evaluates this stored piece of information and always carries out a warm restart where the retain flags retain their contents.

If you activate the "Kalt" manual start pushbutton in the b maXX drive PLC resource control, this forces explicit setting of the default values for the retain flags too.

When you save boot projects, automatic restart response depends on whether there have been any changes in the retain flag area: If the system detects on the controller that by comparison with the previous project download retain flags have been created or deleted, or the name, data type or sequence of retain flags has been changed, then it also cold boots once on the change to the "Run" status. This is to guarantee consistency of the retain flags.

With projects, the aim is, if possible, to retain retain data on the controller even after a project download. If there is just a change in the default values, this means that the system does not automatically cold boot and users themselves may possibly have to explicitly carry out a cold boot.

In the case of a b maXX drive PLC without retain flags, the system always cold boots at automatic program starts.

You can query whether a PLC supports retain flags using the "Info" pushbutton (see below).

- "Upload" pushbutton: Upload functions in PROPROG wt are not currently supported.
- "Info" pushbutton: General information on the b maXX drive PLC itself and the project status on the b maXX drive PLC (for a description, see below).
- "Help" pushbutton: This calls general and specific PLC help for the b maXX drive PLC.



Description of the "resource information" "Info" page.

You call this page by clicking on the "Info" pushbutton in b maXX drive PLC resource control:

Resource: RES1		NA D	×		
Version PLC		PLC state			
Or	megaOS V3.1.2089 Feb 3 20	003	Error		
Firmware 13	14.0101/1276.0102/1284.0	101	None		
- Project			Access rights		
1 lopot	bma≫_demo		Global		
- CPU load	Default-Task	System tick	Powerflow		
0%	0 ms Cyc. time	10ms	None		
Retain data 0 kB free	Prog. mem. 2017 kB free	System data 1422 kB free	Bootproject		
Breakpoints No breakpoints acti	- Project source None				
Time between transmissions : 10 ms Logic Analyser					

Figure 21: Resource information window

- Version: PLC "OmegaOS V3.1.2089 Feb 3 2003"
 - "OmegaOS": Product designation.
 - "V3.1.2089": OmegaOS Compiler Info.
 - "Feb 3 2003": Date on which the PLC version was created.
- Firmware: "1314.0101/1276.0102/1284.0101"
 - "1314.0101": Version OmegaOS software 6.1314.0101.
 - "1276.0102": Version FPGA software 6.1276.0102.
 - "1284.0101": Version BOOT software 6.1284.0101.
- Project: Name of the active project (the project name may be a maximum of eleven letters long).
- CPU load: The system automatically determines loading in real time and displays it here as a percentage.

Amongst other things, this includes the runtimes of the individual cyclical tasks as well as the bypass tasks that are not monitored by means of watchdogs. To guarantee important operating system functions, like online communication, for example, you should aim to achieve total loading of less than 80%. At 100% loading, a system error is generated that stops the b maXX drive PLC.

One hundred percent loading is achieved, for example, if model of the default task could not be completed after approximately ten seconds and the user changed the set-

ting of the watchdog for the default task to more than ten seconds. (In the case of watchdog settings of less than ten seconds in the default task, watchdog monitoring would trigger a system error first and check back). You can read the current duration of the default task in the window to the right of the CPU loading display.

You can avoid overloading by dividing the corresponding tasks into several shorter individual tasks with longer call intervals or by skipping individual program sections (e.g. in the bypass tasks) to reduce task runtimes.

- Default task: Here, you can view the current cycle time of the default task in ms.
- System tick: This time indicates the lowest resolution of the cycle or monitoring times that the PLC runtime system can manage.

Example: It doesn't matter whether you state the interval in a cyclic task as "400 ms" or "409 ms": With a 10-ms system tick, "400 ms" (i.e. rounded down to the duration of one system tick) is always activated.

• Retain data: As was explained above, there are b maXX drive PLC versions with and without retain flags.

In the case of a b maXX drive PLC without retain flags, the system displays the value 0 here. In this case, when you click on the "Project/Download" pushbuttons in the "PLC resource transfer" window, the system issues an appropriate PLC error if you are mistakenly using retain flags in the user project or if they were set in the user data range (see below).

In systems containing retain flags, the "Retain data" display shows the available total retain memory area on the PLC. Since retain system information is also stored there in addition to the retain flags (e.g. whether cold booting has already taken place with a project), the area that users can use as retain flags is smaller and can be taken from the data range settings ("Retain / Start user" and "End system", see below).

• Prog. mem. (Program memory): Display in kB of the amount of PLC program memory in the active project that is still free.

With 2046 kB of free program memory, you can, for example:

- Program a maximum of 400,000 STL lines (LD/ST statements to global variables)
- Typically program 120,000 STL lines (typical STL statements to structures and instance variables)
- System data: Dynamic memory (e.g. 1460 kB) for debug and logic analyzer functions.
- Breakpoints: Here, the system displays whether breakpoints are set on the PLC. If this is the case, the system shows the 'Reset breakpoints' checkbox. Select the checkbox if you want to reset all the set breakpoints at the same time. (You can manage breakpoints in the "Online/Debug" menu).
- Force: Indicates whether variables were forced. If this is the case, the system shows the 'Reset force list' checkbox. Select the checkbox if you want to reset all the set forced variables at the same time.
- Free memory for system data runtime system (for loading, oscilloscope function).
- Time between transmissions: Here, users can state a time after which, at the earliest, the programming system starts new communication to the PLC after the previous communication procedure was completed. By reducing the time, users can lower the general PLC loading due to communications tasks. The value is stated in ms.
- PLC state: This shows the current b maXX drive PLC operating status (e.g. "Run", "Stop", etc.)



- Error: Indicates whether a PLC error message is pending in the error catalog and if you can read it out using the "Error" pushbutton in b maXX drive PLC resource control.
- Access rights: Indicates the access rights for sending and debuggen on the PLC.
- Flow control: Indicates whether the user activated Address status with flow control ("Online/Address status" menu item).
- Boot project: Name of the (inactive) boot project on the b maXX drive PLC (the project name may be a maximum of eleven letters long).
 Using the page for program transfer (b maXX drive PLC resource transfer) you can choose menu item "Activate" to transfer the boot project to the active RAM project. (This always happens automatically in the case of a hardware RESET or switching the power off and on again).
- Project source: This indicates whether a source project (zwt) is present in the PLC (For memory reasons, this is not currently supported).
- Logic Analyser: This indicates whether logic analysis recording is currently active.

4.4.3 Data Area

The data area contains the b maXX drive PLC-specific setting of physical address ranges in the form of flags that users and the compiler PROPROG wt can access.

The settings are stored with the project.

You get to the "data area" form in the project tree in the "Settings/Data area..." context menu in the "Physical Hardware/RES1" resource:

Data Area			×
Non retain			ΠΚ
Start <u>u</u> ser:		0	
End user / Start <u>s</u> ystem:		80000	Cancel
<u>E</u> nd system (max 2097147):		2097147	<u>H</u> elp
Reserve per <u>P</u> OU:		500	
Retain			
S <u>t</u> art user:		10000000	
End user / Sta <u>r</u> t system:		1000000	
<u>E</u> nd system (max 10122879):		10122879	
Reserve per P <u>O</u> U:		10%	
Declare user memory at 1/0 c	onfiguration auto	omatically	

Figure 22: b maXX drive PLC-specific data area resource without retain flags user area.

In this connection, the data area is subdivided according to two criteria:

Firstly, the data area is divided into "non retain flags" and "retain flags".

Secondly, a differentiation is made in both areas between whether the user or the compiler in PROPROG wt are allowed to access these flags.

The two "Reserve per POE" settings that you can see in the picture are for the "Send online changes" compiler functionality and they reserve program memory.

Explanation of "non retain" and "retain" flags:

By contrast with non retain flags, retain ones keep their values even when the power is switched off, which means that the PLC can continue running with these values the next time you reboot it. By preference, plant-specific data is stored there that is only determined during operation and cannot be recalculated from other values.

An example of this is a winder diameter that changes continuously in terms of speed and over the machine's operating time.

NOTE

The standard version of the BM4-O-PLC-01 option module contains no retain flags. In this case, you should not change the existing standard settings for retain flags in the data area.

In the case of a b maXX drive PLC without retain flags, the system displays in the online "Info" window a value of 0 at the "retain data" entry. In this case, the system issues an appropriate PLC error in the "PLC resource transfer" window when you download the project by clicking on the "Project/Send" pushbutton if you mistakenly set retain flags in the user data area.

In systems containing retain flags, the "Retain Data" display shows the available total retain memory area on the PLC.

Explanation of user flag ("Start user/End user"):

If users want to directly access flags in their project, it is possible to reserve in advance areas for the non retain and retain flags.

You should however not set the user areas too large, since with relatively large projects this may lead in some cases to too little system memory being available for the PRO-PROG compiler.

Explanation of system flag ("Start system/End system"):

In PROPROG wt, users can define symbolic variables and use them in their program code without needing to create special flags for this. The system carries this out automatically during compilation in PROPROG wt by mapping these variables to the flags in the system area (i.e. the flags assigned by the system).

Since the system does this every time project code is generated, this means that you can customize separation limits at a later stage in the project too.

The preset standard user area for assigning absolute flag addresses within a b maXX resource in the non retain area is:

• %MB 0 - %MB 79999



The remaining range from %MB 80000 to %MB 2097147, for example, is reserved for the system for automatically converting the non retain symbolic user variables to this flag range.

The standard user area for assigning absolute flag addresses within a b maXX resource in the retain area is deactivated.

In the case of PLC versions with retain flags, users can shift upward the respective project request after the "End user/Start system" partial limit (e.g. from 10000000 to 10020000).

This would correspond to a retain flag area of %MB 10000000 - %MB 10019999 that users can trigger directly in their projects as absolute retain flags.

The remaining range from %MB 10020000 to %MB 10057323, for example, is reserved for the system for automatically converting the non retain symbolic user variables to this flag range.

If users send absolute flag addresses that are in the system area, the system issues an appropriate error message when compiling the project code.



Figure 23: Dividing and setting the b maXX drive PLC data area

Assigning absolute flag addresses in the program

An absolute b maXX drive PLC address or a variable field with data type

- 16-bit (WORD) can only be assigned for an address that can only be divided without remainder by two and zero.
- 32-bit (DWORD) can only be assigned for an address that can only be divided without remainder by four and zero.

Example:

PROPROG wt II:

You want to d	eclare	e a variable	e of (data type	e DWORD in the non retain data range.
d_abs_adr	AT	%MD12	:	DWORD;	(* symbolic variable to absolute address *)
Or also:					
di_abs_adr	AT	%MD16	:	DINT;	(* symbolic variable to absolute address *)
b_abs_adr1	AT	%MB16	:	BYTE;	
b_abs_adr2	AT	%MB17	:	BYTE;	
b_abs_adr3	AT	%MB18	:	BYTE;	
b_abs_adr4	AT	%MB19	:	BYTE;	

ProProg wt III:

Ē	Main2¥:Main2				
	Name	Δ	Туре	Address 🔺	
	di_abs_adr		DINT	%MD16	
	b_abs_adr1		BYTE	%MB16	
	b_abs_adr2		BYTE	%MB17	
	b_abs_adr3		BYTE	%MB18	
	b_abs_adr4		BYTE	%MB19 🗾	
┛					



One advantage of using absolute flags is that it can give quick and easy access to individual variable sections without needing additional masking and conversion functions:

If, for example, the system writes the value "DINT#16#98765432" to created absolute variable "di_abs_adr", the variable value can be further-processed directly as individual bytes (INTEL format: b_abs_adr1 = BYTE#16#32, ..., b_abs_adr4 = BYTE#16#98).

Caution! This type of programming is no longer instantiated and the sequence could be interrupted by an interrupt and called again from there with the result that after the interrupt ends the system carries out further processing with the wrong values!

4.4.4 b maXX drive PLC event tasks

b maXX drive PLC event tasks are for event-driven program calling (interrupt). Their type and code runtime determine the real-time response.

Implementation of the real-time response depends on the type of reference value setting and the b maXX controller's operating mode. Specified value setting can, for example, be implemented as follows:



- In a standalone drive via a BACI process data event task.
- In a networked drive via a "SYNC Signal 1 option module" event task.

The property of the event task is assigned via its event number:

Event	Designation	Level
0	CPU timer 1	14
1	Reserved	
2	CPU timer 2	13
3	Reserved	
4	BACI process data	13
5	Timer A	14
6	Timer A	13
7	Reserved	
8	BACI process data	14
9, 10	Reserved	
11	Sync-Signal 1 option module	14
12	Sync-Signal 2 option module	14

Task settings for SH	103_	_30			x
<u>E</u> vent:	11	SYNC signal 1 option module	Level: 14 💌	OK	
Priority:	3 4 5	reserved BACI process data Timer A	Level: 13	Cancel	
Watchdog Time:	6	Timer A reserved	Level: 13	<u>H</u> elp	
Stack:	8 9 10	BACI process data reserved reserved	Level: 14		
O SMALL	11	SYNC signal 1 option module	Level: 14		
• MEDIUM	12	SYNC signal 2 option module	Level: 14 💌	J	
		✓ <u>B</u> YPASS			
		□ <u>N</u> O SUSPEN	D		

Figure 25: Events of the der b maXX drive PLC event tasks.

NOTE

All the b maXX drive PLC tasks with an "EVENT" task type are dependent on the resource and need the **"BYPASS"** attribute. The initialization FBs within the program initialize and call the declared event task and their priorities. This means that with bypass event tasks, the priority, watchdog time, "SAVE FPU" and "NO SUSPEND" are meaningless. A higher interrupt level means a higher priority.

In the case of several event tasks that can mutually interrupt one another or with multiplenested function blocks, you should adapt the stack to Large or XLarge.

4.5 b maXX drive PLC user libraries

The PROPROG wt user libraries are divided into firmware and user libraries that can be hardware-dependent or hardware-independent. You can only use hardware-dependent libraries in resources of the specified target system. The hardware dependence of b maXX drive PLC libraries is shown by ***_PLC01_** in the library designation.

PROPROG wt II: The version is indicated as follows: 20bd00.

- 20 is the incompatible version.
- 00 is the compatible version.

In the case of compatibility of the input and output variables of the function blocks, the version is incremented by one, e.g. 20bd01, 20bd02, etc. if you add the library to an FB, e.g. an input or output, the version before the "bd" is incremented by one and set to zero after the "bd", e.g. 20bd03 to 21bd00.

ProProg wt III: The version is indicated as follows: 30bd00.

- 30 is the incompatible version.
- 00 is the compatible version.

In the case of compatibility of the input and output variables of the function blocks, the version is incremented by one, e.g. 30bd01, 30bd02, etc. if you add the library to an FB, e.g. an input or output, the version before the "bd" is incremented by one and set to zero after the "bd", e.g. 30bd03 to 31bd00.

The user libraries are divided into:

- Firmware: b maXX drive PLC Board functionality e.g. starting a PROPROG wt bypass event task.
- Data types: b maXX drive PLC-specifically assembled data types and fields, e.g. register structure of option boards.
- Standard FBs: Elementary FBs for local drive control engineering.
- Technology modules: Drive functionality that can be completely applied.



Overview of completely hardware independent PLC libraries PROPROG wt II:

CD-ROM	Contains library	
Standard libraries	BM_TYPES_20bd06	Baumüller data types
	UNIVERSAL_20bd01	Basic function blocks
	MC_SYS_20bd01	Firmware blocks (used by other libraries)

ProProg wt III:

CD-ROM	Contains library	
Standard libraries	BM_TYPES_30bd01	Baumüller data types
	UNIVERSAL_30bd00	Basic function blocks
	MC_SYS_30bd00	Firmware blocks (used by other libraries)

Overview of b maXX group dependent PLC libraries which can used by b maXX drive PLC and b maXX controller PLC (from the stated below version upwards) PROPROG wt II:

CD-ROM	Contains library	
TB cam disk	CAM_PLC01_21bd00	FBs for "cam disk" technology component
TB winder	WINDER_PLC01_20bd01	FBs for "winder" technology component
CANopen	CANopen_PLC01_20bd03	FBs for b maXX option module BM4-O-ETH-02 or BM4-O-CAN-04 (CANopen-Master) BM4-O-CAN-03 (CANopen-Slave)
Ethernet	TCP_PLC01_21bd01	FBs für option module BM4-O-ETH-01 or BM4-O-ETH-02 (Ethernet)

ProProg wt III:

CD-ROM	Contains library	
TB cam disk	CAM_PLC01_30bd00	FBs for "cam disk" technology component
TB winder	WINDER_PLC01_30bd00	FBs for "winder" technology component
CANopen	CANopen_PLC01_30bd00	FBs for option module BM4-O-ETH-02 or BM4-O-CAN-04 (CANopen-Master) BM4-O-CAN-03 (CANopen-Slave)
Ethernet	TCP_PLC01_30bd01	FBs für option module BM4-O-ETH-01 or BM4-O-ETH-02 (Ethernet)

Overview of hardware dependent PLC libraries which can be used only by b maXX drive PLC PROPROG wt II:

CD-ROM	Contains library	
Standard libraries	SYSTEM1_PLC01_20bd00	Function blocks for BM4-O-PLC-01
	SYSTEM2_PLC01_20bd00	Firmware blocks for BM4-O-PLC-01

ProProg wt III:

CD-ROM	Contains library	
Standard libraries	SYSTEM1_PLC01_30bd00	Function blocks for BM4-O-PLC-01
	SYSTEM2_PLC01_30bd00	Firmware blocks for BM4-O-PLC-01

You must state the directory path for libraries under PROPROG wt, Options, Directories. The b maXX drive PLC libraries are inserted in the PROPROG wt project tree under libraries.

You can call HTML help for each FB that gives you a description of the inputs and outputs (see the PROPROG wt II Programming Manual and the Online Help System of ProProg wt III respectively).

4.5.1 b maXX drive PLC firmware

The b maXX drive PLC firmware consists of function blocks (FBs) that use parameter transfers to communicate with functions on the b maXX drive PLC-CPU. You can only use these FBs in a resource-dependent way, i.e. in dependence on the target system.

PROPROG wt II:

You must use library

SYSTEM2_PLC01_20bd00 (or above)

to insert the BM4-O-PLC-01 firmware into a project. The library contains the following range of functions:

- Start bypass event task and freely programmable LEDs on the b maXX drive PLC.
- P, PI controller, 48-bit division via electronic transmission, integration, differentiation.
- Function blocks for interface module to USS[®] and 3964R[®] protocols.



NOTE

The b maXX drive PLC firmware is used by several b maXX drive PLC user libraries. This means that with a b maXX drive PLC user library, it may be necessary to insert the requested firmware library SYSTEM2_PLC01_20bd00 or above (See description of the respective user library). The most current version in each case is on the PROPROG program CD and it is automatically installed when you install PROPROG wt II.

At selection of the "Pattern for BM4_O_PLC01" under "File\New Project" the library SYSTEM2_PLC01_20bd00 (or above) automatically is set. The standard user library SYSTEM1_PLC01_20bd00 (or above) in the normal case also will be necessary in projects and will be delivered on a seperate CD (see ▷b maXX drive PLC user libraries < from page 47 onward).

The same is true for ProProg wt III and its libraries.

ProProg wt III:

You must use library

SYSTEM2_PLC01_30bd00 (or above)

to insert the BM4-O-PLC-01 firmware into a project. The library contains the following range of functions:

- Start bypass event task and freely programmable LEDs on the b maXX drive PLC.
- P, PI controller, 48-bit division via electronic transmission, integration, differentiation.
- Function blocks for interface module to USS[®] and 3964R[®] protocols.

4.5.2 b maXX drive PLC Board functions

Firmware library SYSTEM2_PLC01_20bd00 (or above) contains function blocks (FBs) for checking event signals for interrupts and board LEDs. Function block INTR_SET is used to initialize and start b maXX drive PLC event task (bypass). Function block LED is used to allow the use of freely programmable LEDs.

Two FBs for code runtime measurement are provided to optimize code runtimes within b maXX PLC resources.

PROPROG wt II BM4-O-PLC-01:

The FBs are inserted via user library SYSTEM1_PLC01_20bd00 and above.

ProProg wt III BM4-O-PLC-01:

The FBs are inserted via user library SYSTEM1_PLC01_30bd00 and above.

You must limit the code block to be measured within a task by placing FBs TIME_MEASURE_START and TIME_MEASURE_END appropriately. The system outputs the result of the measured code block's runtime at FB TIME_MEASURE_END as a time difference in μ s (see also the online description of FBs TIME_MEASURE_START and TIME_MEASURE_END). Code running times up to 10 ms (BM4-O-PLC-01) are able to be measured with these function blocks.

4.5.2.1 Function block INTR_SET

Function block INTR_SET starts a bypass event task in a start-up task.

You must set the PROPROG wt event task with the program to the event and to the Bypass attribute.



Figure 26: Initializing and enabling a bypass event task via function block INTR_SET.

Parameter	Input	Value Range
i_EVENT	Interrupt hardware program number	8-bit signed
i_MODE	Reserve	16-bit signed
i_PAR1	CPU timer (1,2) value multiplier to base 50µs	16-bit signed
i_PAR2	Reserve	16-bit signed
x_EN	Block/enable the interrupt	1-bit

Parameter	Output	Value Range
x_ERR	Error bit	1-bit

Description

Using FB INTR_SET, users can configure and activate various system-internal interrupt sources. You can then use these interrupts in the program to activate event tasks.

An event number must be connected at input i_EVENT. This number specifies the interrupt source of the event task. If the interrupt source in question is a CPU timer interrupt, you must additionally state a factor to the time base 50 µs at input i_PAR1.

You can use x_EN = FALSE to disable a previously activated interrupt.



List of event numbers for event tasks:

Event	Designation	Level
0	CPU timer 1	14
2	CPU timer 2	13.
4	BACI process data	13.
5	Timer A	14
6	Timer A	13.
8	BACI process data	14
11	Sync-Signal 1 option module	14
12	Sync-Signal 2 option module	14

The event number at input i_Event must be identical with the setting of the event task within the resource. The Bypass attribute must be activated.

NOTE

A higher-priority interrupt interrupts a lower-priority one. For events 0 and 2, CPU timer 1 (or 2) interrupt, you must additionally state at input i_PAR1 the factor for time base 50 µs.

The higher-priority timer "CPU timer 1" (i_EVENT = 0) and the lower-priority timer "CPU timer 2" (i_EVENT = 2) can be used at the same time.

"Board timer A" high priority (i_EVENT = 5) and "Board timer A" low priority (i_EVENT = 6) cannot be used at the same time.

Events "SYNC-Signal 1 option module" (i_EVENT = 11) and "SYNC-Signal 2 option module" (i_EVENT = 12) cannot be used at the same time. "BACI process data" low priority (i_EVENT = 4) and "BACI process data" high priority (i_EVENT = 8) cannot be used at the same time.

In the case of events i_EVENT = 4, 8, 11 and 12, you do not generally need to use INTR_SET, since the INTR_SET block is already permanently integrated in FB "BACI_INIT" (see standard library "SYSTEM1_PLC01_20bd00" (PROPROG wt II) or "SYSTEM1_PLC01_30bd00" (ProProg wt III) or above).

Example 1:

User POE (e.g. called "timer") is to be linked with the higher-priority CPU timer 1 (i_EVENT = 0) and to be called cyclically at 5-ms intervals.

Implementation:

In the cold boot and warm start task, the system calls an INI-POE that contains the configured INTR_SET.

The following formula applies to the timer interval:

Timer interval = i_PAR1 • 50 µs

For the desired 5-ms interval, this yields: $i_PAR1 := (5000 \ \mu s / 50 \ \mu s) = INT#100$. Representation of the configured and released INTR_SET:





This sets up and activates the interrupt during the PLC start-up procedure.

You must link user POE "timer" in group task within the BM4_O_PLC01 resource as a task type "EVENT" to event "CPU_Timer 1" with setting option "BYPASS":

Task settings for S	H03_30	×
<u>E</u> vent:	0 CPU-Timer 1 Level: 14 💌	OK
<u>P</u> riority:	0	Cancel
Watchdog Time:	100 ms	<u>H</u> elp
Stack: SMALL MEDIUM LARGE XLARGE	Options: SAVE <u>E</u> PU I <u>B</u> YPASS NO SUSPEND	

Figure 28: Linking to event "CPU timer 1" as a bypass task.

Example 2:

Start the "Timer A" interrupt at 5 ms and generate the trigger signal at BACI signal output "TRIGGER1":

By contrast with CPU timer 1 (or 2), you can also use board timer A as a trigger signal for option modules that need the trigger signals. This is because you can only use "Timer A" to both trigger a cyclical interrupt and carry out triggering.

First of all, you set up the event task within the BM4_O_PLC01 resource via event "Timer A" with event number 5 (or 6).



Within the cold boot/warm start task, the system initially calls FB "TIMER_A_INIT" twice (see standard library "SYSTEM1_PLC01_20bd00" (PROPROG wt II) or "SYSTEM1_PLC01_30bd00" (ProProg wt III) or above) and then calls FB "INTR_SET".

- The first call of "TIMER_A_INIT" sets up the timer for 5 ms.
- The second call connects the generated 5-ms signal to BACI output "TRIGGER1" which can then be processed by the option modules.
- The "INTR_SET" call then sets up and activates the timer A interrupt so that users can run their POE synchronized with the generated 5-ms trigger signal.



Figure 29: Start of the "Timer A" bypass event task with a period of 5 ms and simultaneous use of "Timer A" as a trigger signal for BACI option modules.

4.5.2.2 Function block LED

You can use the LED function block from firmware library **SYSTEM2_PLC01_20bd00** (PROPROG wt II) or **SYSTEM2_PLC01_30bd00** (ProProg wt III) (or above) to program the b maXX drive PLC LEDs on the board.



Figure 30: LED function block

Parameter	Input	Value Range
b_LEDS	LED set screen form	8-bit

Description

The LEDs on the left of the b maXX drive PLC board light up green; the ones on the right light up red. Bits 0-3 of the 8-bit pattern at the LED input are output to the four LEDs as follows:

H1	H2
\otimes	\otimes
green Bit 3	red Bit 2
H3	H4
\otimes	\otimes
green Bit 1	red Bit 0

Figure 31: LEDs of the BM4-O-PLC-01 option module

4.5.3 b maXX drive PLC data types

In a PROPROG wt project, data is exchanged between the b maXX drive PLC and the option modules for b maXX drive PLC by means of variables of the appropriate data type. User library BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) or above makes available a large number of ready-made data types (structures and arrays). In general, these structured data types are used in the ready-made standard and technology libraries, which makes it very easy to communicate with the option modules.



For this, the most important variables for the different functions and slots of the individual option modules are defined in template BM4_O_PLC01 ("File/New project.../Template for BM4_O_PLC01").

This means that users only need to choose the slot-dependent variable from the template that corresponds to the fitted option module and to connect it to the appropriate inputs and outputs of the function blocks that are being used (that are available in the different libraries for the option module).

In the libraries, reference will be made at the relevant locations to the data types of BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) or above that were used.

Users can and should of course use the predefined data types in BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) or above.

You cannot directly call the worksheet of BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) or above in the project tree; however, you can view the data types contained there by switching the tab in the footer of the project tree editor from "Project" to "Libraries" and then doubleclicking on the BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) or above worksheet:



Figure 32: View of Baumüller data types "BM_TYPES_20bd03" that are integrated in your project.

You can access these data types when assigning variables via the variable dialog under "Properties/Automatic variable declaration":

PROPROG wt II:

Click on the button "Properties ..." in PROPROG wt II in variables dialog. The window "Automatic Variables Declaration" is opened.

Automatic Variables Declarat	ion			×
POU Main			ОК	
Block	Variable			-
<u>U</u> sage:	Name: ggg		Cancel	
VAR	<u>A</u> T:		<u>H</u> elp	
□ <u>B</u> ETAIN				
	Data type:			
	BYTE_16_BMARRAY	•		
	BYTE 16 BMARRAY			
	BYTE_256_BMARRAY			
	BYTE_4_BMARRAY			
	BYTE_46_BMARRAY	_		
	BYTE_512_BMARRAY			
Co <u>m</u> ment:				

Figure 33: Automatic variable declaration.

ProProg wt III:

The automatical variable declaration is integrated in the variable dialog in ProProg wt III.





When you create a PROPROG wt project using template BM4_O_PLC01, the variables for data exchange are already declared in the global variable worksheet. You will find one (and sometimes two) variables per slot of the option module.

Example:

For initialization, option module BM4-O-IEI-01 needs settings in various registers.

With the option module in slot G, this yields the following variable declaration (that is already created in the template):

PROPROG wt II:

_IEI_Ctrl_Slot_G	AT	%MB3.2258000 : IEI_PLC_BMSTRUCT;	
		(* Option module IEI (BM4-O-IEI-01) *	۲)

ProProg wt III:

Global_Variables:5H03_30.D_PLC01					
Γ		Name	Туре	Address 🔺	
		_IEI_Ctrl_Slot_G	IEI_PLC_BMSTRUCT	%MB3.2258000	
Ŀ	•			▶ <i> </i> ,	

Figure 35: Declaration of variables

The complete register structure of IEI_PLC_BMSTRUCT is stored with its elements and the data types used in BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) or above (extract):

PROPROG wt II - bmaXX_demo - [BM_TYPE9	_20bd03:]						_ 🗆 🗙
Eile Edit View Project Build Objects Layo	ut O <u>n</u> line E <u>x</u> tra	as <u>W</u> indow <u>?</u>					_ & ×
🛛 🗅 🎏 🖬 🖪 🤮 🐇 🖬 🖻 🗠 🗠	0.0	🗖 🔨 😨 🛙	3 ➡ 12 \$ 2 1	š 🔬 🕸 f	4 ●●		
T to to to Q - (+) =	输出合		1+0 1+1; T ¹ 17 L ¹ 12 [-1+ -1+]	C+1 -12-	😌 🖬 🖮 🔁		
	2079 1 2080 \$ 2081 0 2082 2 2083 0 2084 0 2086 0 2086 0 2088 0 2089 0 2090 0 2091 0 2092 0 2092 0 2093 0 2094 0 1 ■ BM_TYF	EI_PLC_BHST TRUCT * 0 *) * 4 *) * 4 *) * 2 *) * 4 *) * 2 *) * 2 *) * 2 *) * 20 *) * 20 *) * 24 *) * 22 *) * 24 *) * 30 *) * 30 *) * 30 *) * 32 *)	RUCT : w_RESERVEDO w_LATCH, STATUS, REC ud_COUNTER_LATCH1 ud_COUNTER_LATCH2 ud_COUNTER_LATCH3 w_RESERVED20 w_RESERVED20 w_RESERVED24 w_RESERVED24 w_RESERVED24 w_LATCH3_DISABLE w_LATCH3_DISABLE w_LATCH3_DISABLE	: WORD; : WORD; : UDINT; : UDINT; : UDINT; : WORD; : WORD;	(* Latch-Status- (* Counter-Latch (* Counter-Latch (* Counter-Latch (* Counter-Prelo (* Latch3-Latch- (* Latch3-Latch- (* Latch3-Latch-	Register *) -Register 1 *) -Register 2 *) *) ad-Register *) Disable-Register * Disable-Register *	

Figure 36: Extract from the register structure of IEI_PLC_BMSTRUCT

The elements of variable _IEI_Ctrl_Slot_G now form the tab of the option module in slot G. For more information on using the option module, see the BM4-O-IEI-01 Operating Instructions.



NOTE

In the variable dialog, the system makes available the data types for assignment in a selection dialog. In this connection, the individual data types of library BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) or above are generally indicated by the abbreviation "_BM" (_BMARRAY, _BMSTRUCT, etc.) The library's worksheet is write-protected and you can view it via the library tree (see above).

4.5.4 The Standard Function Block Libraries

The standard libraries contain function blocks (FBs) with the basic functionality for local programming and configuration of the real-time response.

These function blocks are located in:

PROPROG wt II:

- SYSTEM1_PLC01_20bd00 (or above)
 - BACI communication (process data, requirements data)
 - Function block for BACI (input, timer, output, trigger)
 - USS[®] protocol interface module
 - Code runtime measurement
- SYSTEM2_PLC01_20bd00 (or above)
 - b maXX drive PLC firmware
 - Firmware block LED
 - Firmware block INTR_SET
 - 3964R[®] protocol interface module
 - TER_x terminal blocks
- UNIVERSAL_20bd01 or above (regardless of the hardware)
 - Drive status and control via FB DRIVE1
 - Extrapolators, ramp generators, position generators, Min-Max and limitation FBs
 - Virtual leading axle FB TRAJECTORY_GEN1.

ProProg wt III:

- SYSTEM1_PLC01_30bd00 (or above; for BM4-O-PLC-01)
 - BACI communication (process data, requirements data)
 - Function block for BACI (input, timer, output, trigger)
 - USS[®] protocol interface module
 - Code runtime measurement
- SYSTEM2_PLC01_30bd00 (or above; for BM4-O-PLC-01)
 - b maXX drive PLC firmware
 - Firmware block LED
 - Firmware block INTR_SET
 - 3964R[®] protocol interface module
 - TER_x terminal blocks
- UNIVERSAL_30bd00 or above (regardless of the hardware)

- Drive status and control via FB DRIVE1
- Extrapolators, ramp generators, position generators, Min-Max and limitation FBs
- Virtual leading axle FB TRAJECTORY_GEN1.

4.5.5 b maXX drive PLC technology components

You can extend the standard user libraries by adding complete drive functionality, i.e. the technology components. These are:

•	Technology component cam disk:	PROPROG wt II: user library CAM_PLC01_21bd00 (or above)
		ProProg wt III: user library CAM_PLC01_30bd00 (or above)
•	Technology component register controller	PROPROG wt II: user library REGISTER_PLC01_20bd00 (or above)
		ProProg wt III: user library REGISTER_PLC01_20bd00 (or above)
•	Technology component winder:	PROPROG wt II: user library WINDER_PLC01_20bd00 (or above)
		ProProg wt III: user library WINDER_PLC01_20bd00 (or above)

The technology components offer drive functionality that provide a large number of application solutions due to interconnection and multiple instantiation.



NOTE

For integration, all the user libraries of the technology components need data types BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) and above.

4.5.6 Inserting a User Library into a Project

In PROPROG wt, you insert user libraries in the project tree under libraries. If the library in question is firmware, you must set .fwl when choosing the file format.



Figure 37: Standard selection of user libraries, firmware and data types using the libraries filter

NOTE

Libraries for PROPROG wt are delivered as packed (ZWT format) files). You must unpack the ZWT file under PROPROG wt. When unpacking the file, the system automatically stores the write-protected library in the specified PROPROG wt library path (Tools > options menu). In PROPROG wt II an untitled project displays that you should close without saving it. In ProProg wt III a project will be created with the name of the ZWT file. This project is no longer required.

The system automatically unpacks the firmware libraries to the firmware library directory of PROPROG wt.



4.6 BACI system description for the b maXX drive PLC

4.6.1 Direct access to the BACI hardware from the b maXX drive PLC

BACI is a bus system with several slots between which data must be exchanged. In this context, as well as being connected to the common BACI-BUS by the BACI signals, every module is also connected by dual-port RAM.

A differentiation is made between the BACI-Master (b maXX controller and b maXX drive PLC) and the BACI-Slave. Only BACI-Masters can access the option modules that are assigned to them across the BACI-BUS. BACI-Slave option modules cannot access each other let alone the BACI-Master. Each individual option module can use its own dual-port RAM to query and evaluate the data that the master wrote.

The b maXX drive PLC represents itself to the b maXX controller as a BACI-Slave, which means that only the controller can access the PLC via the BACI-BUS. The PLC can use its own dual-port RAM area to evaluate the data that the controller wrote.

Slot overview BACI of the option module in the b maXX 4400 unit:

	BACI - BUS
SLOT F (b maXX controller)	
SLOT G	
SLOT H (b maXX PLC)	
SLOT J	
SLOT K	
SLOT L	
SLOT M	

Figure 38: Slot overview

From the PLC's point of view, it is only possible in the application to contact BACI slots G to M to communicate with the option modules that are assigned to the PLC. It is also possible to access SLOT H (the preferred PLC slot) via BACI if the PLC itself is fitted in another slot.

Slot	Assigned IEC 61131-3 range (max.)
SLOT G	%MB 3.20000000 - %MB 3.20262143
SLOT H	%MB 3.30000000 - %MB 3.30262143
SLOT J	%MB 3.40000000 - %MB 3.40262143
SLOT K	%MB 3.50000000 - %MB 3.50262143
SLOT L	%MB 3.60000000 - %MB 3.60262143
SLOT M	%MB 3.70000000 - %MB 3.70262143
b maXX drive PLC's own dual-port RAM range	%MB 3.90000000 - %MB 3.90262143

NOTE

The PLC can only ever access SLOTs on a different option module. To evaluate the data from the controller, the PLC must not contact its own slot range in which the PLC itself is located; rather, it must always proceed over its own dual-port RAM range (%MB 3.90000000 - %MB 3.90262143).

In the application, you can then assign a software structure that describes the memory and register structure of an option module and which is used in a ready-made library to a variable that points to the slot that is used.

Global variables of this type are already appropriately predefined in the BM4_O_PLC01 template in PROPROG wt in the "Global_Variables" global variable sheet such that, depending on the option module and the slot that is used, users only need to connect to the library components that are in use. In future, the configurator – which will be integrated at a later expansion stage of PROPROG wt for the b maXX drive PLC – will automatically carry out these tasks. This means that users will no longer have any contact with the SLOT ranges mentioned above.

For further explanations of the structures and functions of the option modules, refer to their respective operating instructions and application manuals.

4.6.2 Process data communication between b maXX controller and b maXX drive PLC, synchronization to a common BACI hardware signal source

In the case of process data communication between the b maXX controller and the b maXX drive PLC a basic differentiation is made between two applications:

 Process data communication between the b maXX controller and the b maXX drive PLC is on a direct basis with the controller and the PLC not being synchronized to a BACI hardware signal. This means that the controller itself triggers the interrupts on the PLC for communication every time, taking into account the set actual value period after processing of its own controller actual value channel. This prevents the controller and the PLC accessing the BACI at the same time and means that communication is always synchronized between the two devices.



To deal with this case, you must connect at FB "BACI_INIT" of library SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher at input i_EVENT event INT#4 (priority level 13) or INT#8 (priority level 14) and must also create a task with the same event in which process data communication to b maXX controller via FB "BACI_PD_COMM" is to run.



Process data communication directly by b maXX controller (MasterCS_Actual1):

Figure 39: Process data communication

2. Direct synchronization to a common source:

In general, the system requests that several controllers – if they are running on an interconnected basis, for example – must run synchronized with one another. You can achieve this by synchronizing all the controllers to a common BUS signal (e.g using a common CANsync ring) that is generated at one location and which the option modules switch through to the respective local BACI buses of the b maXX controllers (preferably to BACI signal SYNC1).

Using case 1 as the basis, this would mean that an option module synchronizes the b maXX controller, which, after processing its assigned actual value channel with its PLC process data, also exchanges data on a synchronized basis.

However, since a certain dead time is involved due to the duration of processing in the controller and since it is usually necessary in any case to exchange (field bus) data on a synchronous basis with the option module that passes on or generates the signal to the b maXX controller, in practice a different procedure is chosen: You synchronize both the controller and the PLC directly to the same hardware signal (usually BACI signal SYNC1).

As a result, you can achieve better synchronization of all the controllers and PLCs since it is only hardware-dependent.

For this case 2, you must connect on FB "BACI_INIT" of library SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher at input i_EVENT event INT#11 (use priority level 14, SYNC1 signal from the BACI) or INT#12 (use priority level 14, SYNC2 signal from the BACI) and create an event-like task in which process data communication with the b maXX controller is to run via FB "BACI_PD_COMM" and possibly additional field bus communication is to take place with the option module that triggered the event.



Figure 40: Process data communication via a SYNC1 or SYNC2 signal

You should, however, take into account that in the case of a "Sync-Offset = 0" controller parameter that is preset by default, both the controller and the PLC try to access the BACI data at the same time when exchanging process data and this results in an access conflict. To offset the access instants of the controller and the PLC to the BACI, you must set a negative Sync-Offset of -25 μ s in the controller. This ensures that processing of the actual value channel in the controller is always completed and the current actual values from the controller are available to the PLC when it processes the interrupt that the BACI signal triggered.

Refer to the descriptions of FBs "BACI_INIT" and "BACI_PD_COMM" of library SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher for information about the necessary settings for synchronization of both cases in the controller and the PLC.

4.6.3 b maXX drive PLC interrupt sources that the application can use

For the b maXX PLC, you can represent hardware signals from the BACI, write accesses from the controller to the PLC, and various PLC-internal sources such as the CPU timer or interrupt sources that can be linked to specific program sections of an application via the event selection of the EVENT-BYPASS task.



INFORMATION ON EVENT BYPASS EVENT TASKS

If you insert an EVENT task type in PROPROG wt II, you must also set the "BYPASS" attribute.

Since EVENT-BYPASS tasks are called directly by the event and are not monitored by the runtime system, the "interval" and "watchdog time" settings in task management are mean-ingless and are ignored.

Apart from this, you must in principle not set any breakpoints or activate an address status in the program sections that are linked to an EVENT BYPASS task.

You must set up an interrupt source during the PLC's cold boot/warm restart stage either by means of function block "BACI_INIT" (for events "4", "8", "11" and "12", see the standard library SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher) or of "INTR_SET" for events "0", "2", "5", "6" (see standard library SYSTEM2_PLC01_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher). Only then, in PLC status "RUN" when the event occurs, can the system call the program section that is assigned in the EVENT BYPASS task.

Due to the assignment of an event to a program section, this section is always synchronized and the system processes it at the same periods as the event source.



Representation of all the EVENTS on the BM4-O-PLC01 option module that can trigger an interrupt:

Figure 41: Representation of all EVENTS

Detailed configuration options for the Timer A EVENT by choosing the BACI signal via the INPUT function of block "TIMER_A_INIT" and applying to the internal TA signal:



Figure 42: Detailed configuration options

4.6.4 Generating BACI signals via function block TIMER_A_INIT

You can also configure the b maXX drive PLC for BACI signal output (b maXX drive PLC -> BACI); in this case, it can function as a trigger source for other option modules, for example.

In this connection, the signal source is generated either on the PLC itself or it comes from another BACI signal that is rerouted via the PLC and may, if necessary be stepped-down the description function block "TIMER A INIT" of (see for library SYSTEM1 PLC01 20bd00 (PROPROG wt II) SYSTEM1 PLC01 30bd00 or (ProProg wt III) or higher).

Configuration options for generating BACI signals by injecting the internally generated TA signal to the BACI signal line via the OUTPUT function of block "TIMER_A_INIT":





Figure 43: Configuration options for generating BACI signals

By calling the OUTPUT function several times, you can multiplex the internal TA signal to different BACI signals at the same time.

You can reroute BACI signal via the PLC (if desired with signal division) by appropriately combining the INPUT and OUTPUT functions of "TIMER_A_INIT" (see the "TIMER_A_INIT" description).

4.6.5 "TIMER_A_INIT" function block

Description of function block "TIMER_A_INIT" of library SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher.

The function block for BACI has several functions:

Function	Description
INPUT	You can choose a BACI signal, divide it and multiplex it to the internal TA line and, if desired, use it to trigger a TIMER_A_Interrupt.
TIMER	INPUT function: By selecting the "4MHz" source (= time base of Timer_A) and stating a divider value, you can generate virtually any cycle signal. If desired, you can use it to trigger a TIMER_A_Interrupt.
OUTPUT	The internal TA line is switched to a selectable BACI output.

Function	Description
TRIGGER	If you combine the TIMER function with the OUTPUT function, you can switch the generated cycle signal to one or more BACI outputs.
Enable/disable OUTPUT signal	You can disable BACI outputs and enable them again on selec- tive basis.



NOTE

on the TIMER_A_INIT block:

Application: It can be integrated at the initialization stage (cold boot/warm restart task) as well as in the DEFAULT task or in any cyclic task you like.

In this connection, you can place the block several times at different locations or several times successively to install the corresponding individual function.

If you use the block in the cyclical section, the system must set input x_EN back to FALSE after activating the function so that the TIMER can run or the divider can carry out division!

Parameter input	Data type	Description
x_MODE	BOOL	Selection of the basic function (signal direction)
us_SIGNAL	USINT	signal source/destination
u_DIVIDER	UINT	Divider value
x_EN_SIGNAL_OUT	BOOL	Enable/disable the output signal when the OUT- PUT function is selected
x_EN	BOOL	Enable the block

Parameter output	Data type	Description
x_ERR	BOOL	Error bit

Input x_MODE:

Using x_MODE, you can choose the basic function:

x_MODE = FALSE (us_SIGNAL = signal source): INPUT, TIMER functions. => The system generates an internal TA signal.

 $x_MODE = TRUE$ (us_SIGNAL = signal destination): Enable/disable OUTPUT, TRIG-GER, OUTPUT signal. If the BACI output has been released, the internal TA signal is switched through to the specified BACI signal destination.



Input us_SIGNAL:

For x_MODE := FALSE: us_SIGNAL :=	Selection of signal source:
USINT#0	4 MHz
USINT#1	MasterCS_Set1
USINT#2	MasterCS_Actual1
USINT#3	MasterCS_Set2
USINT#4	MasterCS_Actual2
USINT#5	INTA
USINT#6	INTB
USINT#7	INTC
USINT#8	INTD
USINT#9	INTE
USINT#10	INTF
USINT#11	TRIGGER1
USINT#12	TRIGGER2
USINT#13	SYNC1
USINT#14	SYNC2
USINT#15	INT_REG
> 15	Not allowed

For x_MODE := TRUE: us_SIGNAL :=	Selection of BACI signal destination
USINT#0 - USINT#4	Not allowed
USINT#5	INTA
USINT#6	INTB
USINT#7	INTC
USINT#8	INTD
USINT#9	INTE
USINT#10	INTF
USINT#11	TRIGGER1
USINT#12	TRIGGER2
USINT#13	SYNC1
USINT#14	SYNC2
> 14	Not allowed

Input **u_DIVIDER**:

Is only evaluated with the INPUT and TIMER functions (x_MODE = FALSE).

u_DIVIDER indicates the ratio with which the input signal is divided. In this connection, the following division formula applies:

Internal TA signal := us_SIGNAL / (u_DIVIDER + 1)

In the case of u_DIVIDER = 0, this means that the external BACI signal is switched through directly on a 1:1 basis to the internal TA signal, i.e. the signal is not divided.

Input x_EN_SIGNAL_OUT:

Is only evaluated with the OUTPUT and TIMER functions (x_MODE = TRUE).

The internal TA signal is switched to the selected BACI output (x_EN_SIGNAL_OUT := TRUE) or is disabled again (x_EN_SIGNAL_OUT := FALSE).

The internal TA signal can be output to several BACI outputs by means of several successive block calls and different BACI destinations.

Input **x_EN**:

You use $x_EN = TRUE$ to install the respective function. In the case of $x_EN := FALSE$, the system does not process the block. If the block is executed cyclically, the system should reset input x_EN to FALSE after activation of an individual function so that the TIMER can run or the BACI input signal can be divided.

Output x_ERR := TRUE:

Selection of the BACI destination is not supported!

Detailed explanation of the functions:

INPUT special function: TIMER (x_MODE := FALSE and us_SIGNAL := USINT#0):

A timer basis of 4 MHz is permanently preset. Formula for calculating the time period:

Time period = $(u_DIVIDER + 1) \times 0.25 \mu s$.

Minimum value for "u_DIVIDER": UINT#999 => Time = 250 µs

Maximum value for "u_DIVIDER": UINT#65535 => Time = 16384 µs

Formula for calculating u_DIVIDER with the specified time period:

u_DIVIDER = (time period / 0.25 µs) - 1

If you want the timer to trigger an interrupt via the internally generated TA signal, the system must, after calling the timer function via "TIMER_A_INIT", execute system function block "INTR_SET" (see firmware library SYSTEM2_PLC01_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher) with parameters: i_EVENT := INT#5 (bzw. i_EVENT := INT#6) for TIMER A. (The other parameters i_MODE, i_PAR1 and i_PAR2 are ignored).

In this connection, you should choose a time period that is not too low or too high; otherwise, the next cyclical interrupt may already be pending before the currently running one has been completed. Since the interrupts are set up as high-priority bypass interrupts,



only this interrupt runs and the PLC goes offline (-> The other application "no longer responds").

To avoid this, you are advised to set an interrupt interval of at least 250 µs. This corresponds to a "u_DIVIDER" value of >= UINT#999.

Special function: TRIGGER

If you combine the TIMER function with the OUTPUT function, you can switch the generated cycle signal as a trigger signal to one or more BACI outputs.

1. Call of the TIMER function:

A timer basis of 4 MHz is permanently preset. If you connect a divider value at input "u_DIVIDER" that is less than UINT#3, the system generates a continuous LOW signal at the internal timer output TA. If after this, you want to output the internal TA signal using the OUTPUT function to the BACI (e.g. a PLC function as a BACI trigger source), you should first enter in the INPUT function at least one value greater than UINT#7 to ensure that you do not violate the BACI-BUS timing.

Formula for calculating the time period:

Time period = (u DIVIDER + 1) x 0.25 μ s. Minimum value for "u DIVIDER": UINT#8 => Time = 2.25 µs Maximum value for "u_DIVIDER": UINT#65535 => Time = 16384 µs

Formula for calculating u_DIVIDER:

u DIVIDER = (time period / 0.25 µs) -1

If you want the trigger pulse to also trigger an interrupt, it is advisable to set an interrupt interval of at least 250 µs. This corresponds to a "u DIVIDER" value of >= UINT#999.

Call of the OUTPUT function (BACI destination = USINT#11 (Trigger 1)): see below

OUTPUT special function: Enable/disable BACI signal:

If you want to output the internally generated TA signal to several BACI outputs at the same time, the system can call the block several times in succession using the respective BACI destination and "x_MODE := TRUE" as well as "x_EN_SIGNAL_OUT := TRUE" for driver enable. Using "x_EN_SIGNAL_OUT := FALSE", you can reverse the enable on a selective basis.

Internal TA signal is intended to generate an interrupt:

After parameterizing "TIMER A INIT", system function block "INTR SET" (see firmware library SYSTEM2 PLC01 20bd00 (PROPROG wt II) or SYSTEM2 PLC01 30bd00 (ProProg wt III) or higher) must be executed with parameters: i EVENT := INT#5 (or i EVENT := INT#6) for TIMER A. (The other parameters i MODE, i PAR1 and i PAR2 are ignored).

Example application 1:

72

The b maXX drive PLC on the SYNC1 line is intended to generate for a BM4-O-IEI-01 option module a trigger signal with a 2-ms period. A PLC program section is to be executed synchronously with the generated trigger signal.
- Step: generate an internal TA signal via the timer function with a time period of 2 ms: Execute FB "TIMER_A_INIT" with: x_MODE: = FALSE; us_SIGNAL := USINT#0; (for timer function); u_DIVIDER = (2000 µs / 0.25 µs) -1 = UINT#7999;
- 2. Step: Output the TA signal as a trigger signal to SYNC1: Execute block "TIMER_A_INIT" with: x_MODE: = TRUE; us_SIGNAL := USINT#13; (for target selection SYNC1); x_EN_SIGNAL_OUT := TRUE;
- Step: Execute block "INTR_SET" with i_EVENT := INT#5.
 => By creating an EVENT BYPASS task with event "5", you can execute a PLC program synchronously with the trigger signal.

Example application 2:

You want input BACI signal TRIGGER1 to be divided by a value of 10 and then to be switched back to output BACI line TRIGGER2; apart from this, the divided signal should trigger an interrupt.

- 1. Step: TRIGGER1 -> 1:10 -> internal TA signal: Execute FB "TIMER_A_INIT" with: x_MODE: = FALSE; us_SIGNAL := USINT#11; (for selection of TRIGGER1) u_DIVIDER := UINT#9; (For division ratio of 1:10)
- 2. Step: internal TA signal -> TRIGGER2: Execute block "TIMER_A_INIT" with: x_MODE: = TRUE; us_SIGNAL := USINT#12; (for selection of TRIGGER2); x_EN_SIGNAL_OUT := TRUE;
- Step: Execute block "INTR_SET" with i_EVENT := INT#5.
 => By creating an EVENT BYPASS task with event "5", you can execute a PLC program synchronously with the divided signal.





Figure 44: The TRIGGER1 signal triggers every tenth time the TRIGGER2 signal and the TRIGGER1 signal triggers the EVENT BYPASS task "5"

4.6.6 Sample Configurations

Depending on the option modules that you use and on the synchronization requirements, you need different configurations for process data communication between the b maXX controller and the PLC, for managing interrupt sources and for providing and processing trigger and sync signals.

The following examples can be used for the majority of applications:

Example A:

Implementing process data communication between the b maXX controller and the PLC.

The controller functionality "MasterCS_Actual1" (controller's actual value channel) carries out synchronization.

A SYNC1 signal should be formed on the PLC from the same source; this signal then triggers the BM4-O-IEI-01 option module.



NOTE

An option module can be synchronized to event "MasterCS_Actual1" (actual channel of the controller) via the PLC by relocating this event to a BACI signal (e.g. SYNC1)!

Example B:

Implementing high-precision BACI process data communication by generating the SYNC1 signal and triggering a BM4-O-IEI-01 option module at the same time and triggering the b maXX controller via the SYNC1 signal.

Example C:

Implementing BACI process data communication within a CANsync event task and triggering a BM4-O-IEI-01 option module as well as the b maXX controller via synchronizing signal SYNC1.

Example D:

Setting up a timer event task for a cyclical call in which the system is to process serial RS485 communication (via the 9-pin female Sub-D connector on the b maXX drive PLC BM4-O-PLC-01 interface X1). The function blocks for cyclical communication are placed in a POE that is assigned to this task.



NOTE

Code runtime measurement is recommended for optimizing the run times of process data. (For more details on this topic, see ▷ Code runtimes ◄ from page 108 onward)

You can carry out this measurement using FBs TIME_MEASURE_START and TIME_MEASURE_END from library SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher.



4.6.7 Example A: Implementing BACI process data communication within a BACI event task



Cold boot/warm restart task:



The block is called once during the initialization stage (cold boot/warm restart task).

Interconnection:

Global variable "_PLC_Init" is already predefined appropriately in the BM4_O_PLC01 template in PROPROG wt in global variable sheet "Global_Variables"; this variable is a placeholder for the b maXX drive PLC's own DPRAM range (this is used for controller communication).

u_CYCLE_TIME = UINT#1000 sets a cycle time of 1000 µs.

i_EVENT = 8 initializes event "BACI process data" and interrupt level 14 (high priority).

Effect: For process data communication, parameter numbers 3331-3334 are set up as target and actual values. Every time the controller operates event "MasterCS_Actual1" (= actual value channel of the controller) interrupt event "8" is executed (see the representation to the right of the "BACI_INIT" call).

PROPROG wt II:

FB "BACI_INIT" is stored in library SYSTEM1_PLC01_20bd00 (or higher) and it uses library BM_TYPES_20bd03 or higher and firmware library SYSTEM2_PLC01_20bd00 or higher. Firmware block "INTR_SET" is a component of block "BACI_INIT".

ProProg wt III:

FB "BACI_INIT" is stored in library SYSTEM1_PLC01_30bd00 (or higher) and it uses library BM_TYPES_30bd01 or higher and firmware library SYSTEM2_PLC01_30bd00 or higher. Firmware block "INTR_SET" is a component of block "BACI_INIT".



Figure 46: Global function of TIMER_A_INIT calls: Every time the controller operates event "MasterCS_Actual1" (= actual value channel of the controller), the PLC generates a BACI-SYNC1 signal for triggering the BM4-O-IEI-01 option module.

The blocks are called once during the initialization stage (cold boot/warm restart task).

To the right of the calls, you can see how the signal points on the PLC are switched to achieve signal change-over via the PLC hardware.

Step 1 (call "TIMER_A_INIT_1"):

Interconnection: x_MODE unused (= FALSE) and us_SIGNAL = USINT#2:

Effect: BACI signal "MasterCS_Actual1" is switched undivided onto the PLC-internal TA signal:



Step 2 (call "TIMER_A_INIT_2"):

Interconnection: x_MODE = TRUE, x_EN_SIGNAL_OUT = TRUE and us_SIGNAL = US-INT#13:

Effect: The internal TA signal is interconnected to the BACI-SYNC1 signal and output to the BACI.

FB "TIMER_A_INIT" is stored in library SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher.

 Triggering a BM4-O-IEI-01 option module via a SYNC1 signal: See the technical description of the BM4-O-IEI-01 module.

Process data communication in the BACI process data BYPASS task:



Figure 47: Carrying out process data communication

By means of block "BACI_PD_COMM" in a POE that was assigned event "8 process data Level 14", the system now cyclically transfers every 1000 µs the target and actual values of the set parameters (in our Example A, these are parameters 3331-3334).

FB "BACI_PD_COMM" is stored in library SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher.

4.6.8 Example B: Implementing BACI process data communication via a self-generated SYNC1 signal

Implementing high-precision BACI process data communication by generating the SYNC1 signal and triggering a BM4-O-IEI-01 option module at the same time and triggering the b maXX controller via the SYNC1 signal.

The TIMER_A_INIT block is used to set timer A to 1 ms and to switch it to the BACI-SYNC1 signal; this is so that the controller and the BM4-O-IEI-01 option module (and also the PLC!) can synchronize this signal:

The SYNC1 signal activates event "11 SYNC signal 1 option module Level 14" and carries out process data communication with the b maXX controller in the associated POE. Cold boot/warm restart task:

(* TIMER_A_INIT: function timer

Timer A should have a time period of exactly 1 mSec:

=> u_DIVIDER = (time period / 0,25 μs) - 1 = 3999 *)



Figure 48: Set up timer A to a 1-ms period

The block is called once during the initialization stage (cold boot/warm restart task).

(* TIMER_A_INIT: function OUTPUT TA-Signal -> BACI-Signal "SYNC1" *)



Figure 49: Output to SYNC1-BACI signal:





The block is called once during the initialization stage (cold boot/warm restart task).



The block is called once during the initialization stage (cold boot/warm restart task).



Process data communication in the SYNC signal 1 option module BYPASS task:

Figure 51: Carrying out process data communication

By means of block "BACI_PD_COMM" in a POE that was assigned event "11 SYNC signal 1 option module Level 14", the system now cyclically transfers every 1000 μ s the target and actual values of the set parameters.

The b maXX controller must also be synchronized to the SYNC1 signal source.

For the necessary b maXX controller settings on WinBASS II page "Synchronization":

- Source for sync signal: "Use Sync 1 signal from the BACI" (i_EVENT = INT#11)
- Choose a 1-ms Sync interval (=> the same time period must be connected at Input "u_CYCLE_TIME" in µs).
- Sync offset: -25.0 µs.
- Sync tolerance: 2.0 µs.

To offset the access instants of the controller and the PLC to the BACI, you must set a negative Sync-Offset of -25 μ s in the controller. This ensures that processing of the actual value channel in the controller is always completed and the current actual values from the controller are available to the PLC when it processes the interrupt that the BACI signal triggered.

Triggering a BM4-O-IEI-01 option module via a SYNC1 signal: See the operating instructions of the BM4-O-IEI-01 option module.



4.6.9 Example C: Implementing BACI process data communication via an external SYNC1 signal

Implementing BACI process data communication within a CANsync event task and triggering a BM4-O-IEI-01 option module as well as the b maXX controller via synchronizing signal SYNC1.

Now, you do not generate the SYNC1 signal yourself; rather, the signal comes from a CANsync option module (BM4-O-CAN-05 for CAN-Slave or BM4-O-CAN-06 for CAN-Master). For information on creating the program and initializing the option modules, see the associated operating instructions and application manuals.

Cold boot/warm restart task:

BACI_INIT_1				
_PLC_Init	BASE	_BASE	PLC_Init	
INT#11	i_EVENT	i_ERR		
UINT#1000	u_CYCLE_TIME	x_ERR		
UINT#3331	u_WR_PAR_NR0	х_ОК	x_Baci_Init_OK	
UINT#3332	u_WR_PAR_NR1			
UINT#3333	u_WR_PAR_NR2			
UINT#3334	u_WR_PAR_NR3			
•	u_WR_PAR_NR4			
•	u_WR_PAR_NR5			
•	u_WR_PAR_NR6			
•	u_WR_PAR_NR7			
•	u_WR_PAR_NR8			
•	u_WR_PAR_NR9			
•	u_WR_PAR_NR10			
•	u_WR_PAR_NR11			
•	u_WR_PAR_NR12			
•	u_WR_PAR_NR13			
•	u_WR_PAR_NR14			
•	u_WR_PAR_NR15			
UINT#3331	u_RD_PAR_NRO			
UINT#3332	u_RD_PAR_NR1			
UINT#3333	u RD PAR NR2			

Figure 52: Set up process data communication to the controller via the SYNC1 event. u_CYCLE_TIME = UINT#1000 sets a cycle time of 1000 µs. i_EVENT = 11 initializes event "SYNC-Signal 1 option module level 14 (high priority)".



The block is called once during the initialization stage (cold boot/warm restart task). Process data communication in the SYNC signal 1 option module BYPASS task:

Figure 53: Carrying out process data communication

By means of block "BACI_PD_COMM" in a POE that was assigned event "11 SYNC signal 1 option module Level 14", the system now cyclically transfers every 1000 μ s the target and actual values of the set parameters.

The b maXX controller must also be synchronized to the SYNC1 signal source.

For the necessary b maXX controller settings on WinBASS II page "Synchronization":

- Source for sync signal:
 - "Use Sync 1 signal from the BACI" (i_EVENT = INT#11)
- Choose a 1-ms Sync interval (=> the same time period must be connected at Input "u_CYCLE_TIME" in µs).
- Sync offset: -25.0 µs.
- Sync tolerance: 2.0 µs.

To offset the access instants of the controller and the PLC to the BACI, you must set a negative Sync-Offset of -25 μ s in the controller. This ensures that processing of the actual value channel in the controller is always completed and the current actual values from the controller are available to the PLC when it processes the interrupt that the BACI signal triggered.



Triggering a BM4-O-IEI-01 option module via a SYNC1 signal: See the operating instructions of the BM4-O-IEI-01 option module.

4.6.10 Example D: Implementing simple serial RS485 communication via a CPU timer

Setting up a timer event task for a cyclical call in which the system is to process serial RS485 communication (via the 9-pin female Sub-D connector on the b maXX drive PLC BM4-O-PLC-01 interface X1). The function blocks for cyclical communication are placed in a POE that is assigned to this task. (For details on connection assignments and cables of the X1 interface, see the b maXX drive PLC BM4-O-PLC-01 Operating Instructions). Cold boot/warm restart task:

UINT#0—terminal_init[0]	(* protocol type: interface to ASCII-protocol *)
UINT#0—terminal_init[1]	(* protocol mode: RS485-Pull-Up-resistor on (activ) RS485-terminator-resistors off (inactiv) *)
UINT#0—terminal_init[2]	(* bidirectional communication activated *)
UINT#10—terminal_init[3]	(* baudrate: 38400 Bd *)
UINT#2—terminal_init[4]	(* parity: even *)
UINT#2—terminal_init[5]	(* 8 databits *)
UINT#1—terminal_init[6]	(* 1 Stopbit *)



Figure 54: Initializing the serial port

The "TER_INIT" block is called once during the initialization stage (cold boot/warm restart task). (For detailed information on "TER_INIT" and the serial port parameters, see ▷De-scription of the blocks for serial RS485 communication via the X1 interface (9-pin female Sub-D connector) on the b maXX drive PLC < from page 86 onward or the online description in SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher).

4





The block is called once during the initialization stage (cold boot/warm restart task). Serial communication in the CPU timer 2 BYPASS task:



Figure 56: Calling the send and receive blocks in the bypass interrupt (every 10 ms)



Brief description

(For detailed information on firmware blocks, see ▷Description of the blocks for serial RS485 communication via the X1 interface (9-pin female Sub-D connector) on the b maXX drive PLC < from page 86 onward or the online descriptions in SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher):

Reception block "TER_R":

The receive job is activated via a rising edge at x_RECEIVE_INIT. Until all the characters have been received (number at "ud_RECEIVE_SIZE"), x_BUSY stays TRUE and the system displays at output "ud_CNT" the characters that have been received and stored in array "a_BYTE1_256_rec".

Send block "TER_S":

The send job is activated via a rising edge at x_SEND_INIT: All the "ud_SEND_SIZE" characters in send buffer array "a_BYTE1_256_send" are sent. As soon as the send job has been completely executed, the system resets x_BUSY and sets x_OK.

4.6.11 Description of the blocks for serial RS485 communication via the X1 interface (9-pin female Sub-D connector) on the b maXX drive PLC

For details on connection assignments and cables of the X1 interface, see the b maXX drive PLC Operating Instructions.



CAUTION

The following **may occur**, if you do not observe this caution information:

property damage.

Danger from: **short circuit** in the PLC or damage to the node connected to pin 2 of the X1 interface.

The +5 V at Pin 2 of interface X1 on the BM4-O-PLC-01 Sub-D socket is intended only to supply external Baumüller-specific RS485/RS232 converters; you must not short-circuit or ring connect it with others.

NOTE

RS485 interface

RS485 interface X1 is galvanically separated and optically decoupled.

The RS485 is an enhancement of the RS422 for multi-sender operation (this means communication is carried out optionally using several transmitters per transfer path: in this connection, only one sender per transfer path may be active at the same time.

Normally, the differential individual wires are twisted together, which means that parasitic electromagnetic disturbances have an equal effect on both individual wires. Due to difference evaluation at the reception block, these disturbances can be suppressed (common-mode rejection). This means that twisting the wires increases the transmission performance.

Recommendation: In addition to the two-/four-wire cable, you can also use the ground wire; in this connection, both driver blocks (the send driver on one side of the connection and the receive driver on the other side) have the same absolute reference potential. This avoids exceeding of the common-mode input voltage range.

The ground wire must not be connected to the shielding at any point along the entire transmission path.

• Configuration options with the b maXX drive PLC via the software: Using the pull-up/ pull-down and terminating resistors that are integrated on the PLC:

When using differential interfaces whose send drivers can be deactivated, it is often necessary to add pull-up/pull-down and/or terminating resistors to the connecting cables.

Using pull-up/pull-down resistors is intended to ensure that a defined potential is always connected to a differential reception unit even if no characters are currently being transferred and the if the associated send unit of the opposite communication partner is switching its drivers on a high-resistance basis (protocol-dependent).

If these types of resistors are not present, the line may float which results in sporadic transmission errors occurring like break errors, framing errors, parity errors, etc.

When using relatively long lines and high transfer rates, you can no longer neglect cable resistors. This means that you must connect teminating resistors to the differential cables at both ends of the bus on the transfer path. If you do not connect terminating resistors, reflections can occur that lead to reception errors. This means that using bus terminators improves the transmission performance.

In the case of network-like structures containing several nodes on one cable, this means that you must ensure that there are neither several pull-up/pull-down resistors in parallel on one cable nor too many terminating resistors (at the most the two at both ends of the bus).

To avoid the time and effort involved in directly integrating pull-up/pull-down and terminating resistors in the male connector or the cable, pull-up/pull-down and terminating resistors are present in the b maXX drive PLC and you can connect and disconnect them separately from one another using the applications software.

For an exact description of this procedure, refer to the description of FB "TER_INIT" in PROPROG wt firmware library SYSTEM2_PLC01_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher (see ▷Function block TER_INIT ◄ from page 88 onward) or their online description.



• Configuration option with the b maXX drive PLC: Two-wire/four-wire cables

Difference between two-wire and four-wire cables:

You can transmit characters on a full-duplex basis across a four-wire cable (it is recommended to use a ground wire too). Full-duplex means that characters can always be transmitted and received across separate channels in both directions at the same time. The 3964R[®] protocol is an example of a full-duplex protocol of this type.

By contrast, there are half-duplex protocols that can handle send and receive jobs via a common two-wire cable (it is recommended to use a ground wire too). In the case of a two-wire cable, the TxD+ wire is short circuited with the RxD+ wire at both ends of the connecting cable; this also applies to the TxD wire with the RxD wire. By contrast with a four-wire cable, this means that you need to lay two less wires, which results in a savings of material.

However, the missing individual wires must be "compensated" by an exact protocol sequence:

The protocol must ensure that characters are never transmitted in both directions at the same time and that only one send unit is ever active at any one time with the other partner send unit being switched off (high-resistance).

In the b maXX drive PLC, the following configuration options are available for this:

You can choose between two-wire and four-wire mode.

The difference is that in two-wire mode the system shuts down the send unit after all the characters have been transmitted. In this connection, you should note that shutting down makes the connecting cable high-resistance unless you programmed pull-up/pull-down resistors.

For an exact description of setting options, refer to the description of FB "TER_INIT" in PROPROG wt II standard library SYSTEM2_PLC01_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher or their online description.

4.6.12 Function block TER_INIT

Firmware FB TER_INIT initializes the terminal interface (serial port) of the b maXX option module with the necessary interface parameters, e.g. baud rate, parity, etc.

The FB TER_INIT is contained in the firmware library SYSTEM2_PLC_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher.

Parameter input	Data type	Description
a_INIT_DATA	UINT_256_BMARRAY	Initialization array for the terminal interface

Parameter output	Data type	Description
a_INIT_DATA	UINT_256_BMARRAY	Initialization array for the terminal interface
x_ERR	BOOL	Error bit
i_ERR	INT	Error word 0, 1, 2, 3, 4



NOTE

All the inputs must be assigned; otherwise, the system does not transfer a defined value!

Type definition:

UINT_256_BMARRAY : ARRAY [0..255] OF UINT

Description:

Before communication can take place via the terminal interface (serial port) of the b maXX drive PLC option module, it must have been parameterized. You do this via connection a_INIT_DATA. The variable that is connected there contains the necessary interface parameters like the baud rate, parity, etc. Actual communication is carried out via the corresponding communications FBs (see below).

Since the terminal interface is initialized only once, TER_INIT must be called using the cold boot and warm restart tasks.

Input a_INIT_DATA:

A variable of type UINT_256_BMARRAY is connected at input a_INIT_DATA. The individual entries of a_INIT_DATA have the following meanings:

a_INIT_DATA[Index]	Meaning
a_INIT_DATA[0]	Protocol 0: Any ASCII protocol 1: Interfacing to procedure 3964R [®] to data blocks
a_INIT_DATA[1]	 Protocol's operating mode Only RS485 pull-up resistors are active (on) Only the RS485 terminating resistor is active (on) The RS485 pull-up resistors and the RS485 terminating resistor are active (on) The RS485 pull-up resistors and the RS485 terminating resistor are not active (off)
a_INIT_DATA[2]	RS485 operating mode 0: Four-wire RS485 operation 1: Two-wire RS485 operation ¹⁾



a_INIT_DATA[Index]	Meaning
a_INIT_DATA[3]	Baud rate 0: 50 bps ¹⁾ 1: 110 bps ¹⁾ 2: 150 bps ¹⁾ 3: 300 bps ¹⁾ 4: 600 bps ¹⁾ 5: 1200 bps ¹⁾ 6: 2400 bps ¹⁾ 7: 4800 bps 8: 9600 bps 9: 19200 bps 10: 38400 bps
a_INIT_DATA[4]	Parity 0: No parity bit 1: Odd 2: Even
a_INIT_DATA[5]	Character length 0: Reserved 1: 7 bits per character 2: 8 bits per character
a_INIT_DATA[6]	Stop bit 0: 1 stop bit 1: 1 stop bit 2: 1 stop bit 3: 2 stop bits
a_INIT_DATA[7]	Reserved
a_INIT_DATA[8]	Max. number of communications attempts per message frame 2)
a_INIT_DATA[9]	Priority ²⁾ 0: Low priority 1: High priority
a_INIT_DATA[10]	Character delay time (ZVZ) in ms ²⁾
a_INIT_DATA[11]	Acknowledgment delay (QVZ) in ms ²⁾
a_INIT_DATA[12]	Block delay (BVZ) in ms ²⁾
a_INIT_DATA[13]	Reserved
a_INIT_DATA[255]	Reserved

Not for interfacing to procedure 3964R[®] to data blocks
 Only for interfacing to procedure 3964R[®] to data blocks

Procedure 3964R[®] is a registered trademark of Siemens AG.

a) ASCII protocol

Communication using protocol "Any ASCII protocol" is carried out via FBs TER_S und TER_R. Users can send n characters with this protocol to a communications partner and receive n characters from a communications partner.

The FBs TER_S and TER_R are contained in the firmware library SYSTEM2_PLC_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher.

Typical initialization values for the ASCII protocol are:

a_INIT_DATA[Index]	Meaning
a_INIT_DATA[0]	Protocol 0: Any ASCII protocol
a_INIT_DATA[1]	Protocol's operating mode 0: Only RS485 pull-up resistors are active (on) 1: Only the RS485 terminating resistor is active (on) 2: The RS485 pull-up resistors and the RS485 terminating resistor are active (on) 3: The RS485 pull-up resistors and the RS485 terminating resistor are not active (off)
a_INIT_DATA[2]	RS485 operating mode 0: Four-wire RS485 operation 1: Two-wire RS485 operation
a_INIT_DATA[3]	Baud rate 0: 50 bps 1: 110 bps 2: 150 bps 3: 300 bps 4: 600 bps 5: 1200 bps 6: 2400 bps 7: 4800 bps 8: 9600 bps 9: 19200 bps 10: 38400 bps
a_INIT_DATA[4]	Parity 0: No parity bit 1: Odd 2: Even
a_INIT_DATA[5]	Character length 1: 7 bits per character 2: 8 bits per character
a_INIT_DATA[6]	Stop bit 0: 1 stop bit 1: 1 stop bit 2: 1 stop bit 3: 2 stop bits
a_INIT_DATA[7]	Reserved 0



a_INIT_DATA[Index]	Meaning
a_INIT_DATA[255]	Reserved 0

b) Interfacing to procedure 3964R[®]

Interfacing to procedure 3964R[®] to data blocks is carried out via firmware FBs T64_RSYN und T64_REC (are contained in the firmware library SYSTEM2_PLC_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher.

Typical initialization values for interfacing to procedure 3964R® to data blocks are:

a_INIT_DATA[Index]	Meaning
a_INIT_DATA[0]	Protocol 1: Interfacing to procedure 3964R® to data blocks
a_INIT_DATA[1]	Protocol's operating mode 0: Only RS485 pull-up resistors are active (on)
a_INIT_DATA[2]	RS485 operating mode 0: Four-wire RS485 operation
a_INIT_DATA[3]	Baud rate (Baud = bps) 7: 4800 bps 8: 9600 bps 9: 19200 bps
a_INIT_DATA[4]	Parity 2: Even
a_INIT_DATA[5]	Character length 2: 8 bits per character
a_INIT_DATA[6]	Stop bit 1: 1 stop bit
a_INIT_DATA[7]	Reserved 0
a_INIT_DATA[8]	Max. number of communications attempts per message frame 2: Max. 2 communications attempts per message frame
a_INIT_DATA[9]	Priority 0: Low priority
a_INIT_DATA[10]	Character delay time (ZVZ) in ms 100
a_INIT_DATA[11]	Acknowledgment delay (QVZ) in ms 500
a_INIT_DATA[12]	Block delay (BVZ) in ms 2000
a_INIT_DATA[13]	Reserved 0

a_INIT_DATA[Index]	Meaning
a_INIT_DATA[255]	Reserved 0

Error evaluation:

If the system detects faulty parameterization, it sets error bit x_ERR and specifies the error in more detail by means of error number i_ERR:

i_ERR	Error on serial port
0	No error
1 to 3	Reserved
4	The set baud rate is not possible

4.6.13 Function block TER_R

Firmware FB TER_R receives characters via the terminal interface (serial port) of the b maXX drive PLC option module and stores the characters in an array.

The FB TER_R is contained in the firmware library SYSTEM2_PLC_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher.

Parameter input	Data type	Description
a_INIT_DATA	UINT_256_BMARRAY	Initialization array for the terminal interface
a_RECEIVE_BUFFER	ANY ¹⁾	Array to which characters are to be loaded
ud_RECEIVE_SIZE	UDINT	number of bytes that are to be received
x_RECEIVE_EN	BOOL	Enable/disable interface receive interrupt
x_RECEIVE_INIT	BOOL	Issue receive job

Parameter output	Data type	Description
a_INIT_DATA	UINT_256_BMARRAY	Initialization array for the terminal interface
a_RECEIVE_BUFFER	ANY ¹⁾	Array to which characters are to be loaded
x_BUSY	BOOL	Indicates whether the job is active
ud_CNT	UDINT	Number of characters that have already been received
i_RECEIVE_ERR	INT	Display of a serial receive error
x_OK	BOOL	Indicates a correctly activated job



Parameter output	Data type	Description
x_ERR	BOOL	Error bit
i_ERR	INT	Error number

¹⁾ You must connect a 256-byte array. Suitable data types are BYTE_256_BMARRAY (: ARRAY [0..255] OF BYTE) or DINT_64_BMARRAY (: ARRAY [0..63] OF DINT) from library BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) and higher.



NOTE

All the inputs must be assigned; otherwise, the system does not transfer a defined value!

Type definition:

UINT 256 BMARRAY : ARRAY [0..255] OF UINT

Description:

Firmware FB TER_R must be called cyclically in the user program.

For communication with firmware FBs TER_S and TER_R, you must set the hardwarespecific interface parameters at firmware FB TER_INIT (see the description of firmware FB TER_INIT).

Using protocol "Any ASCII protocol", users can use firmware FB TER_S to send n characters to a communications partner. Using firmware FB TER_R, users can receive n characters from a communications partner.

Input/output **a_INIT_DATA**:

The parameterized initialization array for the terminal interface is connected to a_INIT_DATA (see the description of firmware FB TER_INIT). This means that the same global variable must be connected to a_INIT_DATA as to firmware FB TER_INIT.

Input/output a_INIT_BUFFER:

A (256-byte) array is connected to a_RECEIVE_BUFFER (see above). The system fetches the received data/characters (that were entered in the system-internal terminal interface receive buffer) and stores them in this array.

Input ud_RECEIVE_SIZE:

At input ud_SEND_SIZE, the system outputs the number of characters that are stored from the system-internal receive buffer of the terminal interface to the array at input/output a_RECEIVE_BUFFER.

Input x_RECEIVE_EN:

At activation of a job (rising edge at $x_RECEIVE_INIT$), the system can either enable the terminal interface receive interrupt ($x_RECEIVE_EN = TRUE$) or disable it

(x_RECEIVE_EN = FALSE). If x_RECEIVE_EN = FALSE, the system deletes all the previously received characters in the system-internal terminal interface receive buffer (regardless of the status of input x_RECEIVE_INIT). If the interrupt is disabled, no more characters are received in the system-internal receive buffer.

Input x_RECEIVE_INIT:

A rising edge at input x_RECEIVE_INIT activates a receive job for "ud_RECEIVE_SIZE" characters (from the system-internal terminal interface receive buffer).

Output **x_BUSY**:

Output x_BUSY is TRUE while a job is being carried out. If the system has fetched all the characters from the system-internal terminal interface receive buffer and written them to the array at input/output a_RECEIVE_BUFFER, the job is successful and x_BUSY changes to FALSE.

Output ud_CNT:

At output ud_CNT, the system displays the number of characters that have been received up to this point in time (from the terminal interface receive buffer).

Output x_OK:

Output x_OK displays x_OK = TRUE for one cycle to indicate whether a new job (rising edge at input x_RECEIVE_INIT) has been accepted. The system accepts a job even if a receive job is currently active (x_BUSY = TRUE).

This means that the system immediately cancels the ongoing job and activates the new one.

Error evaluation:

Output i_RECEIVE_ERR displays receive errors.

i_RECEIVE_ERR	Error on serial port
0	No error
1	BREAK error
2	FRAME error
3	PARITY error
4	OVERRUN error
5	Internal receive error RxRDY



Outputs **x_ERR, i_ERR**:

If the system detects faulty parameterization, it sets output x_ERR = TRUE and specifies the error in more detail by means of the error number (output i_ERR):

i_ERR	Error on serial port
0	No error
1 to 2	Reserved
3	Terminal interface was not initialized. Check calling of TER_INIT in the cold boot and warm restart task as well as all the a_INIT_DATA connections.

4.6.14 Function block TER_S

Firmware FB TER_S sends characters from an array across the terminal interface (serial port) of the b maXX drive PLC option module to a communications partner.

The FB TER_S is contained in the firmware library SYSTEM2_PLC_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher.

Parameter input	Data type	Description
a_INIT_DATA	UINT_256_BMARRAY	Initialization array for the terminal interface
a_SEND_BUFFER	ANY ¹⁾	Array from which characters are to be sent
ud_SEND_SIZE	UDINT	number of bytes that are to be sent
x_SEND_EN	BOOL	Enable/disable interface send interrupt
x_SEND_INIT	BOOL	Issue send job

Parameter output	Data type	Description
a_INIT_DATA	UINT_256_BMARRAY	Initialization array for the terminal interface
a_SEND_BUFFER	ANY ¹⁾	Array from which characters are to be sent
x_BUSY	BOOL	Indicates whether the job is active
ud_CNT	UDINT	Number of characters that have already been sent
i_SEND_ERR	INT	Display of serial send error (not currently used, i.e. always 0)
x_OK	BOOL	Indicates a correctly activated job
x_ERR	BOOL	Error bit
i_ERR	INT	Error number

¹⁾ You must connect a 256-byte array. Suitable data types are BYTE_256_BMARRAY (: ARRAY [0..255] OF BYTE) or DINT_64_BMARRAY (: ARRAY [0..63] OF DINT) from library BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) and higher.



NOTE

All the inputs must be assigned; otherwise, the system does not transfer a defined value!

Type definition:

UINT_256_BMARRAY : ARRAY [0..255] OF UINT

Description:

Firmware FB TER_S must be called cyclically in the user program.

For communication with firmware FBs TER_S and TER_R, you must set the hardwarespecific interface parameters at firmware FB TER_INIT (see the description of firmware FB TER_INIT).

Using protocol "Any ASCII protocol", users can use firmware FB TER_S to send n characters to a communications partner. Using firmware FB TER_R, users can receive n characters from a communications partner.

Input/output a_INIT_DATA:

The parameterized initialization array for the terminal interface is connected to a_INIT_DATA (see the description of firmware FB TER_INIT). This means that the same global variable must be connected to a_INIT_DATA as to firmware FB TER_INIT.

Input/output a_SEND_BUFFER:

A (256-byte) array is connected to a_SEND_BUFFER (see above). In this array, users store the data/characters that are to be sent.

Input ud_SEND_SIZE:

You state the number of characters to be sent at ud_SEND_SIZE.

Input x_SEND_EN:

At activation of a job (rising edge at x_SEND_INIT), the system can either enable the interface send interrupt (x_SEND_EN = TRUE) or disable it (x_SEND_EN = FALSE). If the interrupt is disabled, the system no longer processes a send job that is just running or a new one that has just been triggered. If RS485 operating mode is set to "two-wire" (see TER_INIT), the RS485 send interface is additionally physically disabled (= high-resistance status of the send output for multipoint connections).

Input x_SEND_INIT:

A rising edge at input x_SEND_INIT activates a new job for sending "ud_SEND_SIZE" characters. The RS485 send interface is physically enabled.



Output **x_BUSY**:

Output x_BUSY is TRUE while a job is being carried out. If the system has sent all the characters from array a_SEND_BUFFER, the job has been successfully completed and x_BUSY changes to FALSE.

Output ud_CNT:

At output ud_CNT, the system displays the number of characters that have been set up to this point in time.

Output i_SEND_ERR:

This output indicates with i_SEND_ERR = INT#0 that no send error occurred. Other values of i_SEND_ERR are reserved.

Output x_OK:

Output x_OK displays x_OK = TRUE for one cycle to indicate whether a new job (rising edge at input x_SEND_INIT) has been accepted. The system cannot accept a job until the send procedure that was previously ongoing has been completed (x_BUSY = FALSE) or the user has actively canceled it (x_SEND_EN = FALSE). While output x_BUSY = TRUE, the system ignores send jobs (x_OK stays FALSE).

Error evaluation:

If the system detects faulty parameterization, it sets output x_ERR = TRUE and specifies the error in more detail by means of the error number at output i_ERR:

i_ERR	Error on serial port
0	No error
1 to 2	Reserved
3	Terminal interface was not initialized. Check calling of TER_INIT in the cold boot and warm restart task as well as all the a_INIT_DATA connections.

4.6.15 Function block T64_RSYN

Firmware FB T64_RSYN mimics a data block of interfacing to procedure 3964R[®] to an array. Actual communication is via firmware FB T64_REC.

Procedure 3964R[®] is a registered trademark of Siemens AG.

The FB T64_RSYN is contained in the firmware library SYSTEM2_PLC_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher.

Parameter input	Data type	Description
a_DB_BMARRAY	ANY ¹⁾	Array that is to be enabled for communication with the interfacing to procedure 3964R [®] to data blocks.
i_DB_NR	INT	Number of the data block that is to be used to trig- ger the array of the communications partner.

Parameter output	Data type	Description
a_DB_BMARRAY	ANY ¹⁾	Array that is to be enabled for communication with the interfacing to procedure 3964R® to data blocks.
i_ERR	INT	Error number

¹⁾ You must connect a 256-byte array. Suitable data types are SINT_256_BMARRAY (: ARRAY [0..255] OF SINT) or DINT_64_BMARRAY (: ARRAY [0..63] OF DINT) from library BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) and higher.



NOTE

All the inputs must be assigned; otherwise, the system does not transfer a defined value!

Description:

For interfacing to procedure 3964R[®] via data blocks, you must make the assignments once in the cold boot and warm restart tasks of the different data block numbers to the different arrays.

Up to 20 assignments are possible, i.e. you can call firmware FB T64_RSYN a maximum of 20 times. At each call, the system enters the connected number and the associated array in a table that is managed on a system-internal basis. This means that in the cyclical program section the system only needs to call firmware FB T64_REC that then handles actual communication using this internal table.

Input/output a_DB_BMARRAY:

At a_DB_BMARRAY, you connect a 256-byte variable of data type ARRAY (see above).

Input i_DB_NR:

Using i_DB_NR, you assign the connected array with a corresponding data block number.



Error evaluation:

i_ERR	Error description
0	No error
1	You made too many assignments (a maximum of 20 are possible).
2	Missing entry of a_DB_BMARRAY.
3	No array type connected to a_DB_BMARRAY.

4.6.16 Function block T64_REC

Using firmware FB T64_REC, it is possible to exchange data between the terminal interface (serial port) on the b maXX PLC option module and another node. The FB T64_REC is contained in the firmware library SYSTEM2_PLC_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher.

Interfacing to procedure $3964R^{\textcircled{R}}$ is used as the transfer protocol and is simplified to the extent that data can only be transferred via data blocks and no successor message frames are supported.

Procedure 3964R[®] is a registered trademark of Siemens AG.

In this connection the terminal interface on b maXX drive PLC option module is always a slave interfacing to procedure $3964R^{\mbox{\ensuremath{\mathbb{R}}}}$ to data blocks.

For interfacing to procedure 3964R[®] to data blocks, you must have made the appropriate assignments between the data block numbers used by communication and the individual array memory areas before using T64_REC (see firmware FB T64_RSYN).

Parameter input	Data type	Description
x_STRT	BOOL	Enable for exactly one communication cycle with a rising edge
x_AUTO	BOOL	If TRUE, all subsequent communication cycles are carried out automatically

Parameter output	Data type	Description
i_STAT	INT	Status message (-1, 0, 1, 2, 3, 4)
i_ERR	INT	Error number

NOTE

All the inputs must be assigned; otherwise, the system does not transfer a defined value!



Description:

Communication is carried out between two nodes (point-to-point connection). In this context, the connected partner is always the master that establishes communication. b maXX drive PLC option module interfacing to procedure $3964R^{\mbox{\ensuremath{\mathbb{R}}}}$ to data blocks represents the responding slave.

Transferring data using RS485 interfaces on the b maXX drive PLC option module is conditional on a four-wire cable (plus ground reference) being used, since the data must be transferred on a bidirectional basis. Apart from this, you must ensure that the differential lines are terminated with appropriate pull-up resistors (see firmware FB TER_INIT).

Firmware FB T64_REC should be called at regular intervals (10 ms or more as a rule of thumb). This means that it is sensible to implement the call in a cyclical task or to handle it in a timer event task if the program runtime of the cyclical task is too long.

To initialize the terminal interface, you use firmware FBs TER_INIT and T64_RSYN in the cold boot and warm restart task (see firmware FBs TER_INIT and T64_RSYN).

Input x_STRT:

A rising edge at Input x_STRT of firmware FB T64_REC enables communication on a one off basis. However, the system disables transfer to the partner after the first communication cycle. You can use this function for test purposes to process exactly one communication cycle.

Input **x_AUTO**:

If TRUE is connected here, the partner processes all the subsequent communications jobs. This also applies if an error is issued at output i_STAT (= -1).

Normally, users should set this input permanently to TRUE after firmware FB T64_REC is called for the first time to ensure that the system can process all the communications requests from the partner to the controller.

Output i_STAT:

After starting communication using $x_AUTO = TRUE$ and with a rising edge at Input x_STRT , communication is enabled. As soon as output i_STAT = 2 is displayed, the system can process read and write jobs from the communications partner. The communications partner can then directly access the array contents via the assigned data block numbers (see firmware FB T64_RSYN).

If a job from the communications partner has been received correctly, output i_STAT changes from 2 to 3 and the b maXX drive PLC option module processes the job. The next time firmware FB T64_REC is called, the system sends the answer to the communications partner and output i_STAT changes from 3 to 4. After the send procedure is completed, output i_STAT is automatically set = 2 (i.e. no rising edge is necessary at Input x_STRT). This means that the system can process a new job from the communications partner to the b maXX drive PLC option module. If a receive error occurs during communication, the system displays error status "-1" at output i_STAT.



i_STAT	Internal status of communication of interfacing to procedure $3964R^{\ensuremath{\mathbb{R}}}$ to data blocks
0	Firmware FB T64_REC is not active or initialization has not been carried out
1	RECEIVE function has been triggered
2	From now on, jobs can be received from the communications partner
3	Message frame received, job will be carried out; initiate "Send response"
4	Wait until response has been sent: Then change from status 1 to status 2
-1	Error occurred! Cause of error specified in more detail in i_ERR

Error evaluation:

If a receive error occurs during communication, the system displays error status "-1" at output i_STAT with the exact cause of the error being displayed at output i_ERR. The next time firmware FB T64_RSYN is called, the system switches automatically to receive mode i_STAT = 2.

i_ERR	Error number
0	No error
1	Reserved
2	Terminal interface not initialized (see firmware FB TER_INIT)
3	BREAK error terminal interface
4	FRAME error terminal interface
5	PARITY error terminal interface
6	OVERRUN error terminal interface
7 to 15	Reserved
16	Maximum number of communications attempts reached
17	Wrong END identifier received after block transfer
18	Character delay time (ZVZ) exceeded
19	Block delay time (BVZ) exceeded
20	Wrong character as grouping mark (no STX)
21 to 49	Reserved
50	Received message frame of communications partner too short (< 10 characters)
51	Neither "SEND" nor "FETCH" job implemented or source/target area requested by communications partner not supported
52	Access range not released by user (see firmware FB T64_RSYN)
From 53 onward	Reserved

4.6.17 Function block TER_USS

FB TER_USS is used to implement communication with interfacing to the USS protocol[®]. Connection is via the terminal interface (serial RS485 X1 port) of the b maXX drive PLC.

The b maXX drive PLC is the sole master and it can communicate with all the slaves that can process the USS protocol[®].

		٦
IC	\sim	I
11		I
11	~ I	I
11		I
11	251	I
IL		1

NOTE

Refer to the "Baumotronic Communications Software" description for detailed information about the exact way of functioning, the message frame structure and the meanings of the USS protocol[®] parameters.

$\left \right $		ור
	$\overset{\frown}{\dashv}$	
	Ľ	
		וע

NOTE

FB TER_USS is contained in the standard library SYSTEM1_PLC_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher and uses firmware FB USS_SR from firmware library SYSTEM2_PLC01_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher. This library also contains firmware FB TER_INIT that is needed for initializing the terminal interface. Apart from this, data types from library BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) or higher are used.

The USS protocol® is a registered trademark of Siemens AG.

Parameter input	Data type	Description
a_INIT_DATA	UINT_256_BMARRAY	Array containing the interface parameters
ud_MSEC_DELAY_MAX	UDINT	Maximum delay time for the characters to be received
us_MSG_MIN	USINT	Minimum number of communications attempts
us_MSG_MAX	USINT	Maximum number of communications attempts
us_ADR	USINT 0 to 31	Address of the USS node
x_BROADCAST	BOOL	Broadcast message frame to all nodes
x_MIRROR	BOOL	Mirror message frame
us_SIZE_PIV	USINT 0, 3, 4	Number of PKWs
us_JOB_IDENT	USINT 0 to 4	Job ID
u_PARA_IDENT_WRITE	UINT	Parameter number
ud_PARA_VALUE_WRITE	UDINT	Write parameter value
u_INDEX_WRITE	UINT	Write index number



Parameter input	Data type	Description
us_SIZE_PD	USINT 0 to 3	Number of process data
w_CONTROLWORD	WORD	Control word for process data
ud_PROC_DATA_WRITE	UDINT	Write target value of process data
x_COM_INIT	BOOL	Start bit for message frame (rising edge)
x_COM_CYCL	BOOL	Connection for cyclical data transmission

Parameter output	Data type	Description
a_INIT_DATA	UINT_256_BMARRAY	Array containing the interface parameters
x_BUSY	BOOL	Display bit for ongoing communication
x_VALID	BOOL	Display bit for valid receive data
us_REPLY_IDENT	USINT	Received job ID
u_PARA_IDENT_READ	UINT	Received parameter number
u_INDEX_READ	UINT	Read index number
ud_PARA_VALUE_READ	UDINT	Received parameter value
w_STATUSWORD	WORD	Received status word of process data
ud_PROC_DATA_READ	UDINT	Received actual value of process data
si_SER_ERR	SINT	Error number of serial port
si_MSG_ERR	SINT	Error number of message frame
si_PARA_ERR	SINT	Error number of job
x_ERR	BOOL	Global error bit



NOTE

All the inputs must be assigned; otherwise, the system does not transfer a defined value!

Description:

FB TER_USS should be called cyclically (as a rule of thumb every 10 ms or more). This means that it is sensible to implement calling of FB TER_USS in a cyclical task or to handle it in a timer event task if program runtime of the cyclical task is too long or too irregular due to the other program sections that it contains.

Requirements data about the cPKW range can be transferred between the master (b maXX drive PLC) and its connected USS slaves via the link to the USS protocol[®].

In the USS protocol[®], process data is transferred ("fast target/actual value channel") via the cPZD range.

At a_INIT_DATA you must connect the same (globally declared) array as at firmware FB TER_INIT, since the system accesses this array during communication.

USS communication is started in the case of a rising edge at input x_COM_INIT. If you want new communication cycles to be started automatically, you must set input $x_{COM}CYCL = TRUE$.

Output x_BUSY stays set until master-slave communication to the node has been completed. The system displays that communication has been completed with x_VALID = TRUE. This stays TRUE for one program cycle after a falling x_BUSY edge.

At input ud_MSEC_DELAY_MAX, you connect the maximum timeout in ms by which master-slave communication must have been completed.

If this time is exceeded after communication has been triggered, the system issues a timeout error message. Normally, you should connect a value of approximately 220 ms.

If no error occurs during communication, the system writes with x_VALID = TRUE to the outputs with the received values (w_STATUSWORD, ud_PROC_DATA_READ, us_REPLY_IDENT, u_PARA_IDENT_READ, u_INDEX_READ, ud_PARA_VALUE_READ).

Before parameter output, the system checks the sent and received parameter numbers u_PARA_IDENT_WRITE and u_PARA_IDENT_READ.

In this connection, the system requests the message frame exactly us_MSG_MIN times until parameters are output.

If there is an error (e.g. a timeout), the system tries to set up the message frame us_MSG_MAX times before x_VALID becomes TRUE and an error is displayed. Depending on the error that occurred, the system can evaluate the following outputs:

Parameter and receive error, timeout error:

The system outputs the x_ERR-Bit and the error numbers (si_SER_ERR, si_MSG_ERR, si_PARA_ERR) the other outputs retain their previous instance values!

Job error:

The system rewrites bits x_ERR, si_SER_ERR, si_MSG_ERR status, job error numbers si_PARA_ERR, us_REPLY_IDENT, u_PARA_IDENT_READ; u_INDEX_READ und ud_PARA_VALUE_READ retain their previous instance values!

The process data (w_STATUSWORD and ud_PROC_DATA_READ) is output each time a message frame is set up successfully, even if another parameter job error occurred. This means that process data output is independent of us_MSG_MIN!

Inputs us_MSG_MIN and us_MSG_MAX specify the minimum number of times (us_MSG_MIN) and the maximum number of times (us_MSG_MAX, e.g. in the case of a timeout message) communication is allowed to take place before there is a response at the output due to the data returned by the slave or to an error message.

Normally, users should use the following initialization values:

us_MSG_MIN = 1; us_MSG_MAX = 2;

Organization of the contents in the message frame structure of the USS protocol[®] is specified by the PKW and PZD quantity. The settings must be identical for all the nodes



in the USS ring so that the system can correctly interpret the contents of the exchanged message frame.

us_SIZE_PIV	PKW quantity: Subdivision of requirements data in the USS protocol
4	Doubleword parameter (32-bit types)
3	Word parameter (16-bit types)
0	Message frame contains no requirements data!

us_SIZE_PD	PZD quantity: Subdivision of process data in the USS protocol
3	Control/status word and doubleword target/actual values (32-bit types)
2	Control/status word and word target/actual values (16-bit types)
1	Control/status word only
0	Message frame contains no process data!

us_JOB_IDENT	Job ID (Master -> Slave)
0	No job
1	Read parameter value (answer in ud_PARA_VALUE_READ)
2	Write parameter value ud_PARA_VALUE_WRITE of type word (16-bit)
3	Write parameter value ud_PARA_VALUE_WRITE of type doubleword (32-bit)
4	Read an element from the parameter description (which on is in u_INDEX_WRITE)
5 to	(Reserved)

us_REPLY_IDENT	Answer ID (Slave -> Master)
0	No job
1	Parameter wort (16-bit) was written (us_JOB_IDENT = 2) or read (us_JOB_IDENT = 1) (ud_PARA_VALUE_READ contains the transferred value)
2	Parameter doubleword (32-bit) was written (us_JOB_IDENT = 3) or read (us_JOB_IDENT = 1) (ud_PARA_VALUE_READ contains the transferred value)
3	Element from parameter description was read (answer is in ud_PARA_VALUE_READ)
4 to 6	(Reserved)
7	Parameter error: Job not executable! (For error identification, see si_PARA_ERR)
8 to	(Reserved)

4

Error evaluation:

si_SER_ERR	Error on serial port
0	No error
1	(Reserved)
2	Wrong serial initialization array a_INIT_DATA connected
3	Interface not initialized
4 to 9	(Reserved)
10	Break on receiving
11	Frame error on receiving
12	Parity error on receiving
13.	Overrun error on receiving

si_MSG_ERR	Message frame error on sending/receiving
0	No error
1	The us_SIZE_PIV range that is connected to the FB is not supported
2	The us_SIZE_PD range that is connected to the FB is not supported
3	us_MSG_MIN > us_MSG_MAX or us_MSG_MIN or us_MSG_MAX = 0
4	Invalid address connected to us_ADR (only 031 are permitted)
5	Sent and received addresses are different
6	Sent and received parameter numbers u_PARA_IDENT_WRITE / u_PARA_IDENT_READ are different!
7	us_SIZE_PIV range wrong
8	us_SIZE_PD range wrong
9	STX character not received!
10	Received and expected length indication (us_SIZE_PIV/us_SIZE_PD) are different!
11	BCC checksum error
12	Timeout error on receiving

si_PARA_ERR	Parameter error
0	No error
-1	Parameter number is not supported (impermissible u_PARA_IDENT_WRITE)
1	Parameter cannot be changed
2	MIN/MAX limitation
3	Faulty index u_INDEX_WRITE



si_PARA_ERR	Parameter error
4	No array type
5	Wrong data type
6	Setting not allowed
7	Description element cannot be changed
8 to 100	(Reserved)
101	Undetermined error
102	Service not implemented
103	Parameter format too large for PKW range
104	PBE element not present

4.7 Code runtimes




_		
Г		ור
	$\underline{\bigcirc}$	
	1	
	Jι	
t I		

NOTE

All the events must be created as tasks with the "BYPASS" property.

A higher-priority event task interrupts a lower-priority one; this means that you should always use timer event tasks that could run at the same time as synchronous bus systems with the lower level 13 so that they can be interrupted.

In the case of cyclical tasks that are not BYPASS task, users must enter in the task's "Settings" the cyclical sampling time (the "Interval" setting) and a monitoring time (the "Watchdog" setting). The runtime system monitors these cyclical tasks and the default task for the watchdog during operation.

In this connection, you should note that the set watchdog does not take into account the pure runtime of this task; rather, it also includes the total of the maximum individual runtimes that can interrupt this task.

If the monitoring time is set too low, the system issues PLC error "Watchdog in Task 'x' exceeded!" to inform users of the system overload that has occurred and the controller enters the safe "STOP" status at the same time.

The watchdogs in BYPASS task are ignored.

Further factors influencing the watchdogs in the cyclical non-BYPASS tasks and the default task:

You should allow certain time reserves in the monitoring times to allow for other system functions that are running in the background, e.g task call shells and for functions that are called for online representations of variables in the watch list and/or in the global variable worksheets and which increase the system load.

Apart from this, users can activate specific monitoring functions that are active during runtime:

These include the settings in the resource for "Index checking for PLC" and "Stack inspection for PLC". You can possibly reset these settings after commissioning is completed to save runtime resources.

For the BYPASS tasks, you can exactly determine the actual system loading during operation from a worst case point of view using the Time_Measure blocks from library SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher. Using the FBs, you can acquire runtimes of a maximum of 10 ms at very high resolutions.

If you have to measure relatively large time intervals in the lower-priority cyclical tasks, it is possible to form a continuous global counter value in a BYPASS interrupt that runs with a fixed time base. This timer value can then be evaluated directly in the cyclical tasks by subtraction of the timer value. (For information on setting up a cyclical CPU timer as a BYPASS task, see the description of FB "INTR_SET" in firmware library SYSTEM2_PLC01_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher.

It is possible to deactivate a BYPASS event at runtime using FB "INTR_SET" of firmware library SYSTEM2_PLC01_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher using x_EN = FALSE.



Avoiding system overloading:

In the case of watchdog overshoots, you must set the (interval or watchdog) settings upward and/or minimize the runtimes in the BYPASS interrupts. Do this either by dividing the program in the interrupt itself (i.e. alternate program section executions per interrupt) or by relocating to lower-priority non-BYPASS tasks with longer call intervals or by locating program sections directly in the default task.

If you do not want to carry out runtime monitoring in cyclical non-BYPASS task, you can also set up a watchdog that is higher than the interval that is set for this task.

4.7.1 Function block TIME_MEASURE_START

You can use this function block for TIME_MEASURE together with function block TIME_MEASURE_END to determine code runtimes and call times for tasks.

The FB TIME_MEASURE_START is contained in the standard library SYSTEM1_PLC_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher.

Output parameter	Data type	Description
ud_CNT_START	UDINT	Current system timer value in system units

Description

FB TIME_MEASURE_START is used together with FB TIME_MEASURE_END for time measurements on the b maXX drive PLC. The system determines the runtime of the program code between calling of FB TIME_MEASURE_START (start of time measurement) and calling FB TIME_MEASURE_END (end of time measurement).

FB TIME_MEASURE_START reads the current value in system units from a system timer and outputs it at ud_CNT_START. For its part, FB TIME_MEASURE_END reads the current system timer value in system units and generates the difference to the value read by FB TIME_MEASURE_START. This means that at both FBs the same variable must be connected to ud_CNT_START.



NOTE

Correct time measurement is only possible if both FBs are used in an event task with the highest priority. Runtimes up to a maximum of 10 ms can be determined. In the case of program code with runtimes longer than 10 ms, no correct values will be returned.

4.7.2 Function block TIME_MEASURE_END

You can use this function block for TIME_MEASURE together with function block TIME_MEASURE_START to determine code runtimes and call times for tasks.

The FB TIME_MEASURE_END is contained in the standard library SYSTEM1_PLC_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher.

Input parameter	Data type	Description
ud_CNT_START	UDINT	System timer value from FB TIME_MEASURE_START

Output parameter	Data type	Description
ud_CNT_END	UDINT	Current system timer value in system units
di_DIFF_in_counts	DINT	Difference between ud_CNT_END and ud_CNT_START
di_DIFF_in_mysec	DINT	Time difference in ms

Description

FB TIME_MEASURE_START is used together with FB TIME_MEASURE_END for time measurements on the b maXX drive PLC. The system determines the runtime of the program code between calling of FB TIME_MEASURE_START (start of time measurement) and calling FB TIME_MEASURE_END (end of time measurement).

FB TIME_MEASURE_START reads the current value in system units from a system timer and outputs it at ud_CNT_START. For its part, FB TIME_MEASURE_END reads the current system timer value in system units and generates the difference to the value read by FB TIME_MEASURE_START. This means that at both FBs the same variable must be connected to ud_CNT_START.

The system outputs the time difference to di_DIFF_in_mysec; the difference of the system timer values in system units is available in di_DIFF_in_counts. The system timer value that FB TIME_MEASURE_END reads out can be seen at ud_CNT_END.

To determine a task's call time, you place the two FBs at the start of a POE: in this connection, FB TIME_MEASURE_END must be placed before FB TIME_MEASURE_START. You interconnect to variables in the same way as with code runtime measurement. You can read the call time at di_DIFF_in_mysec.



NOTE

Correct time measurement is only possible if both FBs are used in an event task with the highest priority. Runtimes up to a maximum of 10 ms can be determined. In the case of program code with runtimes longer than 10 ms, no correct values will be returned.



4.8 Practical information

4.8.1 PLC error "Watchdog in task 'x' exceeded!"

This PLC error message is generated by the runtime system to inform users of the following system overloading:

In the case of cyclical tasks that are not BYPASS task, users must enter in the task's "Settings" the cyclical sampling time (the "Interval" setting) and a monitoring time (the "Watchdog" setting). The runtime system monitors these tasks during operation. If the runtime system detects a violation of the selected settings, the PLC enters the "Stop" status and issues the "Watchdog in Task 'x' exceeded!" error message.

Possible reasons for a violation:

If users employ BYPASS tasks that are heavily loaded (e.g. a pure interrupt runtime of 1.5 ms with a 2-ms sampling time) and which interrupt each other (e.g. another BYPASS timer task with a 300-ms runtime), this places an additional load on the CPU computing time. In a worst case runtime scenario, this can lead to the PLC errors mentioned above in a low-priority cyclical task (i.e. a non-BYPASS task) that is monitored by the operating system.

What you should count on:

This means that when setting up the monitoring time, you should not just take into account the pure runtime of the task to be set up; rather, you must also consider time reserves for other system functions that are running, e.g. for the task call shells that are running in the background and for online representations of variables in the watch lists and/or in the global variable worksheets. You should also not forget that users can activate specific monitoring functions that are active at runtime (e.g. the settings in the resource for "Index checking for PLC" and "Stack inspection for PLC") and may be reset after commissioning is completed to save resources.

For the BYPASS tasks, you can exactly determine the actual system loading during operation from a worst case point of view using the Time_Measure blocks from library SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or higher. Using the FBs, you can acquire runtimes of a maximum of 10 ms at very high resolutions.

If you have to measure relatively large time intervals in the lower-priority cyclical tasks, it is possible to form a continuous global counter value in a BYPASS interrupt that runs with a fixed time base. This timer value can then be evaluated directly in the cyclical tasks by subtraction of the timer value. (For information on setting up a cyclical CPU timer as a BYPASS task, see the description of FB "INTR_SET" in firmware library SYSTEM2_PLC01_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher).

Avoiding overloading:

In the case of watchdog overshoots, you must set the (interval or watchdog) settings upward and/or minimize the runtimes in the BYPASS interrupts. Do this either by dividing the program in the interrupt itself (i.e. alternate program section executions per interrupt) or by relocating to lower-priority non-BYPASS tasks with longer call intervals or by locating program sections directly in the default task.



4.8 Practical information

INTERNAL COMMUNICATIONS INTERFACE TO THE (BACI) CONTROLLER

5.1 BACI (BAumüller Component Interface) general

The BACI is an internal communications interface for exchanging data between the b maXX controller and the b maXX drive PLC.

When carrying out communication, a differentiation is made between process data communication and requirements data communication.

Process data communication comprises reading and writing time-critical set values and actual values and the status and control word in a definable time raster.

Service data communication comprises reading and writing non-time-critical parameters of the controller.

Several ways are available for exchanging data between the b maXX controller and the b maXX drive PLC.

• ProMaster, ProProg wt III and Motion Control

The configuration of the data exchange in ProMaster is simply and fast. The programming of the machine function in ProProg wt III with the Motion Control function blocks is simply and fast.

Example projects:

ProMaster project: Example_1_3_2.bmxml IEC project in ProProg wt III: Example_BM4_0_ECT02_MA_2.mwt

See ▷ ProMaster, ProProg wt III and Motion Control < from page 116 onward.

• PROPROG wt II

Using the IEC 61131-3 programming system PROPROG wt II to program the data exchange (BACI communication) and the machine function PROPROG wt II.

See ▶ PROPROG wt II < from page 144 onward.



5.2 ProMaster, ProProg wt III and Motion Control

Network variables are created per default for Motion Control at creating a project in Pro-Master.

In an IEC project the Motion Control function blocks read or write these default network variables. The complete machine function in an IEC project can be programmed via the Motion Control function blocks.

Additional network variables can be created during configuration of the data exchange in ProMaster project.

In a ProProg wt III IEC project these additional network variables can be read or written.

The interval in which the (process) data will be exchanged between b maXX drive PLC and b maXX controller will be configured in ProMaster.

If writing or reading of service data is required, the respective Motion Control function blocks are used.

5.2.1 Requirements

The requirements are

- a PC with
 - the ProMaster engineering framework
 - the IEC 61131-3 programming system ProProg wt III with the firmware libraries
 - Bit_UTIL_30bd00
 - OmegaOS_30bd00
 - SYSTEM2_PLC01_30bd00
 - MC_SYS_30bd00

and the libraries

- BM_TYPES_30bd00
- SYSTEM1_PLC01_30bd00
- MOTION_TYPES_30bd02
- MOTION_CONTROL_30bd03
- MOTION_MULTI_AXIS_30bd03 (if multi-axis motion control is used)

• Physical commissioning of the components.

In the following example an EtherCAT network will be created. In our example, the components are the EtherCAT master

- b maXX 4400 with
 - b maXX drive PLC (BM4-O-PLC-01)
 - EtherCAT master option module (BM4-O-ECT-02-...)

and the EtherCAT slave

- b maXX 4400 with
- EtherCAT slave option module (BM4-O-ECT-01-...)

For this purpose, see the respective operating instructions.

5.2.2 Procedure to be carried out

To use the b maXX drive PLC and the b maXX controller for Motion Control, the following steps must be carried out.

- 1 Commissioning of the b maXX 4400 with b maXX controller and b maXX drive PLC
- 2 Creation of an IEC 61131-3 project for ProProg wt III with a motion-control template
- 3 Creation of a machine configuration in ProMaster (a small EtherCAT network will be created in the following example)
- 4 Configuration of EtherCAT communication and subsequent downloading to the Ether-CAT master
 - (with testing of the EtherCAT network with this configuration if appropriate)
- 5 Configuration of the BACI communication (local axis)
- 6 Configuration of the PLC with linking of the IEC project and ProMaster, configuration of the cam data
- **7** Possible programming of the IEC 61131-3 project for ProProg wt III (application) and subsequent downloading to the b maXX drive PLC
- 8 Operation of the application

Naturally, you can also begin with Step 2 and not perform physical commissioning (Step 1) until just prior to Step 6.

The ProMaster project **Example_1_3_2.bmxml** and the IEC 61131-3 project (ProProg wt III project) **Example_BM4_ECT02_MA_2.mwt/.zwt** are created here.

5.2.3 Commissioning of the b maXX 4400 with b maXX controller and b maXX drive PLC

For details on commissioning the b maXX 4400 with b maXX controller and the b maXX drive PLC option module, please refer to the respective operating instructions.

For details on commissioning the EtherCAT network, please refer to the respective operating instructions for the EtherCAT master for b maXX drive PLC option module and the operating instructions of the other EtherCAT network nodes.

5.2.4 Creating of an IEC project with ProProg wt III

The following explains how a motion control IEC project is created.

Multi-axis motion control is set in the ProMaster default settings for motion control. For this reason, it makes sense to first create an IEC project for multi-axis motion control.

Open ProProg wt III and create a new project by selecting an IEC template project via the "File\Open Project / Unpack Project..." menu.

In our example, we use the IEC template project "Tmpl_PLC01_MA_2_0104.zwt" (for BM4_0_PLC01).

This project is found in the directory <ProMaster installation directory>\projects\IEC templates, e.g. in the ProMaster standard installation directory C:\Baumueller\ProMasterNET \projects\IEC-Templates.

The IEC template project "Tmpl_PLC01_MA_2_0104.zwt" is unpacked as "Example_BM4_0_ECT02_MA_2.mwt".

The template contains the libraries



- Bit_UTIL_30bd00
- BM_TYPES_30bd01
- MC_SYS_30bd00
- MOTION_TYPES_30bd02
- MOTION CONTROL 30bd03
- MOTION_MULTI_AXIS_30bd03

Save the project. In our example, we use the project name "Example_BM4_O_ECT02_MA_2.mwt".



Figure 58: ProProg wt III - Creating the project "Example_BM4_O_ECT02_MA_2.mwt"

The communication settings must now be configured. The serial interface COM1 is set by default. If you would like to use Ethernet, see Section ▷Communication and Connection ◀ from page 31 onward.

When using an IEC project in ProMaster, it is absolutely necessary that the "Create boot project when compiling" checkbox in the "Resource Settings" window (select resource, choose context menu "Settings") is activated for ProProg wt III. This creates the "boot-file.pro" file, which is required for the download to the b maXX drive PLC.

NOTE

The "Create boot project when compiling" checkbox under "Resource Settings" must be activated in ProProg wt III.

The project "Example_BM4_O_ECT02_MA_2.mwt" is linked to the ProMaster project later on in Section ▷Configuration of the PLC ◄ from page 130 onward.

Now close ProProg wt III via the menu "File\Exit".

5.2.5 Creation of a machine configuration in ProMaster

This section explains how a project is created in ProMaster and how a machine configuration is created.

Open ProMaster.



Figure 59: ProMaster with no projects

Create a new ProMaster project by opening the "Project Settings" window via the menu "File\New Project".





Figure 60: ProMaster - Project name

Enter the name (in the edit box) and the save location (via path selection) of the project. We use the name "Example_1_3_2.bmxml" for our example project.

Project settings 🛛 🔀		
Projectname:	Example_1_3_2	
Save path:	C:\Baumueller\ProMasterNET\projects	
C:\Baumueller\ProMasterNET\projects\Example_1_3_2.bmxml		
	OK Cancel	

Figure 61: ProMaster - Issuing a project name

Accept the settings from the "Project Settings" window by clicking the "OK" button. Pro-Master now switches to the network view.



Figure 62: ProMaster - Issuing a project name

Now open the Baumüller catalog via the menu "Views\Catalog". The Baumüller catalog contains the devices, bus system and components provided by Baumüller by default.

In our example, we use

- the devices
 - "b maXX 4000 EtherCAT master (2-row)" (from the group "b maXX 4000 drive"); b maXX 4000 with two slots, Ethernet with EtherCAT master option module in slot G, b maXX drive PLC in slot H
 - "b maXX 4000 EtherCAT slave (2-row)" (from the group "b maXX 4000 drive"); b maXX 4000 with two slots, Ethernet with EtherCAT slave option module in slot G
- the bus system
 - "EtherCAT bus" is created automatically

Drag the "b maXX 4000 EtherCAT master (2-row)" device from the Baumüller catalog and drop it in the ProMaster network view. The bus system is connected automatically. Now drag the "b maXX 4000 EtherCAT slave (2-row)" device and drop it on the EtherCAT bus (only possible when the bus changes color).





Figure 63: ProMaster - Machine configuration created

In the picture, you can now see the EtherCAT master (Modul1) and the EtherCAT slave (Modul2). Additional information on the modules can be obtained via the respective tool tip or the "Project Tree" window. The "Catalog" window is now closed to make things clearer.

The names (Modul1 and Modul2) are changed by clicking the respective module and then opening the properties window of the respective module via the context menu and "Properties".



Figure 64: ProMaster - Module properties

In our example, we issue the name _Axis_A to the EtherCAT master and the name _Axis_B to the EtherCAT slave (_Axis_A and _Axis_B are the default axis variable names of the motion control axis in our IEC project). We retain the respective images (*.bmp). The new names now appear in the ProMaster network view and in the project tree.





Figure 65: ProMaster - Machine configuration - Renamed module

The communication settings for the communication from the ProMaster to the b maXX drive PLC can be set by clicking the "_Axis_A" device and selecting "Communication settings" via the context menu. Then save the project via the menu "File\Save project".

Motion control is activated by default in ProMaster for the local axis and the components with EtherCAT (EtherCAT master drive, EtherCAT slave drive). This reduces the settings to be configured to a minimum.

If you would like to use the default settings, you do not need to configure BACI communication with "Motion Control (local axis)" and the EtherCAT communication with ProEtherCAT.

In this case, continue with ▶ Configuration of the PLC ◄ from page 130 onward.

5.2.6 Configuring EtherCAT communication with ProEtherCAT

Motion control is activated by default in ProMaster for the components with EtherCAT (EtherCAT master drive, EtherCAT slave drive). This reduces the settings to be configured to a minimum.

If you would like to use the default settings, you do not need to configure EtherCAT communication with ProEtherCAT.

In this case, continue with ▶ Configuration of the PLC ◄ from page 130 onward.

Changing the EtherCAT communication settings is described in the respective application manuals. In our example see the "Ethernet with EtherCAT master for b maXX drive PLC" application manual.

5.2.7 Configuring BACI communication

Open the "Motion Control (local axis)" window for our b maXX controller (local axis) by clicking the "_Axis_A" device and then selecting "Configuration Data (Components)\Controller[...]\Motion Control (local axis)" via the context menu.

When the machine configuration was created, the local axis (i.e. the BACI communication between b maXX controller and b maXX drive PLC) was set by default so, that the BACI settings are configured for motion control (dragging and dropping of a b maXX with PLC).

The window "Motion Control (local axis) is opened.

5.2.7.1 Ident tab

On the "Ident" tab b maXX controller specific informations (controller table version, controller type and the controller firmware version) are displayed.

If your b maXX controller has another than the set (controller table) version, you can select in the combo box "Version" the respective (controller table) version.



Figure 66: Motion Control (local axis) - "Ident" tab

5.2.7.2 IEC tab

On the "IEC" tab the network variables are displayed which are used for the communication between b maXX drive PLC and b maXX controller. The network variables differ in standard network variables and additional network variables for the BACI communication, if additional parameters are created on the "PD Receive" and "PD Transmit" tab.

The following must be heeded:



The standard network variables for motion control may be read, but not written, by the user.

These are the standard motion control network variables for the setpoint values:

"w_controlword"	for the control word of the axis	
"ud_PosIpSetAngel1"	for the synchronization position setpoint an- gle of the axis	
These are the standard motion control netwo	ork variables for the actual values:	
"w_statusword"	for the status word of the axis	
"ud_Enc1ActAngle1"	for the synchronization position actual angle of the axis	
"i_OperationModeAct"	for the operating mode of the axis	

NOTE

The standard network variables for motion control may be read, but not written, by the user.

The number after the network variable name is an internal number used to differentiate between identically sounding, automatically generated network variable names.

Motion	Motion Control (local axis) X					
Ident [IEC PD Receive	PD Transmit	ismit 🔍 👻 K < K		< >>>>)	
No	Name	Тур	e Add	ress	De	scription
1	w_Controlword	WORD	%MW3.46	6800 BM_	_w_Controlwo	rd [P300]
2	ud_PosIpSetAngle1	DWORD	%MD3.46	6804 BM_	_ud_PosIpSet/	Angle (P370)
3	di_ApplicationParam	11 DWORD	%MD3.46	6808 BM_	_di_Applicatior	nParam1 [P3314]
4	w_Statusword		%MW3.46	6828 BM_	BM_w_Statusword [P301]	
5	i_OperationModeAct		%MW3.46	6832 BM_	_i_OperationM	lodeAct [P304]
6	ud_Enc1ActAngle1	DWORD	%MD3.46	6836 BM_	BM_ud_Enc1ActAngle [P391]	
7	di_SpeedActValue1	DWORD	%MD3.46	6840 BM_	BM_di_SpeedActValue [P353]	
<						>
Name: w_Controlword Apply						
Connect OFFLINE OnlineStatus				OnlineStatus		
😰 ProPLC, Version=1.0.1.10, Baumüller Nürnberg 2006						

Figure 67: Motion Control (local axis) - "IEC" tab

If you created the additional network variables (and their link to the parameters of the b maXX controller) that were suggested when configuring BACI communication in Sections >PD Receive tab < from page 127 onward and >PD Transmit tab < from page 128 onward, you will see the additional network variables.

The additional network variable for the setpoint value is:

"di_ApplicationParam1.." for application parameter 1 of the axis

The additional network variable for the actual value is:

"di_SpeedActValue.."

for the actual speed value of the axis

5.2.7.3 PD Receive tab

Communication from the b maXX drive PLC to the b maXX controller is configured on the "PD Receive" tab.

The default configuration is already set for motion control. You can expand on the configuration. Note that the motion-control configuration has a higher priority than the configuration by the user.

Motion (Motion Control (local axis) X			
Ident I	EC PD Receive	PD Transmit	👻 K 🛠	< >>>> >>
	Groups of parameter	¹¹ Device_type		•
	Parameter:	[P0001] BM_u_Controller	Туре	•
		🛃 🛛 Add parameter		
		All receive processdata		
Number	Name		Туре	
P300 P370	BM_w_Controlw BM_ud_PosIpSe	ord tAngle	motion motion	
Delete parameter Delete all parameters				
Connect OFFLINE OnlineStatus				
😑 ProPLC, Version=1.0.1.10, Baumüller Nürnberg 2006				

Figure 68: Motion Control (local axis) - "PD Receive" tab with default motion control configuration

Linking of a parameter in the b maXX controller with a network variable in the IEC project occurs here.

Procedure:

• Select a parameter group of the b maXX controller.

Example: We select the group "Configuration_Application" in the "Groups of parameter" combo box.

- Select a parameter from this group.
 - Example: We select the parameter 3314 "[3314]BM_di_ApplicationParam1" in the "Parameter" combo box.
- Click the button "Add Parameter". The just prepared linking is checked for conformity to the settings and is entered in the list.



The b maXX controller parameter 3314 (application parameter 1) is now linked to a network variable in the IEC project. In our case the name of the network variable in the IEC project is "di_Application_Param11". To this network variable will be written in the IEC project. The value written to the parameter 3314 (Application parameter 1) is written via the BACI communication in the controller.

Motion Control (local axis) X					
Ident	IEC	PD Receive	PD Transmit	👻 K 🛠	< > >> >i
Groups of parameter: Configuration_Application					-
	Paran	neter:	[P3314] BM_di_Applic	ationParam1	-
	Add parameter				
			All receive processd	lata	
Numb	er I	Name		Туре	
P300	B	M_w_Controlwo	ord	motion	
P370	B	M_ud_PosIpSet	Angle	motion	
P3314	B	M_di_Applicatio	nParam1	user	
X Delete parameter X Delete all parameters					
Connect OFFLINE OnlineStatus					
💌 Prof	🕫 ProPLC, Version=1.0.1.10, Baumüller Nürnberg 2006				

Figure 69: Motion Control (local axis) - "PD Receive" tab with default motion control configuration and additional parameter

NOTE

ProMaster automatically takes the 30-character limit for variable names in the IEC project in ProProg wt III into account.

The variable names from the additional configuration can be changed in Section ►IEC tab < from page 125 onward.

5.2.7.4 PD Transmit tab

Communication from the b maXX controller to the b maXX drive PLC is configured on the "PD Transmit" tab.

The default configuration is already set for motion control. You can expand on the configuration. Note that the motion-control configuration has a higher priority than the configuration by the user.



Figure 70: Motion Control (local axis) - "PD Transmit" tab with default motion control configuration

Linking of a parameter in the b maXX controller with a network variable in the IEC project occurs here.

Procedure:

• Select a parameter group of the b maXX controller.

Example: We select the group "Speed_controller" in the "Groups of parameters" combo box.

• Select a parameter from this group.

Example: We select the parameter 353 $_{\rm m}$ [0353]BM_di_SpeedActValue" in the <code>_____ Parameter</code> combo box.

• Click the button "Add Parameter". The just prepared linking is checked for conformity to the settings and is entered in the list.

The b maXX controller parameter 353 (speed actual value) is now linked to a network variable in the IEC project. In our case the name of the network variable in the IEC project is "di_SpeedActValue1". This network variable will be read in the IEC project. The value will be read from the Controller parameter 353 (speed actual value) via the BACI communication.



Motion Control (local axis) X				
Ident IEC PD Receiv	e PD Transmit 🛛 🗸 🗸	к «< < >>> >		
Groups of parameters: Speed_controller				
Parameter:	[P0353] BM_di_SpeedActValu	ue 🔻		
	Add parameter			
	All transmit processdata			
Number Name		Туре		
P301 BM_w_Status P304 BM_i_Operat P391 BM_ud_Enc1	sword n ionModeAct n ActAngle n	notion notion notion		
P353 BM_di_Speed	iActValue u	iser		
X Delete parameter				
Connect	OFFLINE	OnlineStatus		
😰 ProPLC, Version=1.0.1.10, Baumüller Nürnberg 2006				

Figure 71: Motion Control (local axis) - "PD Transmit" tab with default motion control configuration and additional parameter



Note

ProMaster automatically takes the 30-character limit for variable names in the IEC project in ProProg wt III into account.

The variable names from the additional configuration can be changed in Section ►IEC tab < from page 125 onward.

5.2.8 Configuration of the PLC

Once the configuration of BACI communication, the communication of EtherCAT network and the creation of the IEC project have occurred, the data for the b maXX drive PLC are to be configured.

For this purpose,

- the IEC project is included in the ProMaster project
- the cam data sets are selected

In addition,

cam data can be generated with the cam editor ProCAM

Then click the "Update total IEC project" button in the "ProPLC" window. The data for the machine configuration, both for the EtherCAT network and the b maXX drive PLC, (including local axis) are then generated.

NOTE

The network variables from the configuration of the BACI communication (local axis) are not displayed in ProPLC.

With the "Update total IEC project" button these network variables are written in the global work sheet of the IEC project in ProProg wt III (in the section LocalAxisVariables) too.

5.2.8.1 IEC

This section explains how an IEC project is linked with ProMaster.

Open the "ProPLC" window in the network view for our local axis (and EtherCAT master) in the ProMaster project. Click the "_Axis_A" device and then select "Configuration Data (Components)\PLC (slot H)\PLC - Configuration (ProPLC)" via the context menu and then the "IEC" tab.

RC ProPLC (_	Axis_A - Slot H - Ty	'p BM4-0-PI	.C-01-01-02)	×	
IEC PLC	Cams EtherCAT	Motion Con	trol	-	
Slot	н	~			
Туре:	BM4-O-PLC-01-01-02	2			
IEC project					
			Project:		
			Configuration:		
			Resources:		
			E	New link	
	_				
Connect		OFFLIN		Online Status	
🕜 Upda	Update total IEC project 😰 Open IEC project				
😐 ProPLC, Vi	ersion=1.0.1.10, Baum	nüller Nürnbe	rg 2006		

Figure 72: ProPLC - Connecting with example IEC project



Note

Only ProProg wt III projects can be opened with ProMaster. If you would like to use an existing PROPROG wt II project, you must first open it with ProProg wt III (thus converting it) and can then open and use it in ProMaster.

Note that your PROPROG wt II libraries will also be converted here!

Click the "New link" button and select our example IEC project "Example_BM4_O_ECT02_MA_2.mwt" created in Section ▷Creating of an IEC project with ProProg wt III < from page 117 onward.

The IEC project just selected is displayed on the "IEC" tab.

RC ProPLC	: (_Axis_A - Slot H - Ty	Гур ВМ4-0-PLC-01-01-02) 🛛 🗙		
TEC PL	.C Cams EtherCAT	Motion Control 🗸 🗸		
Slot	н	✓		
Туре:	BM4-O-PLC-01-01-0	02		
IEC projec	ct			
	Example_BM4_ECT02_M4	IA_2.mwt Project:		
	SH03_30	Example_BM4_ECT02_MA_2.mwt		
		Configuration:		
		5H03_30		
		Resources:		
		PLC01		
		Rev link		
Connect OFFLINE Online Status				
🕜 Update total IEC project 📧 Open IEC project				
ProPLC, Version=1.0.1.10, Baumüller Nürnberg 2006				

Figure 73: ProPLC - IEC tab

If you link an existing application (or template) from ProProg wt III with the ProMaster project, the names of the devices in the ProMaster may not match those in the IEC project. In this case, see Section > Programming the IEC project < from page 140 onward.

5.2.8.2 PLC

After downloading the data to the EtherCAT master and b maXX drive PLC (see >Downloading the data to the EtherCAT master and the b maXX drive PLC <> from page 139 onward), the IEC project on the b maXX drive PLC can be activated and started on the PLC tab ("PLC Status" section).

In addition, data of the b maXX drive PLC, such as the operating system version, firmware version, IEC project and boot project, is also displayed in the "PLC Info" section. Information on the files in the flash memory of the b maXX drive PLC, e.g. on the cam records (see ▷5.2.8.3 Cams◄) is displayed in the "Flash Directory" section (after "Connect" and "Update")

RC ProPLC (_Axis_A	- Slot H - T	yp BM4-O-PLC-(D1-01-	02)	×
IEC PLC Cams	EtherCAT	Motion Control			•
PLC status		PLC Info			
Stop Ca	old start	OmegaOS:	Omega	aOS V3.1.2108) Feb 20 2007
Reset Wa	arm start	Firmware:	1314.0	0112/1276.010	06/1284.0105
Activate H	ot start	IEC project:	Examp	ole_BM4	
		Boot project:	Examp	ole_BM4	
Flash directory					
					Update
Validated files:	1	Version:		V 000.001	
Used memory:	4352 bytes	Maximum files:		512	
Invalid files:	0	Maximum mem	ory:	4096 Kbyte	
Name	Туре	Size			
SetA_512.sk	Cam	4144 Bytes			
	!				
Disconnect STOP Conge Status					
Update total IEC project 📃 🚾 Open IEC project				IEC project	
ProPLC, Version=1.0.1.10, Baumüller Nürnberg 2006					

Figure 74: ProPLC - PLC tab after download of the cam (cam tab)

5.2.8.3 Cams

This section explains how a cam data set is generated and linked with ProMaster.

Open the "PLC Configuration" window in the network view for our local axis (and Ether-CAT master) in the ProMaster project by clicking the "_Axis_A" device and then select "Configuration Data (Components)\PLC (slot H)\PLC - Configuration (ProPLC)" via the context menu and then the "Cams" tab.



RC ProPLC (_Axis_A	Slot H - Ty	yp BM4-0-I	PLC-01-01-	02)			×
IEC PLC Cams	EtherCAT	Motion Co	ntrol				-
IEC-CAM-Variables							
Name	Address	File size	Path				
no entries available							_
			-				
				1	_	• • •	
Add cam sets							
S Online S Library							
					Update	CAM variables	
Connect		OFFLIM	NE			Online Statu	IS
📝 Update total IB	C project			(Open IE	C project	
😰 ProPLC, Version=1.0.1.10, Baumüller Nürnberg 2006							

Figure 75: ProPLC - "Cams" tab with no cam data set

Press the "Add Data Sets" button. The "ProMaster.NET - Cams" window is opened. Press the "Add" button in the "Hard Disk" section and select the path on your hard disk that contains your cam data.

\cap	
\simeq	
ורו	
コレ	

NOTE

Example cam data is found in the installation directory of ProCAM in the "examples" subfolder (e.g. C:\...\Baumueller\ProCam 2\examples).

If you would like to create a cam, click the "ProCAM" button, which opens the cam editor. You can edit your cams there.

Now create your cam data set (in the "*.sk Files" section) by dragging and dropping different cam data (in the "Hard Disk" section).

In our example, we select the cam data "ExampleGerade_MC.kbin" and "ExamplePendelP5_MC.kbin", which are combined in the "SetA_512" cam data set.

NOTE

You can display the cam data graphically (in the respective section) via the "Preview" button. This simplifies cam selection.

Then click the "Save" button. This creates the cam data set and makes ProMaster available.

🕶 ProMaster.NET - Kurvenscheiben	×
Add X Remove View data Harddisk	File: C:\~ \ExamplePendelP5 _MC.kbin Data: Mainpoints: 512 Offset: 0 Minimum: 0 Maximum: 3435973836
*.sk Files SetA_512 ExampleGerade_MC.kbin ExamplePendelP5_MC.kbin Save Save Save MC Save all X Delete MC View data	
ProCam	<u></u>

Figure 76: ProPLC (- Cams tab -) Generating cam data set

Now close the "ProMaster.NET - Cams" window by clicking "x" on the top right.

You can now see the name of the variables of the cam data set in the IEC project, its address in the IEC project and the file name of the cam data set on the hard disk via the "Cams" tab.



RC ProPLC (_Ax	tis_A - Slot H - Typ	BM4-O-PLC-0	1-01-02)		×
IEC PLC	ams EtherCAT	Motion Control			-
IEC-CAM-Variable:	s				
Name	Address	File size	Path		
[_SetA_512]	%MD3.970000	4144 Bytes	C:\Baum	ueller\ProMasterNE	
			T.		
				Add cam sets	
S Online S Library					
			2	Update CAM variable	es
Connect		OFFLINE		Online St.	atus
📝 Update	total IEC project			Open IEC project	
😰 ProPLC, Version=1.0.1.10, Baumüller Nürnberg 2006					

Figure 77: ProPLC - "Cams" tab with cam data set

If you link an existing application (or template) from ProProg wt III with the ProMaster project, the cam data set name in ProMaster may not match that in the IEC project. In this case, see section ▷Programming the IEC project < from page 140 onward.

From the "Cam" tab, you can clear the flash memory on the b maXX drive PLC via the "Clear Flash" button ("U Online" section). This may be necessary if the flash memory is "full" because of various downloads (both cam data sets and IEC projects).

In addition, you can download cam data sets to the b maXX drive PLC individually via the "Download Data Sets" button on the "Cams" tab.

Now load the cam data sets onto the b maXX drive PLC via the "Download Data Sets" button (" \Downarrow Online" section).

5.2.8.4 EtherCAT

The name, data type, address and comment of the network variables of the EtherCAT slave in the IEC project are displayed on the "EtherCAT" tab.

If motion control is used, communication occurs via the axis variable. ProMaster recreates the axis variable with the device name of the EtherCAT slave after the "Update total IEC project" button is pressed (see section >Downloading the data to the EtherCAT master and the b maXX drive PLC < from page 139 onward). ProMaster also creates network variables in the IEC project. These are divided into standard network variables for motion control and, if additional objects were created during configuration of the EtherCAT slave, additional network variables for EtherCAT. The "EtherCAT" tab displays these network variables, both the standard network variables for motion control and the additional network variables for EtherCAT.

The following must be heeded:

The standard network variables for motion control may be read, but not written, by the user.

These are the standard motion control network variables for the setpoint values:

"u_controlword"	for the control word of the axis
"ud_PosIpSetAngel"	for the synchronization position setpoint angle of the axis
These are the standard motion control netwo	ork variables for the actual values:
"u_statusword"	for the status word of the axis
"ud_Enc1ActAngle"	for the synchronization position actual angle of the axis
"si_modes_of_operation_display"	for the operating mode of the axis



NOTE

The standard network variables for motion control may be read by the user, but not written.



NOTE

The standard network variables must be read in the motion control event task.

The number after the network variable name is an internal number used to differentiate between identically sounding, automatically generated network variable names.

R.C I	RC ProPLC (_Axis_A - Slot H - Typ BM4-0-PLC-01-01-02) X						
IEC	IEC PLC Cams EtherCAT Motion Control -						
Ether	EtherCAT Master: Slot G [BM4-O-ECT-02-00-00] 🛛 🔽 Update list						
No	Name	Туре	Address	Description			
1	di_ApplicationParam1	DINT	%MD 3.2040960	_Axis_A> _Axis_B: Index: 4CF2			
2	ud_PosIpSetAngle	UDINT	%MD 3.2040964	_Axis_A> _Axis_B: Index: 60FB Subindex: 17			
3	u_controlword	UINT	%MW 3.2040968	_Axis_A> _Axis_B: Index: 6040			
4	di_SpeedActValue	DINT	%MD 3.2041216	_Axis_B: Index: 4161> _Axis_A			
5	ud_Enc1ActAngle	UDINT	%MD 3.2041220	_Axis_B: Index: 60FB Subindex: A> _Axis_A			
6	u_statusword	UINT	%MW 3.2041224	_Axis_B: Index: 6041> _Axis_A			
7	7 si_modes_of_operation_di SINT %MB 3.2041226 _Axis_B: Index: 6061> _Axis_A						
<	<pre></pre>						
	Name: di_ApplicationParam1						
	Update EtherCAT variables						
0	Connect OFFLINE Online Status						
	Update total IEC project Open IEC project						
	😰 ProPLC, Version=1.0.1.10, Baumüller Nürnberg 2006						

Figure 78: ProPLC - EtherCAT tab

If you created additional network variables (and their link to EtherCAT slaves) when configuring EtherCAT slave communication in Section >Configuring EtherCAT communication with ProEtherCAT

E.g. an additional network variable for the set value is:

"di_ApplicationParam1.." for application parameter 1 of the axis,

- e.g. an additional network variable for the actual value is:
 - "di_SpeedActValue.." for the actual speed value of the axis

When changing the network variable names, note that each variable name can be issued only once in the IEC project. This is especially important to note when using several EtherCAT master modules on the b maXX drive PLC.

NOTE

Each variable name may be issued only once in the IEC project.

NOTE

The additional network variables for the set values must be written in the motion control event task.

The additional network variables for the set values must be written at every call of the motion control event task.

For more informations please refer to Ethernet with EtherCAT master for b maXX drive PLC application manual.

5.2.8.5 Motion Control

All general settings for motion control will be made on the "Motion Control" tab in the future.

If you would like to use the default motion control settings, you do not need to make any settings here.

5.2.9 Downloading the data to the EtherCAT master and the b maXX drive PLC

At present, downloading of the data for the EtherCAT master occurs see Ethernet with EtherCAT master for b maXX drive PLC application manual.

Downloading of the cam data sets for the b maXX drive PLC currently occurs via the "Cams" tab of the PLC configuration. For this purpose, see Section ▶Cams ◄ from page 133 onward.

Downloading the IEC project for the bmaXX drive PLC currently occurs via ProProg wt III, as usual.

Now click the "Update total IEC project" button in the "PLC Configuration" window. The data for the b maXX drive PLC is now generated. This procedure can take some time, since ProProg wt III is opened and the configured IEC variables are written in the global variable worksheet in the IEC project, among other things.

Afterwards you can compile the IEC project by confirming the correspondent request with "Yes".

ProPLC 🛛
The IEC variables were updated. Should the IEC project be compiled?
<u>]</u> a <u>N</u> ein

Figure 79: ProMaster - compile the updated IEC project

You can compile alternatively the IEC project in ProProg wt III via the ProProg wt III menu "Build\Rebuild Project".



Now download the IEC project to the b maXX drive PLC (ProProg wt III menu "Online\ Ressource Control..." \rightarrow "Send" \rightarrow "Send" Boot Project).

Now perform a reset of the b maXX drive PLC and then switch the PLC to the "RUN" state (alternatively, you can switch the entire EtherCAT network off and then on again).

You can now control the local axis _Axis_A and the EtherCAT slave axis _Axis_B via the IEC project in ProProg wt III.

5.2.10 Programming the IEC project

5.2.10.1 General information

For information on how to program a motion control application in the IEC project in ProProg wt III, please refer to the motion control application manual and the Online Help System of ProProg wt III.

ProProg wt III is opened with our IEC project "Example_BM4_O_ECT02_MA_2.mwt" via the context menu on _Axis_A "Configuration Data (Components)\PLC (Slot H)\IEC Programming (ProProg wt III)". You can edit the IEC project as usual.

ProMaster has written

- the motion-control axis variables (in the MC_Axis_Variables section)
- the cam data set (in the MC_CamDataSet section)
- the network variables for EtherCAT (in the EtherCATVariables section)
- the network variables of the local axis (in the LocalAxisVariables section) (standard network variables for motion control and additional network variables for the local axis, see ▷ Exchanging data < from page 142 onward)

in the global variable worksheet "Global_Variables".

	Global_Variables:SH03_30.PLC01						
	Name	Туре	Usage	Description	Address		
	🗄 Global_Variables			¢			
	MyApplication						
	_MyMaster	AXI	VAR_GLO	Not from ProMaster			
	MC_AxisVariables						
	_Axis_A	AXI	VAR_GLO	1. Achse	%MD3.451500		
	_Axis_B	AXI	VAR_GLO	2. Achse	%MD3.457300		
	∃ MC_MasterRef						
	∃ MC_SystemReserved	t					
	∃ MC_AxisRef						
	∃ MC_BacilnitRef						
	∃ MC_AxisPDORef						
	⊞ MC_TriggerRef						
	∃ MC_IRPRef						
	MC_CamDataSet						
	s_File_SetA_512	FileS	VAR_GLO		%MD3.970000		
	_SetA_512	MC	VAR_GLO		%MD3.970000		
	EtherCAT Variables						
	🖃 LocalAxisVariables						
	w_Controlword	WORD	VAR_GLO	BM_w_Controlword [P300]	%M/V3.466800		
	ud_PoslpSetAngle1	UDINT	VAR_GLO	BM_ud_PoslpSetAngle [P370]	%MD3.466804		
	di_ApplicationParam11	DINT	VAR_GLO	BM_di_ApplicationParam1 [P3314]	%MD3.466808		
	w_Statusword	WORD	VAR_GLO	BM_w_Statusword [P301]	%MW3.466828		
	i_OperationModeAct	INT	VAR_GLO	BM_i_OperationModeAct [P304]	%MVV3.466832		
	ud_Enc1ActAngle1	UDINT	VAR_GLO	BM_ud_Enc1ActAngle [P391]	%MD3.466836		
	di_SpeedActValue1	DINT	VAR_GLO	BM_di_SpeedAct∀alue [P353]	%MD3.466840		
<					>		

Figure 80: ProProg wt III - Global variable worksheet with the ProMaster data

The following, in particular, must be heeded:

The device name of the device on the EtherCAT bus (local axis/EtherCAT master, Ether-CAT slave(s)) in ProMaster is also the name of the axes in the IEC project in ProProg wt III. This means that if you have linked an existing application (or template) from ProProg wt III with the ProMaster project, the names of the devices in ProMaster may not match those in the IEC project. In this case, there are two possible solutions:

- 1 ProMaster changes the axis names to the device names in ProMaster in the "MC_AxisVariables" section of the "Global_Variables" variable worksheet in ProProg wt III, and the user changes the axis names in the POEs to the device names in ProMaster (via the ProProg wt III function "Replace Globally").
- 2 You change the device names in ProMaster to the axis names in ProProg wt III.

In our example, we have given the local axis the device name _Axis_A and the EtherCAT slave the device name _Axis_B in ProMaster. This is also the axis name from our motion control template used for our IEC project.

This also applies for the cam data set name in the IEC project in ProProg wt III. This means that if you link an existing application (or template) from ProProg wt III with the ProMaster project, the name of the cam data set in ProMaster may not match that in the IEC project. In this case, the following applies:



ProMaster changes the cam data set names to the cam data set names in ProMaster in the "MC_CamDataSet" section of the "Global_Variables" variable worksheet in ProProg wt III, and the user changes the cam data set names in the POEs to the cam data set names in ProMaster (via the ProProg wt III function "Replace Globally").

5.2.10.2 Exchanging data

- A global variable is required for exchanging data between
- the function modules in the IEC project on the b maXX drive PLC (BM4-O-PLC-0x) and the local axis and
- the function modules in the IEC project on the b maXX drive PLC (BM4-O-PLC-0x), the Ether-CAT master option module (BM4-O-ETH-02) and (via the EtherCAT field bus) the EtherCAT slave.

These variables are also called axis variables and have axis names in the IEC project.

Our axis variable for the local axis has the axis name _Axis_A.

Our axis variable for the EtherCAT slave axis has the axis name _Axis_B.

We have given our local axis the device name _Axis_A and our EtherCAT slave the (same-sounding) name _Axis_B in ProMaster, which is why we do not need to make any adjustments here.

The same applies for the variable for the cam data, which has the cam data set name _SetA_512 in the IEC project and ProMaster.

The axis variable and the cam data variable are connected to the motion control function modules in the IEC project. The machine functions are programmed with the motion control function modules.

Information on using the motion control function modules is found in the motion control application manual.

If motion control is used, communication occurs via the axis variable. ProMaster creates network variables in the IEC project. These are divided into standard network variables for motion control and, if additional objects were created during configuration of the BACI communication, additional network variables for the local axis.

The following must be heeded:

The standard network variables for motion control may be read, but not written, by the user.

_Axis_A (local axis)

These are the standard motion control network variables for the set values:

"w_controlword"	for the control word of the axis
"ud_PoslpSetAngel1"	for the synchronization position setpoint an- gle of the axis

These are the standard motion control network variables for the actual values:

"w_statusword"	for the status word of the axis
"ud_Enc1ActAngle1"	for the synchronization position actual angle of the axis
"i_OperationModeAct"	for the operating mode of the axis

The additional network variables for the local axis are written (set values) and read (actual values) by the user.

If you created the additional network variables (and their link to the parameters of the b maXX controller) that were suggested when configuring BACI communication in Sections >PD Receive tab < from page 127 onward and >PD Transmit tab < from page 128 onward, the additional network variable for the set values are:

"di_ApplicationParam1.." for application parameter 1 of the axis

The additional network variable for the actual value is:

"di_SpeedActValue.." for the actual speed value of the axis

_Axis_B (EtherCAT slave axis)

These are the standard motion control network variables for the set values:

rol word of the axis
hronization position setpoint an- xis

These are the standard motion control network variables for the actual values:

"u_statusword"	for the status word of the axis
"ud_Enc1ActAngle"	for the synchronization position actual angle of the axis

"si_modes_of_operation_display.." for the operating mode of the axis

If you created the additional network variables (and their link to EtherCAT slaves) that were suggested when configuring EtherCAT slave communication in sections >PD Receive tab < from page 127 onward and >PD Transmit tab < from page 128 onward, you see the additional network variable for the set values.

E.g. an additional network variable for the set value is:

"di_ApplicationParam1.." for application parameter 1 of the axis,

e.g. an additional network variable for the actual value is:

"di_SpeedActValue.." for the actual speed value of the axis

The number after the network variable name is an internal number used to differentiate between identically sounding, automatically generated network variable names.



NOTE

The standard network variables for motion control may be read, but not written, by the user.

The additional network variables for EtherCAT are written (set values) and read (actual values) by the user.



NOTE

If motion control is used, the network is started automatically via motion control.





NOTE

The additional network variables for the set values must be written in the motion control event task.

The additional network variables for the set values must be written at every call of the motion control event task.

5.3 PROPROG wt II

5.3.1 b maXX PLC and controller

Process data:

The b maXX drive PLC takes the controller's actual values and the status word in a definable time raster from BACI and transfers the reference values and the control word via BACI to the controller.

At transfer of the actual values and the status word, the system triggers the "BACI process data" hardware event in the b maXX drive PLC. This event can trigger an event task in the b maXX drive PLC in which BACI process data communication can be carried out.

The system sets the instant or the timing code for communication at initialization of the process data communication in the user program using FB BACI_INIT.

Service data:

The b maXX drive PLC transfers a read parameter or write parameter job to BACI. The controller reads the job from BACI, processes the appropriate parameters in the controller (see the respective controller description) and returns the result to BACI. The b maXX drive PLC then reads the result of communication from BACI.

5.3.2 Programming BACI communication on the b maXX drive PLC

Due to compatibility the function blocks of the libraries for PROPROG wt II are available in the libraries for ProProg wt III. The function blocks are written in the following.



NOTE

The following function blocks, also written for ProProg wt III, are not used for new projects with ProMaster, ProProg wt III and Motion Control
You program the b maXX drive PLC using the PROPROG wt II or ProProg wt III programming system (see the PROPROG wt II programming manual or the Online Help System of ProProg wt III).

The Baumüller user libraries SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) and SYSTEM2_PLC01_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or above are available for programming BACI communication.

In library SYSTEM1_PLC01_20bd00 (PROPROG wt II) or SYSTEM1_PLC01_30bd00 (ProProg wt III) or above, function blocks are available for initializing process data communication, for process data communication and for service data communication.

You need the following FBs for process data communication:

BACI_INIT	Initializing process data communication.
BACI_PD_COMM	Process data communication

You need the following FBs for requirements data communication:

BACI_PAR_READ	Service data communication (read parameter job)
BACI_PAR_WRITE	Service data communication (write parameter job)

Library SYSTEM2_PLC01_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or above contains amongst others, the following function block:

INTR_SET	is used by FB BACI_INIT
	(FB for linking and activating a hardware signal with
	the BACI process data event.)



5.3.3 Function Blocks for BACI Overview

In addition to the standard function blocks, you can use manufacturer-defined function blocks if you have logged on manufacturer-defined libraries in a project.

Note: Logging on of libraries is described in the general help.

The following function blocks are available for BACI:

Function block	Brief description
BACI_INIT	For initializing BACI (BA umüller C omponent Interface) in the b maXX drive PLC
BACI_PAR_READ	Read BACI parameter
BACI_PAR_WRITE	Write BACI parameter
BACI_PD_COMM	Process data communication via BACI in the b maXX drive PLC for a maximum of eight target and actual values
BACI_PD_RECONFIG	Reconfigure BACI process data communication during ongoing operation

5.3.3.1 BACI_INIT

You can use this function block for BACI to initialize process data communication between the b maXX controller and b maXX drive PLC via the BACI interface.



Note

FB BACI_INIT uses library BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) or higher and firmware library SYSTEM2_PLC01_20bd00 (PROPROG wt II) or SYSTEM2_PLC01_30bd00 (ProProg wt III) or higher.

Application: During the initialization stage (cold boot/warm restart task).



Note

Necessary b maXX controller settings for i_EVENT = INT#11 (=SYNC1 signal source) or i_EVENT = INT#12 (=SYNC2 signal source) on the WinBASS II "Synchronization" side:

- Source for sync signal:
 - "Use Sync 1 signal from BACI" (i_EVENT = INT#11) or
 - "Use Sync 2 signal from BACI" (i_EVENT = INT#12).
- Choose Sync interval (=> the same time period must be connected at input "u_CYCLE_TIME" in µs).
 - Sync offset: -25.0 µs.
 - Sync tolerance: 2.0 µs.

Setting the Sync offset guarantees that the controller has already finished the actual value cycle before the PLC starts its communication cycle.

Otherwise, BACI access conflicts can result when transferring target and actual values in block BACI_PD_COMM.

Parameter input	Data type	Description
_BASE	BACI_CTRL_BMSTRUCT	Operating data for BACI
i_EVENT	INT 0, 4, 8, 11, 12	Event
u_CYCLE_TIME	UINT	BACI cycle time in µs
u_WR_PAR_NR0	UINT	Specified value parameter number 0
u_WR_PAR_NR1	UINT	Specified value parameter number 1
u_WR_PAR_NR2	UINT	Specified value parameter number 2
u_WR_PAR_NR3	UINT	Specified value parameter number 3
u_WR_PAR_NR4	UINT	Specified value parameter number 4
u_WR_PAR_NR5	UINT	Specified value parameter number 5
u_WR_PAR_NR6	UINT	Specified value parameter number 6

Parameter input	Data type	Description
u_WR_PAR_NR7	UINT	Specified value parameter number 7
u_WR_PAR_NR8	UINT	Specified value parameter number 8
u_WR_PAR_NR9	UINT	Specified value parameter number 9
u_WR_PAR_NR10	UINT	Specified value parameter number 10
u_WR_PAR_NR11	UINT	Specified value parameter number 11
u_WR_PAR_NR12	UINT	Specified value parameter number 12
u_WR_PAR_NR13	UINT	Specified value parameter number 13
u_WR_PAR_NR14	UINT	Specified value parameter number 14
u_WR_PAR_NR15	UINT	Specified value parameter number 15
u_RD_PAR_NR0	UINT	Actual value parameter number 0
u_RD_PAR_NR1	UINT	Actual value parameter number 1
u_RD_PAR_NR2	UINT	Actual value parameter number 2
u_RD_PAR_NR3	UINT	Actual value parameter number 3
u_RD_PAR_NR4	UINT	Actual value parameter number 4
u_RD_PAR_NR5	UINT	Actual value parameter number 5
u_RD_PAR_NR6	UINT	Actual value parameter number 6
u_RD_PAR_NR7	UINT	Actual value parameter number 7
u_RD_PAR_NR8	UINT	Actual value parameter number 8
u_RD_PAR_NR9	UINT	Actual value parameter number 9
u_RD_PAR_NR10	UINT	Actual value parameter number 10
u_RD_PAR_NR11	UINT	Actual value parameter number 11
u_RD_PAR_NR12	UINT	Actual value parameter number 12
u_RD_PAR_NR13	UINT	Actual value parameter number 13
u_RD_PAR_NR14	UINT	Actual value parameter number 14
u_RD_PAR_NR15	UINT	Actual value parameter number 15
t_TIME	TIME	Monitoring time in seconds

Parameter output	Data type	Description
_BASE	BACI_CTRL_BMSTRUCT	Operating data for BACI
i_ERR	INT	Error number
x_ERR	BOOL	Error bit
x_OK	BOOL	OK bit

Description

FB BACI_INIT make it possible to initialize process data communication between the b maXX controller and the b maXX drive PLC.

FB BACI_PD_COMM is available for process data communication for applications in the associated bypass interrupt (see Input i_EVENT).

Input/output _BASE:

At _BASE, you must connect a global variable of data type BACI_CTRL _BMSTRUCT.

This global variable is predefined as _PLC_Init in the BM4_O_PLC01 template in PROPROG wt in global variable sheet Global_Variables.

Alternatively, users can create this variable themselves.

In this case, you must locate it by means of declaration of global variables to the base address of the b maXX drive PLC's dual-port RAM, i.e. %MB3.9000000.

Example:

```
_PLC_Init AT %MB3.9000000 : BACI_CTRL_BMSTRUCT;

Where:

_PLC_Init is the variable name with the data type

short designation "_" for Struct

BACI_CTRL_BMSTRUCT is the data type

%MB3.9000000 is the base address of the b maXX drive

PLC's dual-port RAM
```

Input i_EVENT:

i_EVENT = 4 initializes event "BACI process data" with interrupt level 13 (low priority).

i_EVENT = 8 initializes event "BACI process data" with interrupt level 14 (high priority).

i_EVENT = 11 initializes event "SYNC-Signal 1 option module" with interrupt level 14 (high priority).

i_EVENT = 12 initializes event "SYNC-Signal 2 option module" with interrupt level 14 (high priority).

If input i_EVENT is not assigned or i_EVENT = 0, the system does not initialize any events. In this case, new parameter numbers are reconfigured but no interrupt source is set up.

If you want to reconfigure parameter numbers during operation, you should use block BACI_PD_RECONFIG.

If i_EVENT is not 0, 4, 8, 11 or 12, the system sets i_ERR to the value INT#3.

Input u_CYCLE_TIME:

You specify the cycle time of process data communication at input u_CYCLE_TIME. The cycle time of process data communication corresponds to the interval at which the "BACI process data" event triggers an interrupt on the b maXX drive PLC.

The u_CYCLE_TIME value must be a multiple of 125 μ s and be at least 250 μ s.

If u_CYCLE_TIME < 250, 250 μs is set as the cycle time of process data communication.

If u_CYCLE_TIME < 125 * x, the system rounds up and sets 125 μ s * x as the cycle time of process data communication.

Example:

u_CYCLE_TIME = 100: 250 µs is set. u_CYCLE_TIME = 1900: 2000 µs (2 ms) is set.

Inputs u_WR_PAR_NR0 to u_WR_PAR_NR15:

You state the parameter numbers at inputs u_WR_PAR_NR0 to u_WR_PAR_NR15 of the specified values that are to be transferred cyclically. The system then cyclically transfers the specified values themselves in the assigned BYPASS task via block BACI_PD_COMM.

Inputs u_RD_PAR_NR0 to u_RD_PAR_NR15:

You state the parameter numbers at inputs u_RD_PAR_NR0 to u_RD_PAR_NR15 of the actual values that are to be transferred cyclically. The system then cyclically transfers the actual values themselves in the assigned BYPASS task via block BACI_PD_COMM.

Input t_TIME:

You set the monitoring time in seconds at input t_TIME. If Input t_TIME is not assigned, this yields a presetting of TIME#3s. If it is not possible to carry out initialization during the monitoring time, the system issues a corresponding timeout error message.

Output x_OK:

Output x_OK is set to TRUE if it was possible to correctly initialize process data communication between the b maXX controller and b maXX drive PLC via the BACI interface.

Outputs x_ERR, i_ERR:

If an error occurs, the system sets error bit x_ERR to TRUE and outputs error number i_ERR.

Error number i_ERR:

i_ERR	Error
-32768 to -1	Reserved
0	Error i_EVENT initialization
1	Timeout basic init b maXX controller: Wait for ConfDone bit or config flag bit.
2	Timeout Reconfig b maXX controller: Wait for ConfDone bit.
3	Timeout Reconfig b maXX drive PLC: Error in the PLC settings.
4	Input i_EVENT is not 0, 4, 8, 11 or 12.
5 to 32767	Reserved



5.3.3.2 BACI_PAR_READ

You can use this function block for BACI to read a service data value (a parameter value) from the b maXX controller via the BACI interface.



NOTE

FB BACI_PAR_READ uses library BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) or above.

Application: Integrated preferably in the DEFAULT task or in any cyclic task.

Parameter input	Data type	Description
_BASE	BACI_CTRL_BMSTRUCT	Operating data for BACI
u_PAR_NR	UINT	Parameter number
t_ TIME	TIME	Monitoring time
x_EN	BOOL	Release
x_RESET	BOOL	Reset

Parameter output	Data type	Description
_BASE	BACI_CTRL_BMSTRUCT	Operating data for BACI
di_PAR_VALUE	DINT	Read parameter value
x_PAR_FORMAT	BOOL	Format of the parameter (16-/32-bit)
x_BUSY	BOOL	Communication is active
i_ERR	INT	Error number
x_ERR	BOOL	Error bit
x_OK	BOOL	OK bit

Description

FB BAPS_PAR_READ sends a parameter read job to the b maXX controller via parameter number input u_PAR_NR. The system displays the parameter value that the b maXX controller requested at output ud_PAR_VALUE; the format of the parameter is displayed at output x_PAR_FORMAT. If an error occurs when executing the read parameter job, the system sets error bit x_ERR and outputs error number i_ERR.

FB BACI_PAR_READ can be set several times (instantiated) in the same way as FB BACI_PAR_WRITE. However, only one parameter job may be active at the time (i.e. only one FB BACI_PAR_READ or BACI_PAR_WRITE may be active at the time).

Input/output _BASE:

At _BASE, you must connect a global variable of data type BACI_CTRL _BMSTRUCT.

This global variable is predefined as _PLC_Init in the BM4_O_PLC01 template in PROPROG wt in global variable sheet Global_Variables.

Alternatively, users can create this variable themselves.

In this case, you must locate it by means of declaration of global variables to the base address of the b maXX drive PLC's dual-port RAM, i.e. %MB3.9000000.

Example:

PLC_Init	AT	%MB3.900000	:	BACI_CTRL	BMSTRUCT	;	
Where:							
_PLC_I	nit		is th short	ne variable na designation "_	ame with th _" for Struct	e data ty	/pe
BACI_C	TRL_I	BMSTRUCT	is the	e data type			
%MB3.9	00000	00	is the PLC's	e base addres s dual-port RA	ss of the b	maXX dr	ive

Input u_PAR_NR:

At input u_PAR_NR, you state the parameter number of the parameter whose value you want to read.

Input t_TIME:

You set the monitoring time in seconds at input t_TIME. If Input t_TIME is not assigned, this yields a presetting of 3 s. If it is not possible to complete the job within the monitoring time, the system issues a timeout message.

Input x_EN:

Communication is started by means of $x_EN = TRUE$. If x_EN is set to FALSE before $x_BUSY=FALSE$, it is assumed that communication was cancelled deliberately. You must then reset FB BACI_PAR_READ by means of $x_RESET = TRUE$.

Input x_RESET:

You use x_RESET = TRUE to reset the FB.

Output di_PAR_VALUE:

The read parameter value is output at output di_PAR_VALUE.

Output x_PAR_FORMAT:

At output x_PAR_FORMAT, the system outputs the format of the parameter.

With a 16-bit parameter, $x_PAR_FORMAT = FALSE$; with a 32-bi parameter, $x_PAR_FORMAT = TRUE$.

In the case of other parameter formats (e.g. STRING parameter, not currently supported), $x_PAR_FORMAT = FALSE$ stays the same and the system issues a number at i_ERR.



Output x_BUSY:

Output x_BUSY indicates by TRUE that communication is active.

Output x_OK:

The system sets output x_OK to TRUE when communication has been completed successfully.

Outputs x_ERR, i_ERR:

If an error occurs, the system sets error bit x_ERR to TRUE and specifies the error at output i_ERR.

Error number i_ERR:

i_ERR	Error
-32768 to -3	Reserved
-2	Timeout
-1	Read parameter job on the BACI interface was canceled (possibly due to another instance of FB BACI_PAR_READ or FB BACI_PAR_WRITE)
0	No error
1 to 4	Internal message from b maXX controllers 1 - 4
5 to 127	Reserved
128 to 141	Internal message from b maXX controllers 128 - 141
142 to 255	Reserved
256 to 273	Internal message from b maXX controllers 256 - 273
274 to 511	Reserved
512	No data type can be determined
513	Data type is not supported
514	Data type is STRING (is not currently supported).
515 to 32767	Reserved

5.3.3.3 BACI_PAR_WRITE

You can use this function block for BACI to write a service data value (a parameter value) to the b maXX controller via the BACI interface.

NOTE

FB BACI_PAR_WRITE uses library BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) or above.

Application: Integrated preferably in the DEFAULT task or in any cyclic task.

Parameter input	Data type	Description
_BASE	BACI_CTRL_BMSTRUCT	Operating data for BACI
u_PAR_NR	UINT	Parameter number
di_PAR_VALUE	DINT	Parameter value
t_ TIME	TIME	Monitoring time
x_EN	BOOL	Release
x_RESET	BOOL	Reset

Parameter output	Data type	Description
_BASE	BACI_CTRL_BMSTRUCT	Operating data for BACI
x_BUSY	BOOL	Communication is active
i_ERR	INT	Error number
x_ERR	BOOL	Error bit
x_OK	BOOL	OK bit

Description

FB BACI_PAR_WRITE sends a write parameter job to the b maXX controller via parameter number input u_PAR_NR and parameter value di_PAR_VALUE. If an error occurs when executing the write parameter job, the system sets error bit x_ERR and outputs error number i_ERR.

FB BACI_PAR_WRITE can be set several times (instantiated) in the same way as FB BACI_PAR_READ. However, only one parameter job may be active at the time (i.e. only one FB BACI_PAR_READ or BACI_PAR_WRITE may be active at the time).

Input/output _BASE:

At _BASE, you must connect a global variable of data type BACI_CTRL _BMSTRUCT.

This global variable is predefined as _PLC_Init in the BM4_O_PLC01 template in PROPROG wt in global variable sheet Global_Variables.



Alternatively, users can create this variable themselves.

In this case, you must locate it by means of declaration of global variables to the base address of the b maXX drive PLC's dual-port RAM, i.e. %MB3.9000000.

Example:

_PLC_Init AT %MB3.9000000 : BACI_CTRL_BMSTRUCT; Where: _PLC_Init is the variable name with the data type short designation "_" for Struct BACI_CTRL_BMSTRUCT is the data type %MB3.9000000 is the base address of the b maXX drive PLC's dual-port RAM

Input u_PAR_NR:

At input u_PAR_NR, you state the parameter number of the parameter whose value you want to write.

Input di_PAR_VALUE:

You state the parameter value to be written at input di_PAR_VALUE.

Input t_TIME:

You set the monitoring time in seconds at input t_TIME. If Input t_TIME is not assigned, this yields a presetting of 3 s. If it is not possible to complete the job within the monitoring time, the system issues a timeout message.

Input x_EN:

Communication is started by means of $x_EN = TRUE$. If x_EN is set to FALSE before $x_BUSY=FALSE$, it is assumed that communication was cancelled deliberately. You must then reset FB BACI_PAR_WRITE in each case by means of $x_RESET = TRUE$.

Input x_RESET:

You use x_RESET = TRUE to reset the FB.

Output x_BUSY:

Output x_BUSY indicates by TRUE that communication is active.

Output x_OK:

The system sets output x_OK to TRUE when communication has been completed successfully.

Outputs x_ERR, i_ERR:

If an error occurs, the system sets error bit x_ERR to TRUE and specifies the error at output i_ERR. Error number i_ERR:

i_ERR	Error
-32768 to -3	Reserved
-2	Timeout
-1	Write parameter job on the BACI interface was canceled (possibly due to another instance of FB BACI_PAR_READ or FB BACI_PAR_WRITE)
0	No error
1 to 4	Internal message b maXX controllers 1 to 4
5 to 127	Reserved
128 to 141	Internal message b maXX controllers 128 to 141
142 to 255	Reserved
256	Invalid parameter number
257	Invalid data type
258	Value less than minimum value
259	Value greater than maximum value
260	Parameter is read-only, i.e. you are not allowed to write parameters
261	Internal message b maXX controller 261 -
262	Parameter cannot be changed due to the operating status
263	Parameter value is invalid
264 to 273	Internal message b maXX controllers 264 to 511
274 to 281	Reserved
282	Write paramater impossible, because "BACI write access service data" not enabled in drive manager (WinBASS II)
283 to 32767	Reserved



5.3.3.4 BACI_PD_COMM

You can use this function block for BACI to carry out process data communication between the b maXX controller and b maXX drive PLC via the BACI interface.



NOTE

FB BACI_PAR_COMM uses library BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) or above.

Application: In a BYPASS task in which process data communication is to be carried out (i.e. event 4, 8, 11 or 12).

Parameter input	Data type	Description
_BASE	BACI_CTRL_BMSTRUCT	Operating data for BACI
di_WR_VALUE0	DINT	Specified value 0
di_WR_VALUE1	DINT	Specified value 1
di_WR_VALUE2	DINT	Specified value 2
di_WR_VALUE3	DINT	Specified value 3
di_WR_VALUE4	DINT	Specified value 4
di_WR_VALUE5	DINT	Specified value 5
di_WR_VALUE6	DINT	Specified value 6
di_WR_VALUE7	DINT	Specified value 7
di_WR_VALUE8	DINT	Specified value 8
di_WR_VALUE9	DINT	Specified value 9
di_WR_VALUE10	DINT	Specified value 10
di_WR_VALUE11	DINT	Specified value 11
di_WR_VALUE12	DINT	Specified value 12
di_WR_VALUE13	DINT	Specified value 13
di_WR_VALUE14	DINT	Specified value 14
di_WR_VALUE16	DINT	Specified value 15
x_SYNC_CHECK	BOOL	Enable synchronization monitoring
x_EN	BOOL	Enable

Parameter output	Data type	Description
_BASE	BACI_CTRL_BMSTRUCT	Operating data for BACI
di_RD_VALUE0	DINT	Actual value 0
di_RD_VALUE1	DINT	Actual value 1

Parameter output	Data type	Description
di_RD_VALUE2	DINT	Actual value 2
di_RD_VALUE3	DINT	Actual value 3
di_RD_VALUE4	DINT	Actual value 4
di_RD_VALUE5	DINT	Actual value 5
di_RD_VALUE6	DINT	Actual value 6
di_RD_VALUE7	DINT	Actual value 7
di_RD_VALUE8	DINT	Actual value 8
di_RD_VALUE9	DINT	Actual value 9
di_RD_VALUE10	DINT	Actual value 10
di_RD_VALUE11	DINT	Actual value 11
di_RD_VALUE12	DINT	Actual value 12
di_RD_VALUE13	DINT	Actual value 13
di_RD_VALUE14	DINT	Actual value 14
di_RD_VALUE15	DINT	Actual value 15
x_SYNC_ERR	BOOL	Synchronization error bit
i_ERR	INT	Error number
x_ERR	BOOL	Error bit

Description

The specified values are sent to the b maXX controller; the b maXX controller receives the actual values and outputs them.

Input/output _BASE:

At _BASE, you must connect a global variable of data type BACI_CTRL _BMSTRUCT.

This global variable is predefined as _PLC_Init in the BM4_O_PLC01 template in PROPROG wt in global variable sheet Global_Variables.

Alternatively, users can create this variable themselves.

In this case, you must locate it by means of declaration of global variables to the base address of the b maXX drive PLC's dual-port RAM, i.e. %MB3.9000000.

Example:

_PLC_Init AT %MB3.9000000 : BACI_CTRL_BMSTRUCT; Where: _PLC_Init is the variable name with the data type short designation "_" for Struct BACI_CTRL_BMSTRUCT is the data type %MB3.9000000 is the base address of the b maXX drive PLC's dual-port RAM



Inputs di_WR_VALUE0 to di_WR_VALUE15:

At inputs di_WR_VALUE0 to di_WR_VALUE15, you connect the specified values whose parameter numbers were stated at FB BACI_INIT (inputs u_WR_PAR_NR0 to u_WR_PAR_NR15) at initialization of process data communication between the b maXX controller and b maXX drive PLC via the BACI interface (or the parameter numbers that were changed via BACI_PD_RECONFIG).

Input x_SYNC_CHECK:

Using x_SYNC_CHECK = TRUE, you enable synchronization monitoring between the b maXX controller and b maXX drive PLC via the BACI interface. The default setting for x_SYNC_CHECK = TRUE, i.e. synchronization monitoring is enabled.

Input x_EN:

Communication is enabled by means of $x_EN = TRUE$. The default setting is $x_EN = TRUE$, i.e. communication is enabled.

Outputs di_RD_VALUE0 to di_RD_VALUE15:

At outputs di_RD_VALUE0 to di_RD_VALUE15, the system outputs the actual values whose parameter numbers were stated at FB BACI_INIT (inputs u_RD_PAR_NR0 to u_RD_PAR_NR15) at initialization of process data communication between the b maXX controller and b maXX drive PLC via the BACI interface (or the parameter numbers that were changed via BACI_PD_RECONFIG).

Output x_SYNC_ERR:

If you activated synchronization monitoring, the system monitors the Alive Counter. If a synchronization error occurs (i.e. one or more communications cycles are missing), the system sets synchronization error bit x_SYNC_ERR to TRUE.

Outputs x_ERR, i_ERR:

If an error occurs, the system sets error bit x_ERR to TRUE and outputs error number i_ERR.

Error number i_ERR:

If errors occur, check the setting in WinBASS II "Synchronization" page

(Example: SyncOffset = -25.0 µs).

i_ERR	Error
-32768 to -6	Reserved
-5	BACI access conflict at actual value transfer: The b maXX controller has set its "data not valid flag" and "data access flag". => b maXX drive PLC is not allowed to read any actual values from the b maXX controller.
-4	BACI access conflict at actual value transfer: The b maXX controller has set its "data not valid flag" after b maXX drive PLC set its own "data access flag". => b maXX drive PLC is not allowed to read any actual values from the b maXX controller.
-3	BACI access conflict at actual value transfer: The b maXX controller has set its "data access flag". => b maXX drive PLC is not allowed to read any actual values from the b maXX controller.
-2	BACI access conflict at specified value transfer: The b maXX control- ler has set its "data not valid flag" after b maXX drive PLC set its own "data access flag". => b maXX drive PLC is not allowed to read any specified values from the b maXX controller.
-1	BACI access conflict at specified value transfer: The b maXX control- ler has set its "data access flag". => b maXX drive PLC is not allowed to read any specified values from the b maXX controller.
0	No error
1 to 32767	Reserved



5.3.3.5 BACI_PD_RECONFIG

You can use this function block for BACI to reconfigure process data communication between the b maXX controller and b maXX drive PLC via the BACI interface during ongoing operation.



NOTE

FB BACI_PAR_RECONFIG uses library BM_TYPES_20bd03 (PROPROG wt II) or BM_TYPES_30bd01 (ProProg wt III) or above.

During reconfiguration, FB BACI_PD_COMM must be disabled (x_EN := FALSE).

By contrast with block BACI_INIT, you can only change the parameter numbers; the cycle time and interrupt source that were set via BACI_INIT are retained.

Application: For runtime reasons, ntegrated preferably in the DEFAULT task or in any cyclic task. Can also run in a BYPASS task (e.g. event 4, 8, 11 or 12).

Parameter input	Data type	Description
_BASE	BACI_CTRL_BMSTRUCT	Operating data for BACI
u_WR_PAR_NR0	UINT	Specified value parameter number 0
u_WR_PAR_NR1	UINT	Specified value parameter number 1
u_WR_PAR_NR2	UINT	Specified value parameter number 2
u_WR_PAR_NR3	UINT	Specified value parameter number 3
u_WR_PAR_NR4	UINT	Specified value parameter number 4
u_WR_PAR_NR5	UINT	Specified value parameter number 5
u_WR_PAR_NR6	UINT	Specified value parameter number 6
u_WR_PAR_NR7	UINT	Specified value parameter number 7
u_WR_PAR_NR8	UINT	Specified value parameter number 8
u_WR_PAR_NR9	UINT	Specified value parameter number 9
u_WR_PAR_NR10	UINT	Specified value parameter number 10
u_WR_PAR_NR11	UINT	Specified value parameter number 11
u_WR_PAR_NR12	UINT	Specified value parameter number 12
u_WR_PAR_NR13	UINT	Specified value parameter number 13
u_WR_PAR_NR14	UINT	Specified value parameter number 14
u_WR_PAR_NR15	UINT	Specified value parameter number 15
u_RD_PAR_NR0	UINT	Actual value parameter number 0
u_RD_PAR_NR1	UINT	Actual value parameter number 1
u_RD_PAR_NR2	UINT	Actual value parameter number 2
u_RD_PAR_NR3	UINT	Actual value parameter number 3

Parameter input	Data type	Description
u_RD_PAR_NR4	UINT	Actual value parameter number 4
u_RD_PAR_NR5	UINT	Actual value parameter number 5
u_RD_PAR_NR6	UINT	Actual value parameter number 6
u_RD_PAR_NR7	UINT	Actual value parameter number 7
u_RD_PAR_NR8	UINT	Actual value parameter number 8
u_RD_PAR_NR9	UINT	Actual value parameter number 9
u_RD_PAR_NR10	UINT	Actual value parameter number 10
u_RD_PAR_NR11	UINT	Actual value parameter number 11
u_RD_PAR_NR12	UINT	Actual value parameter number 12
u_RD_PAR_NR13	UINT	Actual value parameter number 13
u_RD_PAR_NR14	UINT	Actual value parameter number 14
u_RD_PAR_NR15	UINT	Actual value parameter number 15
x_CFG_INIT	BOOL	Release
t TIME	TIME	Monitoring time in seconds

Parameter output	Data type	Description
_BASE	BACI_CTRL_BMSTRUCT	Operating data for BACI
x_ERR	BOOL	Error bit
x_OK	BOOL	OK bit

Description

FB BACI_PD_RECONFIG allows you to reconfigure the specified value and actual value parameter numbers for process data communication between the b maXX controller and b maXX drive PLC in ongoing operation.

You can only carry out reconfiguration when FB BACI_PD_COMM is disabled (x_EN := FALSE).

Input/output _BASE:

At _BASE, you must connect a global variable of data type BACI_CTRL _BMSTRUCT.

This global variable is predefined as _PLC_Init in the BM4_O_PLC01 template in PROPROG wt in global variable sheet Global_Variables.

Alternatively, users can create this variable themselves.

In this case, you must locate it by means of declaration of global variables to the base address of the b maXX drive PLC's dual-port RAM, i.e. %MB3.9000000.



Example:

_PLC_Ini	t AT	%MB3.900000) :	BACI_CTRL_BMSTRUCT;	
Where	e:				
_PLC	_Init		is th short	he variable name with the data typ rt designation "_" for Struct	pe
BACI	_CTRL_I	BMSTRUCT	is the	ne data type	
%MB3	.90000	00	is the PLC'	he base address of the b maXX driv C's dual-port RAM	ve

Inputs u_WR_PAR_NR0 to u_WR_PAR_NR15:

You state the parameter numbers at inputs u_WR_PAR_NR0 to u_WR_PAR_NR15 of the specified values that are to be transferred cyclically via FB BACI_PD_COMM.

Inputs u_RD_PAR_NR0 to u_RD_PAR_NR15:

You state the actual value parameter numbers at inputs u_WR_PAR_NR0 to u_WR_PAR_NR15 of the actual values that are to be transferred cyclically to inputs u_RD_PAR_NR0 to u_RD_PAR_NR15.

Input t_TIME:

You set the monitoring time in seconds at input t_TIME. If Input t_TIME is not assigned, this yields a presetting of TIME 3s. If it is not possible to complete reconfiguration during the monitoring time, the system sets error bit x_ERR.

Eingang x_CFG_INIT:

x_CFG_INIT = TRUE starts reconfiguration.

Output x_ERR:

A timeout occurred during reconfiguration. Possible cause of the error: Block FB BACI_PD_COMM was not disabled at an x_EN or the system skips it.

Output x_OK:

Output x_OK is set to TRUE if the b maXX controller has taken over the new list of specified and actual value parameter numbers.

Now you can reset x_CFG_INIT and reenable process data communication via block FB BACI_PD_COMM (x_EN = TRUE).

APPENDIX A ABBREVIATIONS

AA	Analog outputs function module	
Para.	Paragraph	
AC	Alternating Current	
ADR	Address byte	
AE	Analog inputs function module	
AK	Job/answer identifier	
BACI	Baumüller Component Interface	
BAPS	Baumüller drives parallel interface	
BASS	Baumüller drives serial interface	
BB	Ready for operation	
BBext	Ready for operation (external)	
BBint	Ready for operation (internal)	
BEDAS	Operating data store	
BOF	Begin of File	
BSE	External reference for 24 V control input	
BUB	Ballast unit	
BUC	Baumüller feed/return feed unit	
BUG	Baumüller converter basic feed unit	
BUM	Baumüller individual power unit	
BUS	Baumüller power module	
CPU	Central Processing Unit	
DA	Digital/analog	
DAC	Digital/analog converter	
DB	Data byte (8 bits)	
DC	direct currentDrive Control	
DIN	Deutsches Institut für Normung e.V. (German Standards Institute)	
DOPPELW Doubleword (32-bit)		
DW	Data word (16-bit)	

Doubleword (32-bit)				
Electromagnetic constant				
Electromagnetic compatibility				
European standard				
End of File				
EXT, ext External				
Leakage current				
Ramp function generator function module				
Main menu				
Highword				
Input/Output				
Rotary encoder function module				
Identification number				
Count unit of the position				
Index				
Number of scale marks of the rota- ry encoder				
Incremental				
Actual value				
Actual value channel				
Light Emitting Diode				
Lowword				
Prefix for hexadecimal numbers				
Medium time lag (fuse)				
RPM speed = 0				
Height above sea level				
Parameter identifier				
Parameter identifier value				
Process data				
Reserved				

- PE Protective earth
- SL PE conductor
- SM Synchronous motor
- STX Start of Text
- SW Specified value
- **SWG** Specified value generator function module
- **SWK** Specified value channel
- USS protocol function module
- **USS[®]** Trademark of Siemens, universal serial interface
- **VBG** Management commercial employers' liability insurance association
- **VDE** Verband deutscher Elektrotechniker (German Association of Electrical Engineers)
- **ZK** Intermediate circuit



Index

R

В		Р
b maXX drive PLC		Personnel
Firmware	49	qualified
BACI function blocks	140	Process data
	140	Brogrommin
BACI Interface Process data communication	158	Project
Read parameter	150	New oper
Write parameter	155	Property
Basic functionality	59	Event Tas
Baumüller	7	PROPROG
Board function	50	PROPROG
С		Q
CAM PLC 21bd00	60	Qualified Pe
CAM_PLC_30bd00	60	
Communication source	28	R
Communication via RS232	31	Real-time re
Control Dialog for Resources	34	REGISTER_
5		REGISTER_
	00.40	Resource
Data Area	28, 42	Settings
Directory path for libraries	49	
Documentation worksheets	29	control dia
E		Responsibili
– Event Task	45	Ксэронзыя
		S
F		Send projec
Firmware library	47	Specialist
Function block	49	Standard lib
INTR_SET	51	SYSTEM1_I
TER_USS	103	SYSTEM2_I
TIME_MEASURE_END	50, 111	т
TIME_MEASURE_START	50, 110	
TIMER_A_INT	67	Technology
G		Cam disk
Global variable worksheets	29	Register o
	20	Winder
1		TER R
I/O configuration	29	TER S
Initializing the BACI interface	147	TER USS
INTR_SET	51	Terms
		Definition
	10	TIME_MEAS
LED display	16	TIME_MEAS
	55	TIMER_A_II
	16 52	
menupi	40, 52	
Ν		UNIVERSAL
New project	27	Incorting in
		moorang n

Personnel qualified Process data communication Reconfiguring Programming languages	13 13 147, 158 162 25
New, open	27
Event Task PROPROG wt II PROPROG wt II library	46 25 61
Q Qualified Personnel	13
R Real-time response REGISTER_PLC_20bd00 REGISTER_PLC_30bd00 Resource Settings Resource BM4_O_PLC01 Resources control dialog Responsibility and liability	45 60 28 31 27 34 13
S Send project to target system Specialist Standard library SYSTEM1_PLC_20bd00 SYSTEM2_PLC_20bd00	36 13 59 50, 59 59
T T64_RSYN Technology component Cam disk Register controller Winder TER_R TER_S TER_USS Terms	98 60 60 93 96 103
Definition TIME_MEASURE_END TIME_MEASURE_START TIMER_A_INIT	5 50, 111 50, 110 67
U UNIVERSAL_20bd00 User library Inserting in a project	59 47 60





W

Warranty and Liability	14
Watchdog	40, 109, 112
monitoring	41
WINDER_PLC_20bd00	60
WINDER_PLC_30bd00	60
Z	
ZWT format file	61

be in motion



All the information in these Operating Instructions is non-binding customer information; it is subject to ongoing further development and is updated on a continuous basis by our permanent change management system. Note that all the data/numbers/information that are quoted are current values at the time of printing. This information is not legally binding for dimensioning, calculation and costing. Before using the information listed in these Operating Instructions as the basis for your own calculations and/or applications, make sure that you have the latest most current information. This means that we accept no resonsibility for the accuracy of the information.